

ACTIVE CUBE

Operating Instructions
Frequency inverter 230 V / 400 V
0.25 kW ... 132 kW



TABLE OF CONTENTS

1	General information about the documentation	10
1.1	Instruction manuals.....	10
1.2	This document.....	12
1.3	Warranty and liability	12
1.4	Obligation	13
1.5	Copyright	13
1.6	Storage.....	13
2	General safety instructions and information on use.....	14
2.1	Terminology	14
2.2	Designated use	15
2.3	Misuse	15
2.3.1	Explosion protection	15
2.4	Residual risks.....	16
2.5	Safety and warning signs at frequency inverter.....	16
2.6	Warning information and symbols used in the user manual	17
2.6.1	Hazard classes	17
2.6.2	Hazard symbols.....	17
2.6.3	Prohibition signs.....	17
2.6.4	Personal safety equipment	18
2.6.5	Recycling.....	18
2.6.6	Grounding symbol	18
2.6.7	ESD symbol	18
2.6.8	Information signs.....	18
2.7	Directives and guidelines to be adhered to by the operator	19
2.8	Operator's general plant documentation.....	19
2.9	Operator's/operating staff's responsibilities.....	19
2.9.1	Selection and qualification of staff	19
2.9.2	General work safety	19
2.10	Organizational measures	20
2.10.1	General	20
2.10.2	Use in combination with third-party products.....	20
2.10.3	Transport and Storage.....	20
2.10.4	Handling and installation.....	20
2.10.5	Electrical connections	20
2.10.5.1	The five safety rules	21
2.10.6	Safe operation	21
2.10.7	Maintenance and service/troubleshooting	22
2.10.8	Final decommissioning.....	22
2.11	Safety Instructions on Function „Safe Torque Off“ (STO)	23
3	Scope of Supply	25
3.1	ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW).....	25
3.2	ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW).....	26
3.3	ACU 401 (18.5 to 30.0 kW)	27
3.4	ACU 401 (37.0 to 65.0 kW)	28
3.5	ACU 401 (75.0 to 132.0 kW)	29

4	Technical Data.....	30
4.1	General technical data	30
4.2	Technical Data – Control Electronic Equipment	31
4.3	ACU 201 (0.25 to 1.1 kW, 230 V)	32
4.4	ACU 201 (1.5 to 3.0 kW, 230 V)	33
4.5	ACU 201 (4.0 to 9.2 kW, 230 V)	34
4.6	ACU 401 (0.25 to 1.5 kW, 400 V)	35
4.7	ACU 401 (1.85 to 4.0 kW, 400 V)	36
4.8	ACU 401 (5.5 to 15.0 kW, 400 V)	37
4.9	ACU 401 (18.5 to 30.0 kW, 400 V)	38
4.10	ACU 401 (37.0 to 65.0 kW, 400 V)	39
4.11	ACU 401 (75.0 to 132.0 kW, 400 V)	40
4.12	Operation diagrams	41
5	Mechanical Installation.....	42
5.1	ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)	43
5.2	ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW).....	44
5.3	ACU 401 (18.5 to 30.0 kW)	45
5.4	ACU 401 (37.0 to 65.0 kW)	46
5.5	ACU 401 (75.0 to 132.0 kW)	47
6	Electrical Installation	48
6.1	EMC Information.....	50
6.2	Block diagram	52
6.3	Optional Components	53
6.4	Connection of Unit	54
6.4.1	Dimensioning of conductor cross-section	54
6.4.1.1	Typical cross-sections	54
6.4.2	Mains Connection	56
6.4.3	Motor Connection.....	56
6.4.3.1	Length of motor cables, without filter	57
6.4.3.2	Motor cable length, with output filter dU/dt	57
6.4.3.3	Motor cable length, with sinus filter	57
6.4.3.4	Group drive	58
6.4.3.5	Speed sensor connection	58
6.4.4	Connection of a Brake Resistor	59
6.5	Connection of types	60
6.5.1	ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW).....	60
6.5.2	ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)	62
6.5.3	ACU 401 (18.5 to 30.0 kW)	64
6.5.4	ACU 401 (37.0 to 65.0 kW)	66
6.5.5	ACU 401 (75.0 to 132.0 kW)	68
6.6	Control Terminals.....	70
6.6.1	External DC 24 V power supply.....	72
6.6.2	Relay Output	72
6.6.3	Motor Thermo-Contact.....	73
6.6.4	Control terminals – Connection diagrams of configurations	73
6.7	Configurations overview.....	74
6.7.1	Configuration 110 – Sensorless Control	75
6.7.2	Configuration 111 – Sensorless Control with Technology Controller.....	75

6.7.3	Configuration 410 – Sensorless Field-Oriented Control	76
6.7.4	Configuration 411 – Sensorless Field-Oriented Control with Technology Controller	77
6.7.5	Configuration 430 – Sensorless FOC, Speed and Torque Controlled	78
6.7.6	Configuration 210 – Field-Oriented Control, Speed Controlled	79
6.7.7	Configuration 211 – Field-Oriented Control with Technology Controller	80
6.7.8	Configuration 230 – Field-Oriented Control, Speed and Torque Controlled	80
6.7.9	Configuration 510 – FOC of Synchronous Machine, Speed Controlled	81
6.7.10	Configuration 530 – FOC of a Synchronous Machine, Speed and Torque Controlled	82
6.7.11	Configuration 610 – Sensorless FOC of Synchronous Machine, Speed Controlled	83
6.7.12	Configuration 611 – Sensorless FOC of a Synchronous Machine with Technology Controller	84
6.7.13	Configuration 630 – Sensorless FOC of a Synchronous Machine, Speed and Torque Controlled	85
6.7.14	Installation notes according to UL508c	86

7 Control Unit KP500 87

7.1	Menu Structure	88
7.2	Main Menu.....	88
7.3	Actual Value Menu (VAL)	89
7.4	Parameter Menu (PARA).....	90
7.5	Copy Menu (CPY)	91
7.5.1	Reading the Stored Information.....	91
7.5.2	Menu Structure	92
7.5.3	Selecting the Source.....	92
7.5.4	Selecting the Destination	93
7.5.5	Copy Operation.....	93
7.5.6	Error Messages	94
7.6	Reading Data from Control Unit	95
7.6.1	Activation	95
7.6.2	Data transfer	96
7.6.3	Resetting to Normal Operation	97
7.7	Control Menu (CTRL)	97
7.8	Controlling the Motor via the Control Unit	98

8 Commissioning of the Frequency Inverter..... 101

8.1	Switching on Mains Voltage.....	101
8.2	Setup Using the Control Unit	101
8.2.1	Configuration	102
8.2.2	Data Set	104
8.2.3	Motor Type.....	104
8.2.4	Machine Data.....	105
8.2.5	Plausibility check.....	106
8.2.6	Parameter identification	107
8.2.7	Status messages during commissioning (SS...)	108
8.2.8	Warnings during commissioning (SA...)	108
8.2.9	Error messages during commissioning (SF...)	110
8.2.10	Application data	111
8.2.10.1	Acceleration and deceleration.....	111
8.2.10.2	Set points at multi-functional input	111
8.2.11	Quitting commissioning.....	112
8.2.12	Selection of an actual value for display.....	112
8.3	Check direction of rotation	113
8.4	Speed sensor.....	114
8.4.1	Speed sensor 1	115
8.4.2	Speed sensor 2	115

8.5	Set-up via the Communication Interface	116
9	Inverter Data	118
9.1	Serial Number	118
9.2	Optional Modules	118
9.3	Inverter Software Version	118
9.4	Set Password	118
9.5	Control Level	119
9.6	User Name.....	119
9.7	Configuration	119
9.8	Language	122
9.9	Programming	122
10	Machine Data	123
10.1	Rated Motor Parameters.....	123
10.2	Further motor parameters	124
10.2.1	Stator Resistance	124
10.2.2	Leakage Coefficient	124
10.2.3	Magnetizing Current	125
10.2.4	Rated slip correction factor	125
10.2.5	Voltage constant	126
10.2.6	Stator inductance	126
10.2.7	Peak current	126
10.2.8	Change sense of rotation	127
10.3	Internal values.....	127
10.4	Speed Sensor 1	128
10.4.1	Operation Mode Speed Sensor 1	128
10.4.2	Division marks, speed sensor 1.....	130
10.4.3	Gear factor speed sensor 1	131
10.4.4	Filter time constant speed sensor 1.....	131
10.5	Sensor evaluation	132
11	System Data	133
11.1	Actual System Value	133
11.2	Volume Flow and Pressure.....	133
12	Operational Behavior	134
12.1	Starting Behavior	134
12.1.1	Starting Behavior of Sensorless Control System.....	134
12.1.1.1	Starting Current	136
12.1.1.2	Frequency Limit	136
12.1.1.3	Brake release time	136
12.1.2	Flux Formation.....	137
12.2	Stopping Behavior.....	138
12.2.1	Switch-Off Threshold	140
12.2.2	Holding Time	140
12.3	Direct current brake.....	140
12.4	Auto Start.....	141
12.5	Search Run.....	142
12.6	Positioning	144
12.6.1	Reference Positioning	144

12.6.2	Axle Positioning.....	147
13	Error and warning behavior	149
13.1	Overload Ixt	150
13.2	Temperature	150
13.3	Controller status	151
13.4	IDC Compensation Limit	151
13.5	Frequency Switch-Off Limit	152
13.6	Motor Temperature	152
13.7	Phase Failure.....	153
13.8	Automatic Error Acknowledgment	153
14	Reference Values.....	154
14.1	Frequency Limits	154
14.2	Slip Frequency.....	154
14.3	Percentage Value Limits	154
14.4	Frequency reference channel.....	154
14.4.1	Block diagram	156
14.5	Reference percentage channel	158
14.5.1	Block diagram	159
14.6	Fixed reference values	161
14.6.1	Fixed Frequencies	161
14.6.2	JOG frequency	162
14.6.3	Fixed Percentages	162
14.7	Frequency ramps	163
14.8	Percentage Value Ramps	166
14.9	Block Frequencies	166
14.10	Motor Potentiometer	167
14.10.1	Motorpoti (MP).....	168
14.10.2	Motorpoti (KP)	168
14.10.3	Controlling the Motor via the Control Unit.....	169
14.11	PWM-/repetition frequency input	170
15	Control Inputs and Outputs	172
15.1	Multi-Function Input MFI1	172
15.1.1	Analog input MFI1A.....	172
15.1.1.1	Characteristic.....	172
15.1.1.2	Scaling	174
15.1.1.3	Tolerance Band and Hysteresis.....	174
15.1.1.4	Filter Time Constant	175
15.1.1.5	Error and warning behavior.....	176
15.2	Multi-Function Output MFO1	177
15.2.1	Analog output MFO1A.....	177
15.2.1.1	Output Characteristic.....	178
15.2.2	Frequency Output MFO1F	179
15.2.2.1	Scaling	179
15.3	Digital Outputs.....	180
15.3.1	Digital Signal	183
15.3.2	Setting Frequency	184
15.3.3	Reference value reached.....	185
15.3.4	Flux Forming finished	186

15.3.5	Brake release.....	186
15.3.6	Current Limitation	186
15.3.7	External Fan	186
15.3.8	Warning Mask.....	187
15.3.9	Application warning mask	190
15.4	Digital inputs.....	191
15.4.1	Start command	196
15.4.2	3-wire control	196
15.4.3	Error Acknowledgment	197
15.4.4	Timer	197
15.4.5	Thermo contact.....	197
15.4.6	n-/M Control Change-Over	197
15.4.7	Data Set Change-Over	198
15.4.8	Fixed Value Change-Over.....	199
15.4.9	Motor Potentiometer.....	199
15.4.10	Handshake Traverse Function	200
15.4.11	User warning	200
15.4.12	External error	200
15.5	Function Modules.....	201
15.5.1	Timer	201
15.5.1.1	Timer – Time Constant	202
15.5.2	Comparator	204
15.5.3	Function table.....	205
15.5.4	Multiplexer/Demultiplexer	206
16	V/f-Characteristic	208
16.1	Dynamic Voltage Pre-Control	209
17	Control Functions	210
17.1	Intelligent current limits	210
17.2	Voltage controller	211
17.3	Technology Controller.....	216
17.4	Functions of Sensorless Control.....	226
17.4.1	Slip compensation	226
17.4.2	Current limit value controller	226
17.5	Functions of Field-Orientated Control	227
17.5.1	Current Controller	227
17.5.2	Extended Current Controller	229
17.5.3	Torque Controller	229
17.5.3.1	Torque Reference.....	230
17.5.3.2	Upper and lower limit of the frequency in Torque Control	230
17.5.3.3	Limit Value Sources	231
17.5.3.4	Switching over between speed control and torque control.....	231
17.5.4	Speed controller.....	232
17.5.4.1	Limitation of Speed Controller	234
17.5.4.2	Limit Value Sources	235
17.5.4.3	Integral time speed synchronization.....	236
17.5.5	Acceleration Pre-Control	236
17.5.6	Field Controller	237
17.5.6.1	Limitation of field controller.....	238
17.5.7	Modulation Controller	239
17.5.7.1	Limitation of Modulation Controller	239
18	Special Functions	240
18.1	Pulse Width Modulation.....	240
18.2	Fan	241

18.3	Bus controller	241
18.4	Brake Chopper and Brake Resistance	243
18.4.1	Dimensioning of Brake Resistor	244
18.5	Motor Protection	245
18.5.1	Motor Protection Switch	245
18.5.2	Motor Protection by I2t- Monitoring	248
18.6	V-belt Monitoring	250
18.7	Functions of Field-Orientated Control	251
18.7.1	Motor Chopper	251
18.7.2	Temperature Adjustment	252
18.7.3	Speed Sensor Monitoring	253
18.8	Traverse function	254
18.9	Converter Profibus from/to Internal Notation	256
19	Actual Values	257
19.1	Actual Values of the Frequency Inverter	257
19.1.1	STO Status	259
19.2	Actual Values of the Machine	260
19.3	Actual value memory	261
19.4	Actual Values of the System	262
19.4.1	Actual System Value	262
19.4.2	Volume Flow and Pressure	263
20	Error Protocol	264
20.1	Error List	264
20.1.1	Error Messages	264
20.2	Error Environment	269
21	Operational and Error Diagnosis	271
21.1	Status Display	271
21.2	Status of Digital Signals	271
21.3	Controller Status	272
21.4	Warning Status and Warning Status Application	273
22	Parameter List	275
22.1	Actual Value Menu (VAL)	275
22.2	Parameter Menu (PARA)	278
Index		287
Functions of the control terminals (table)		289

1 General information about the documentation




For the series of devices ACU (ACTIVE Cube) is for the safety-related commissioning and operation to be complied with the following documentation:

- This Operating instructions
- Application manual "Safe Torque Off ACU"

The present documentation refers to the frequency inverters ACTIVE Cube 201 and ACTIVE Cube 401 series. With their factory settings, both series of devices are suited for a wide range of applications. The modular hardware and software structure enables customer-specific adaptation of the frequency inverters. Applications with high functionality and dynamics requirements can be realized easily.

The ACTIVE Cube series can be recognized by its label on the case and the identification below the top cover.



1.1 Instruction manuals

For better clarity, the documentation is structured according to the customer-specific requirements made on the frequency inverter.

Quick start guide

The Quick Start Guide describes the basic steps required for mechanical and electrical installation of the frequency inverter. The guided commissioning supports you in the selection of necessary parameters and the configuration of the frequency inverter by the software.

Operating instructions

The Operating Instructions describe and document all functions of the frequency inverter. The parameters required for adapting the frequency inverter to specific applications as well as the wide range of additional functions are described in detail.

Application manual

The application manual supplements the documentation for purposeful installation and commissioning of the frequency inverter. Information on various subjects connected with the use of the frequency inverter is described specific to the application.

If you need a copy of the documentation or additional information, contact your local representative of BONFIGLIOLI.

The following instructions are available for the *ACTIVE CUBE* series:

Operating Instructions <i>ACTIVE CUBE</i>	Functions of the frequency inverter.
Quick Start Guide <i>ACTIVE CUBE</i>	Installation and commissioning. Delivered with the device.
Manuals	CM-CAN: Manual CANopen
Communication Interfaces	CM-PDP-V1: Manual Profibus DP-V1
	CM-232/CM-485: Manual VABus (Serial protocol)
	CM-232/CM-485 Modbus: Manual Modbus ASCII and RTU
	CM-VABus/TCP: Ethernet Module CM-VABus/TCP (i.P.)
	CM-ModbusTCP: Ethernet Module CM-Modbus/TCP (i.P.)
	CM-EtherCAT®: Ethernet Module CM-EtherCAT®
	CM-ProfiNet: Ethernet Module CM-ProfiNet (i.P.)
	CM-EtherNet-I/P: Ethernet Module CM-EtherNet-I/P (i.P.)
Manuals	EM-ABS-01: Absolute Encoder Module
Expansion Modules	EM-ENC-01: Encoder Module
	EM-ENC-02: Encoder Module
	EM-ENC-03: Encoder Module
	EM-ENC-04: Encoder Module
	EM-ENC-05: Encoder Module
	EM-IO-01: Expansion Module for Digital inputs/outputs
	EM-IO-02: Expansion Module for Digital inputs/outputs
	EM-IO-03: Expansion Module for Digital inputs/outputs
	EM-IO-04: Expansion Module for Digital inputs/outputs
	EM-RES-01: Resolver Module
	EM-RES-02: Resolver Module
	EM-RES-03: Resolver Module
	EM-SYS: Systembus Module
Application Safe Torque Off	Safety function STO.
Application manual PLC	Logic linking of digital signals. Functions for analog signals such as comparisons and mathematical functions. Graphic functional block programming.
Application manual Positioning	Positioning functions of configurations x40.
Application manual Electronic Gear	Using at least 2 drives as electronic gear with Slave in configuration x15 or x16.
Application manual Crane drives	Extended Brake control for Crane and Hoist drives.

The products for CANopen® communication comply with the specifications of the user organization CiA® (CAN in Automation).

The products for EtherCAT® communication comply with the specifications of the user organization ETG (EtherCAT Technology Group).

The present documentation was prepared with great care and it was subjected to extensive and repeated reviews. For reasons of clarity, it was not possible to include all details of all types of the product in the documentation. Neither was it possible to consider all conceivable installation, operation or maintenance situations. If you require further information or if you meet with specific problems which are not dealt with in sufficient detail in the documentation, contact your national BONFIGLIOLI agent.

We would also like to point out that the contents of this documentation do not form part of any previous or existing agreement, assurance or legal relationship. Neither are they intended to supplement or replace such agreements, assurances or legal relationships. The manufacturer's obligations are exclusively specified in the relevant purchase contract. This contract also contains all and any warranty regulations which may apply to the relevant scope of supply. These contractual warranty provisions are neither extended nor limited by the specifications contained in this documentation.

The manufacturer reserves the right to correct or amend the specifications, product information and omissions in these operating instructions without notice. The manufacturer shall not be liable for any damage, injuries or costs which may be caused by the aforementioned reasons.

This documentation was written in german language. Other language versions are translated.

1.2 This document

The present documentation describes the frequency inverters of the *ACTIVE Cube* series. The modular hardware and software structure enables customer-specific adaptation of the frequency inverter series. Applications with high functionality and dynamism can be realized easily.

The user manual contains important information on the installation and use of the in its specified application range. Compliance with this user manual contributes to avoiding risks, minimizing repair cost and downtimes and increasing the reliability and service life of the frequency inverter.

For this reason, make sure you read the user manual carefully.



WARNING

Compliance with the documentation is required to ensure safe operation of the frequency inverter. BONFIGLIOLI VECTRON GmbH shall not be held liable for any damage caused by any non-compliance with the documentation.



In case any problems occur which are not covered by the documentation sufficiently, please contact the manufacturer.

1.3 Warranty and liability

BONFIGLIOLI VECTRON GmbH would like to point out that the contents of this user manual do not form part of any previous or existing agreement, assurance or legal relationship. Neither are they intended to supplement or replace such agreements, assurances or legal relationships. Any obligations of the manufacturer shall solely be based on the relevant purchase agreement which also includes the complete and solely valid warranty stipulations. These contractual warranty provisions are neither extended nor limited by the specifications contained in this documentation.

The manufacturer reserves the right to correct or amend the specifications, product information and omissions in these operating instructions without notice. The manufacturer shall not be liable for any damage, injuries or costs which may be caused by the aforementioned reasons.

In addition to that, BONFIGLIOLI VECTRON GmbH excludes any warranty/liability claims for any personal and/or material damage if such damage is due to one or more of the following causes:

- inappropriate use of the frequency inverter,
- non-compliance with the instructions, warnings and prohibitions contained in the documentation,
- unauthorized modifications of the solar inverter,
- insufficient monitoring of parts of the machine/plant which are subject to wear,
- repair work at the machine/plant not carried out properly or in time,
- catastrophes by external impact and Force Majeure.

1.4 Obligation

This user manual must be read before commissioning and complied with. Anybody entrusted with tasks in connection with the

- transport,
- assembly,
- installation of the frequency inverter and
- operation of the frequency inverter

must have read and understood the user manual and, in particular, the safety instructions in order to prevent personal and material losses.

1.5 Copyright

In accordance with applicable law against unfair competition, this user manual is a certificate. Any copyrights relating to it shall remain with

BONFIGLIOLI VECTRON GmbH

Europark Fichtenhain B6

47807 Krefeld

Germany

These user manual is intended for the operator of the frequency inverter. Any disclosure or copying of this document, exploitation and communication of its contents (as hardcopy or electronically) shall be forbidden, unless permitted expressly.

Any non-compliance will constitute an offense against the copyright law dated 09 September 1965, the law against unfair competition and the Civil Code and may result in claims for damages. All rights relating to patent, utility model or design registration reserved.

1.6 Storage

The documentation form an integral part of the frequency inverter. It must be stored such that it is accessible to operating staff at all times. In case the frequency inverter is sold to other users, this user manual must also be handed over.

2 General safety instructions and information on use

The chapter "General safety instructions and information on use" contains general safety instructions for the Operator and the Operating Staff. At the beginning of certain main chapters, some safety instructions are included which apply to all work described in the relevant chapter. Special work-specific safety instructions are provided before each safety-relevant work step.

2.1 Terminology

According to the documentation, different activities must be performed by certain persons with certain qualifications.

The groups of persons with the required qualification are defined as follows:

Operator

This is the entrepreneur/company who/which operates the frequency inverter and uses it as per the specifications or has it operated by qualified and instructed staff.

Operating staff

The term Operating Staff covers persons instructed by the Operator of the frequency inverter and assigned the task of operating the frequency inverter.

Qualified staff

The term Qualified Staff covers staff who is assigned special tasks by the Operator of the frequency inverter, e.g. installation, maintenance and service/repair and troubleshooting. Based on their qualification and/or know-how, qualified staff must be capable of identifying defects and assessing functions.

Qualified electrician

The term Qualified Electrician covers qualified and trained staff who has special technical know-how and experience with electrical installations. In addition, Qualified Electricians must be familiar with the applicable standards and regulations, they must be able to assess the assigned tasks properly and identify and eliminate potential hazards.

Instructed person

The term Instructed Person covers staff who was instructed and trained about/in the assigned tasks and the potential hazards that might result from inappropriate behavior. In addition, instructed persons must have been instructed in the required protection provisions, protective measures, the applicable directives, accident prevention regulations as well as the operating conditions and verified their qualification.

Expert

The term Expert covers qualified and trained staff who has special technical know-how and experience relating to frequency inverter. Experts must be familiar with the applicable government work safety directives, accident prevention regulations, guidelines and generally accepted rules of technology in order to assess the operationally safe condition of the frequency inverter.

2.2 Designated use

The frequency inverter is designed according to the state of the art and recognized safety regulations.

The frequency inverters are electrical drive components intended for installation in industrial plants or machines. Commissioning and start of operation is not allowed until it has been verified that the machine meets the requirements of the EC Machinery Directive 2006/42/EC and DIN EN 60204-1.

The frequency inverters meet the requirements of the low voltage directive 2006/95/EEC and DIN EN 61800-5-1. CE-labeling is based on these standards. Responsibility for compliance with the EMC Directive 2004/108/EC lies with the operator. Frequency inverters are only available at specialized dealers and are exclusively intended for commercial use as per EN 61000-3-2.

No capacitive loads may be connected to the frequency inverter.

The technical data, connection specifications and information on ambient conditions are indicated on the rating plate and in the documentation and must be complied with in any case.

2.3 Misuse

Any use other than that described in "Designated use" shall not be permissible and shall be considered as misuse.

For example, the machine/plant must not be operated

- by uninstructed staff,
- while it is not in perfect condition,
- without protection enclosure (e.g. covers),
- without safety equipment or with safety equipment deactivated.

The manufacturer shall not be held liable for any damage resulting from such misuse. The sole risk shall be borne by the operator.

2.3.1 Explosion protection

The frequency inverter is an IP 20 protection class device. For this reason, use of the device in explosive atmospheres is not permitted.

2.4 Residual risks

Residual risks are special hazards involved in handling of the frequency inverter which cannot be eliminated despite the safety-compliant design of the device. Residual risks are not obviously identifiable and can be a potential source of injury or health hazard.

Typical residual hazards include:

Electrical hazard

Danger of contact with energized components due to a defect, opened covers or enclosures or improper working on electrical equipment.

Danger of contact with energized components inside of the frequency inverter if no external disconnection device was installed by the operator.

Electrostatic charging

Touching electronic components bears the risk of electrostatic discharges.

Thermal hazards

Risk of accidents by hot machine/plant surfaces, e.g. heat sink, transformer, fuse or sine filter.

Charged capacitors in DC link

The DC link may have dangerous voltage levels even up to three minutes after shutdown.

Danger of equipment falling down/over, e.g. during transport

Center of gravity is not the middle of the electric cabinet modules.

2.5 Safety and warning signs at frequency inverter

- Comply with all safety instructions and danger information provided on the frequency inverter.
- Safety information and warnings on the frequency inverter must not be removed.

2.6 Warning information and symbols used in the user manual

2.6.1 Hazard classes

The following hazard identifications and symbols are used to mark particularly important information:



DANGER

Identification of immediate threat holding a **high** risk of death or serious injury if not avoided.



WARNING

Identification of immediate threat holding a **medium** risk of death or serious injury if not avoided.







CAUTION

Identification of immediate threat holding a **low** risk of minor or moderate physical injury if not avoided.


NOTE

Identification of a threat holding a risk of material damage if not avoided.


2.6.2 Hazard symbols

Symbol	Meaning	Symbol	Meaning
	General hazard		Suspended load
	Electrical voltage		Hot surfaces


2.6.3 Prohibition signs

Symbol	Meaning
	No switching; it is forbidden to switch the machine/plant, assembly on


2.6.4 Personal safety equipment

Symbol	Meaning
	Wear body protection


2.6.5 Recycling

Symbol	Meaning
	Recycling, to avoid waste, collect all materials for reuse


2.6.6 Grounding symbol

Symbol	Meaning
	Ground connection

2.6.7 ESD symbol

Symbol	Meaning
	ESD: Electrostatic Discharge (can damage components and assemblies)

2.6.8 Information signs

Symbol	Meaning
	Tips and information making using the frequency inverter easier.

2.7 Directives and guidelines to be adhered to by the operator

The operator must follow the following directives and regulations:

- Ensure that the applicable workplace-related accident prevention regulations as well as other applicable national regulation are accessible to the staff.
- An authorized person must ensure, before using the frequency inverter, that the device is used in compliance with its designated use and that all safety requirements are met.
- Additionally, comply with the applicable laws, regulations and directives of the country in which the frequency inverter is used.
- Any additional guidelines and directives that may be required additionally shall be defined by the operator of the machine/plant considering the operating environment.

2.8 Operator's general plant documentation

- In addition to the user manual, the operator should issue separate internal operating instructions for the frequency inverter. The user manual of the frequency inverter must be included in the user manual of the whole plant.

2.9 Operator's/operating staff's responsibilities

2.9.1 Selection and qualification of staff

- Any work on the frequency inverter may only be carried out by qualified technical staff. The staff must not be under the influence of any drugs. Note the minimum age required by law. Define the staff's responsibility in connection with all work on the frequency inverter clearly.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering.
- The operating staff must be trained for the relevant work to be performed.

2.9.2 General work safety

- In addition to the user manual of the machine/plant, any applicable legal or other regulations relating to accident prevention and environmental protection must be complied with. The staff must be instructed accordingly.
Such regulations and/or requirements may include, for example, handling of hazardous media and materials or provision/use of personal protective equipment.
- In addition to this user manual, issue any additional directives that may be required to meet specific operating requirements, including supervision and reporting requirements, e.g. directives relating to work organization, workflow and employed staff.
- Unless approved of expressly by the manufacturer, do not modify the frequency inverter in any way, including addition of attachments or retrofits.
- Only use the frequency inverter if the rated connection and setup values specified by the manufacturer are met.
- Provide appropriate tools as may be required for performing all work on the frequency inverter properly.

2.10 Organizational measures

2.10.1 General

- Train your staff in the handling and use of the frequency inverter and the machine/plant as well as the risks involved.
- Use of any individual parts or components of the frequency inverter in other parts of the operator's machine/plant is prohibited.
- Optional components for the frequency inverter must be used in accordance with their designated use and in compliance with the relevant documentation.

2.10.2 Use in combination with third-party products

- Please note that BONFIGLIOLI VECTRON GmbH will not accept any responsibility for compatibility with third-party products (e.g. motors, cables or filters).
- In order to enable optimum system compatibility, BONFIGLIOLI VECTRON GmbH office components facilitating commissioning and providing optimum synchronization of the machine/plant parts in operation.
- If you use the frequency inverter in combination with third-party products, you do this at your own risk.

2.10.3 Transport and Storage

- The frequency inverters must be transported and stored in an appropriate way. During transport and storage the devices must remain in their original packaging.
- The units may only be stored in dry rooms which are protected against dust and moisture and are exposed to little temperature deviations only. The requirements of DIN EN 60721-3-1 for storage, DIN EN 60721-3-2 for transport and labeling on the packaging must be met.
- The duration of storage without connection to the permissible nominal voltage may not exceed one year.

2.10.4 Handling and installation

- Do not commission any damaged or destroyed components.
- Prevent any mechanical overloading of the frequency inverter. Do not bend any components and never change the isolation distances.
- Do not touch any electronic construction elements and contacts. The frequency inverter is equipped with components which are sensitive to electrostatic energy and can be damaged if handled improperly. Any use of damaged or destroyed components will endanger the machine/plant safety and shall be considered as a non-compliance with the applicable standards.
- Only install the frequency inverter in a suitable operating environment. The frequency inverter is exclusively designed for installation in industrial environments.
- If seals are removed from the case, this can result in the warranty becoming null and void.

2.10.5 Electrical connections

- The five safety rules must be complied with.
- Never touch live terminals. The DC link may have dangerous voltage levels even up to three minutes after shutdown.
- When performing any work on/with the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants of the country when the frequency inverter is used.
- The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.
- Only connect the frequency inverter to suitable supply mains.

2.10.5.1 The five safety rules

When working on/in electrical plants, always follow the five safety rules:

1. Isolate
2. Secure to prevent restarting
3. Check isolation
4. Earth and short-circuit,
5. Cover or shield neighboring live parts.

2.10.6 Safe operation

- During operation of the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to the applicable national and international safety directives.
- During operation, never open the machine/plant
- Do not connect/disconnect any components/equipment during operation.
- The machine/plant holds high voltage levels during operation, is equipped with rotating parts (fan) and has hot surfaces. Any unauthorized removal of covers, improper use, wrong installation or operation may result in serious injuries or material damage.
- Some components, e.g. the heat sink or brake resistor, may be hot even some time after the machine/plant was shut down. Don't touch any surfaces directly after shutdown. Wear safety gloves where necessary.
- The frequency inverter may hold dangerous voltage levels until the capacitor in the DC link is discharged. Wait for at least 3 minutes after shutdown before starting electrical or mechanical work on the frequency inverter. Even after this waiting time, make sure that the equipment is deenergized in accordance with the safety rules before starting the work.
- In order to avoid accidents or damage, only qualified staff and electricians may carry out the work such as installation, commissioning or setup.
- In the case of a defect of terminals and/or cables, immediately disconnect the frequency inverter from mains supply.
- Persons not familiar with the operation of frequency inverters must not have access to the frequency inverter. Do not bypass nor decommission any protective facilities.
- The frequency inverter may be connected to power supply every 60 s. This must be considered when operating a mains contactor in jog operation mode. For commissioning or after an emergency stop, a non-recurrent, direct restart is permissible.
- After a failure and restoration of the power supply, the motor may start unexpectedly if the Auto Start function is activated.
If staff is endangered, a restart of the motor must be prevented by means of external circuitry.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to EN 60204 and applicable the safety directives (e.g. Working Machines Act or Accident Prevention Directives).

2.10.7 Maintenance and service/troubleshooting

- Visually inspect the frequency inverter when carrying out the required maintenance work and inspections at the machine/plant.
- Perform the maintenance work and inspections prescribed for the machine carefully, including the specifications on parts/equipment replacement.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering. Only use original spare parts.
- Unauthorized opening and improper interventions in the machine/plant can lead to personal injury or material damage. Repairs on the frequency inverters may only be carried out by the manufacturer or persons authorized by the manufacturer. Check protective equipment regularly.
- Before performing any maintenance work, the machine/plant must be disconnected from mains supply and secured against restarting. The five safety rules must be complied with.

2.10.8 Final decommissioning

Unless separate return or disposal agreements were made, recycle the disassembled frequency inverter components:

- Scrap metal materials
- Recycle plastic elements
- Sort and dispose of other component materials



Electric scrap, electronic components, lubricants and other utility materials must be treated as special waste and may only be disposed of by specialized companies.



In any case, comply with any applicable national disposal regulations as regards environmentally compatible disposal of the frequency inverter. For more details, contact the competent local authorities.

2.11 Safety Instructions on Function „Safe Torque Off“ (STO)

The function “Safe Torque Off” (STO) is a functional safety provision, i.e. it protects staff from damage, provided that projecting, installation and operation are performed properly. This function does not disconnect the plant from power supply.

To disconnect the plant from power supply (for example for service purposes) an “Emergency Stop” circuit according to EN 60204 has to be installed.

For maintenance work, a provision must be provided for disconnecting the plant from power supply.

WARNING

Improper installation of the safety technique can cause an uncontrolled starting of the drive. This may cause death, serious injuries and significant material damage.

Safety functions may only be installed and commissioned by qualified staff.

The STO function is not suitable for emergency switch off as per EN 60204. An emergency switch off can be realized by installing a mains contactor.

An emergency stop according to EN 60204 must be functioning in all operation modes of the frequency inverter. Resetting of an emergency stop must not result in uncontrolled starting of the drive.

The drive is started again when the function STO is no longer triggered. In order to comply with EN 60204, it must be ensured by taking external measures that the drive does not start without prior confirmation.

Without a mechanical brake, the drive might not stop immediately but coast to a standstill. If this may result in personal or material damage, additional safety measures must be taken.

If persons may be endangered after disconnection of the motor control by STO, access to the hazard areas must be prevented until the drive has stopped.

Check the safety function at regular intervals according to the results of your risk assessment. BONFIGLIOLI VECTRON recommends that the check is performed after one year, at the latest.

The STO function is one fault fail-safe. No single fault or component failure can cause a disabled drive to produce motor shaft torque. Only in extremely unlikely combinations of component faults the motor shaft could move jerky with sudden acceleration (maximum $180^\circ/\text{number of pole pairs}$, for example jerky movement of 90° for 4-pole motor, $180^\circ/2$) and produce torque. It must be checked if this behavior can cause a dangerous machine movement.

If the STO function is used, the special safety, installation and instructions on use instructions shall be complied with.



Comply with the Application manual „Safe Torque Off STO“, especially when the described safety relevant function is used.

**⚠ Warning! Dangerous voltage!**

The safety function "Safe Torque Off" may only be used if mechanical work is to be performed on the driven machines, not for work on live components.

After disconnection of an external DC 24 V power supply, the DC link of the frequency inverter is still connected to mains supply.

Even if power supply to the motor is disconnected, and the motor is coasting to a standstill or has already stopped, high voltages may still be present on the motor terminals.

Before working (e.g. maintenance) on live parts, the plant must always be disconnected from mains supply (main switch). This must be documented on the plant.


When the function "Safe Torque Off" is triggered, the motor is not isolated from the DC link of the frequency inverter. High voltage levels may be present at the motor.

Do not touch live terminals.

3 Scope of Supply

Thanks to the modular hardware components, the frequency inverters can be integrated in the automation concept easily. The scope of delivery described can be supplemented by optional components and adapted to the customer-specific requirements. The plug-in type connection terminals enable a safe function and quick and easy assembly.

3.1 ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)




Scope of Supply	
A	Frequency inverter
B	Terminal strip X1 (Phoenix ZEC 1,5/ST7,5) Plug-in terminals for mains connection and DC linking
C	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
D	Standard fixtures for vertical assembly
E	Brief Instructions and Operating Instructions on CD ROM
F	Terminal strip X2 (Phoenix ZEC 1,5/ST7,5) Plug-in terminal for brake resistor and motor connection
G	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

3.2 ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)




Scope of Supply	
A	Frequency inverter
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Standard fittings with fitting screws (M4x20, M4x60) for vertical assembly
D	Brief Instructions and Operating Instructions on CD ROM
E	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

3.3 ACU 401 (18.5 to 30.0 kW)

Scope of Supply




Scope of Supply

A	Frequency inverter
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Standard fittings with fitting screws (M4x20, M4x70) for vertical assembly
D	Brief Instructions and Operating Instructions on CD ROM
E	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

3.4 ACU 401 (37.0 to 65.0 kW)




Scope of Supply	
A	Frequency inverter
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Standard fittings with fitting screws (M5x20) for vertical assembly
D	Brief Instructions and Operating Instructions on CD ROM
E	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

3.5 ACU 401 (75.0 to 132.0 kW)

Scope of Supply



Scope of Supply

A	Frequency inverter
B	Terminal strip X10 (Phoenix ZEC 1.5/3ST5.0) Plug-in terminals for the relay output
C	Control terminals X210A / X210B (Wieland DST85 / RM3.5) Plug-in terminal for connection of the control signals
D	Brief Instructions and Operating Instructions on CD ROM



Please check incoming goods for quality, quantity and nature without delay. Obvious defects such as exterior damage of the packing and/or the unit must be notified to the sender within seven days for insurance reasons.

4 Technical Data

4.1 General technical data

CE conformity	The frequency inverters ACU meet the requirements of the low voltage directive 2006/95/EEC and EN 61800-5-1.
EMC directive	For proper installation of the frequency inverter in order to meet the requirements of EN 61800-3, please comply with the installation instructions in these operating instructions.
Interference immunity	The frequency inverters ACU meet the requirements of EN 61800-3 for use in industrial environments.
UL Approval	The frequency inverters marked with the UL label according to UL508c also meet the requirements of the CSA Standard C22.2-No. 14. UL approved are the device series ACU401 in sizes 1 to 7 and ACU201 devices in sizes 1 and 2.
Safety function	The function is described in the application manual "Safe Torque Off".
Ambient temperature	Operation: 0...55 °C; as from 40 °C power reduction has to be considered.
Environmental class	Operation: 3K3 (EN60721-3-3) Relative humidity 15...85 %, no water condensation.
Degree of protection	IP20 if covers and connection terminals are used properly.
Altitude of installation	Up to 1000 m at rated specifications. Up to 4000 m at reduced power.
Storage	Storage according to EN 50178. BONFIGLIOLI VECTRON recommends that the unit be connected to mains voltage for 60 minutes after one year, at the latest.
Overload capability	Continuous Operation: 100 % I_N Up to 150 % I_N for 60 s Up to 200 % I_N for 1 s The overload capability can be used once in a time cycle of 10 minutes.
Functions	Devices -01 , -03 Up to 200 % I_N for 60 s (0.25 & 0.37 kW): Up to 200 % I_N for 1 s <ul style="list-style-type: none"> – Control methods adjusted to motors and application (configuration). – Adjustable speed/torque control. – Various control functions for motor and frequency inverter. – Positioning absolute or relative to a reference point. – Search Run. – Special brake control and load detection for lifting gear. – S-ramps for jerk limitation during acceleration and deceleration. – Technology (PI) controller. – Parameterizable Master-Slave operation via system bus. – Error memory. – Simplified and extended control via PC (commissioning, parameterization, data set backup, diagnosis with Scope).
Parameterization	<ul style="list-style-type: none"> – Freely programmable digital inputs and outputs. – Various logic modules for linking and processing of signals. – Four separate data sets incl. motor parameter.

4.2 Technical Data – Control Electronic Equipment

Control terminal X210A			Control terminal X210B		
X210A.1	DC 20 V output ($I_{\max}=180$ mA) or DC 24 V $\pm 10\%$ input for external power supply		X210B.1	Digital input ¹⁾	
X210A.2	GND 20 V/ GND 24 V (ext.)		X210B.2	Digital input STOB (sec- ond shutdown path)	safety relevant
X210A.3	Digital input STOA (first shutdown path)	safety relevant	X210B.3	Digital output ¹⁾	
X210A.4	Digital inputs ¹⁾		X210B.4	Multifunction output ¹⁾ (voltage sig- nal, proportional act. frequency, factory settings)	
X210A.5			X210B.5	Supply voltage DC 10 V for refer- ence value potentiometer, ($I_{\max}=4$ mA)	
X210A.6			X210B.6	Multifunction input ¹⁾ (reference speed 0 ... +10 V, factory settings)	
X210A.7			X210B.7	Ground 10 V	

Relay output X10	
S3OUT.1	Inverted Error Signal ¹⁾

¹⁾ Control terminals are freely configurable.

- Control „Safe Torque Off “: Contacts on X210A.3 and X210B.2 open.
- Release of frequency inverter: Contacts on X210A.3 and X210B.2 closed.



By default, the different configurations occupy the control terminals with certain settings. These settings can be adjusted to the specific application, and various functions can be assigned freely to the control terminals. An overview of the settings is displayed at the last but one page of these operating instructions.

Technical data of control terminals
Digital inputs (X210A.3 ... X210B.2): Low Signal: DC 0...3 V, High Signal: DC 12...30 V, Input resistance: 2.3 k Ω , response time: 2 ms (STOA and STOB: 10 ms), PLC compatible, X210A.6 and X210A.7 additionally: Frequency signal: DC 0 V...30 V, 10 mA at DC 24 V, $f_{\max}=150$ kHz
Digital output (X210B.3): Low Signal: DC 0...3 V, High Signal: DC 12...30 V, maximum output current: 50 mA, PLC compatible
Relay output (X10): Change-over contact, response time approx. 40 ms, – make-contact AC 5 A / 240 V, DC 5 A (ohmic) / 24 V break-contact AC 3 A / 240 V, DC 1 A (ohmic) / 24 V
Multifunction output (X210B.4): analog signal: DC 19...28 V, maximum output current: 50 mA, pulse-width modulated ($f_{\text{PWM}}=116$ Hz), Digital signal: Low Signal: DC 0...3 V, High Signal: DC 12...30 V, output current: 50 mA, PLC compatible, Frequency signal: Output voltage: DC 0...24 V, maximum output current: 40 mA, maximum output frequency: 150 kHz
Multifunction input (X210B.6): analog signal: Input voltage: DC 0... 10 V ($R_i=70$ k Ω), input current: DC 0...20 mA ($R_i=500$ Ω), Digital signal: Low Signal: DC 0...3 V, High Signal: DC 12 V...30 V, response time: 4 ms, PLC compatible
Cable size: The signal terminals are suitable for the following cable sizes: with ferrule: 0.25...1.0 mm ² without ferrule: 0.14...1.5 mm ²

4.3 ACU 201 (0.25 to 1.1 kW, 230 V)

Type							
ACU 201			-01	-03	-05	-07	-09
Construction Size			1				
Output, motor side							
Recommended motor shaft power	P	kW	0.25	0.37	0.55	0.75	1.1
Output current	I	A	1.6	2.5	3.0	4.0	5.4 ⁵⁾
Long-term overload current (60 s)	I	A	3.2	5.0	4.5	6.0	7.3
Short-time overload current (1 s)	I	A	3.2	5.0	6.0	8.0	8.0
Output voltage	U	V	Maximum input voltage, three-phase				
Protection	-	-	Short circuit / earth fault proof				
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency				
Switching frequency	f	kHz	2, 4, 8, 12, 16				
Output, brake resistor							
Min. brake resistance	R	Ω	100	100	100	100	100
Recommended brake resistor (U _{dBc} = 385 V)	R	Ω	430	300	230	160	115
Input, mains side							
Mains current ³⁾ 3ph/PE 1ph/N/PE; 2ph/PE	I	A	1.6 2.9	2.5 4.5	3 5.4	4 7.2	5.5 ¹⁾ 9.5 ²⁾
Mains voltage	U	V	184 ... 264				
Mains frequency	f	Hz	45 ... 66				
Fuse 3ph 1ph/N; 2ph	I	A	6 6	6 10			10 16
UL type 250 VAC RK5, 3ph 1ph/N; 2ph	I	A	6 6	6 10			10 15
Mechanics							
Dimensions	HxWxD	mm	190 x 60 x 175				
Weight (approx.)	m	kg	1.2				
Degree of protection	-	-	IP20 (EN60529)				
Terminals	A	mm ²	0.2 ... 1.5				
Form of assembly	-	-	Vertical				
Ambient conditions							
Energy dissipation (2 kHz switching frequency)	P	W	32	38	43	53	73
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)				
Storage temperature	T _L	°C	-25 ... 55				
Transport temperature	T _T	°C	-25 ... 70				
Rel. air humidity	-	%	15 ... 85; not condensing				

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁶⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
0.25 kW	1.6 A	1.6 A	1.6 A	1.3 A	1.1 A
0.37 kW	2.5 A	2.5 A	2.5 A	2.1 A	1.7 A
0.55 kW	3.0 A	3.0 A	3.0 A	2.5 A	2.0 A
0.75 kW	4.0 A	4.0 A	4.0 A	3.4 A	2.7 A
1.1 kW	5.4 A ²⁾	5.4 A ^{2) 5)}	5.4 A ^{2) 5)}	4.5 A ^{2) 5)}	3.7 A ⁵⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ One- and two-phase connection requires a commutating choke.

³⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter "Electrical installation")

⁴⁾ Maximum output current = 9.5 A with single-phase and two-phase connection

⁵⁾ Reduction of switching frequency in thermal limit range

⁶⁾ Maximum current in continuous operation

⁷⁾ The device for single phase connection is not listed in the product catalogue and only available on request.

4.4 ACU 201 (1.5 to 3.0 kW, 230 V)

Type					
ACU 201			-11	-13	-15
Construction Size			2		
Output, motor side					
Recommended motor shaft power	P	kW	1.5	2.2	3.0 ⁴⁾
Output current	I	A	7.0	9.5	12.5 ⁴⁾ ⁵⁾
Long-term overload current (60 s)	I	A	10.5	14.3	16.2
Short-time overload current (1 s)	I	A	14.0	19.0	19.0
Output voltage	U	V	Maximum input voltage, three-phase		
Protection	-	-	Short circuit / earth fault proof		
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency		
Switching frequency	f	kHz	2, 4, 8, 12, 16		
Output, brake resistor					
Min. brake resistance	R	Ω	37	37	37
Recommended brake resistor (U _{dbc} = 385 V)	R	Ω	75	55	37
Input, mains side					
Mains current ³⁾ 3ph/PE 1ph/N/PE; 2ph/PE	I	A	7 13.2	9.5 16.5 ²⁾	10.5 ¹⁾ 16.5 ²⁾ ⁴⁾ ⁷⁾
Mains voltage	U	V	184 ... 264		
Mains frequency	f	Hz	45 ... 66		
Fuse 3ph 1ph/N; 2ph	I	A	10 16	16 20	16 20
UL type 250 VAC RK5, 3ph 1ph/N; 2ph	I	A	10 15	15 20	15 20
Mechanics					
Dimensions	HxWxD	mm	250 x 60 x 175		
Weight (approx.)	m	kg	1.6		
Degree of protection	-	-	IP20 (EN60529)		
Terminals	A	mm ²	0.2 ... 1.5		
Form of assembly	-	-	Vertical		
Ambient conditions					
Energy dissipation (2 kHz switching frequency)	P	W	84	115	170
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)		
Storage temperature	T _L	°C	-25 ... 55		
Transport temperature	T _T	°C	-25 ... 70		
Rel. air humidity	-	%	15 ... 85; not condensing		

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁶⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
1.5 kW	7.0 A	7.0 A	7.0 A	5.9 A	4.8 A
2.2 kW	9.5 A ²⁾	9.5 A ²⁾	9.5 A ²⁾	8.0 A ²⁾	6.5 A
3.0 kW ²⁾ ⁴⁾	12.5 A ¹⁾	12.5 A ¹⁾ ⁵⁾	12.5 A ¹⁾ ⁵⁾	10.5 A ¹⁾ ⁵⁾	8.5 A ⁵⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ One- and two-phase connection requires a commutating choke.

³⁾ Mains current with relative mains impedance ≥ 1% (see chapter „Electrical installation“)

⁴⁾ Maximum output current = 9.5 A with single-phase and two-phase connection

⁵⁾ Reduction of switching frequency in thermal limit range

⁶⁾ Maximum current in continuous operation

⁷⁾ The device for single phase connection is not listed in the product catalogue and only available on request.

4.5 ACU 201 (4.0 to 9.2 kW, 230 V)

Type						
ACU 201			-18	-19	-21	-22
Construction Size			3		4	
Output, motor side						
Recommended motor shaft power	P	kW	4.0	5.5 ⁴⁾	7.5 ⁴⁾	9.2 ⁴⁾
Output current	I	A	18.0	22.0	32.0	35.0
Long-term overload current (60 s)	I	A	26.3	30.3	44.5	51.5
Short-time overload current (1 s)	I	A	33.0	33.0	64.0	64.0
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8, 12, 16			
Output, brake resistor						
Min. brake resistance	R	Ω	24	24	12	12
Recommended brake resistor (U _{dB} = 385 V)	R	Ω	30	24	16	12
Input, mains side						
Mains current ³⁾ 3ph/PE 1ph/N/PE; 2ph/PE	I	A	18 28 ^{2) 7)}	20 ¹⁾ - ⁴⁾	28.2 ¹⁾ - ⁴⁾	35.6 ¹⁾ - ⁴⁾
Mains voltage	U	V	184 ... 264			
Mains frequency	f	Hz	45 ... 66			
Fuse 3ph 1ph/N; 2ph	I	A	25 35	25 - ⁴⁾	35 - ⁴⁾	50 - ⁴⁾
Mechanics						
Dimensions	HxWxD	mm	250 x 100 x 200		250 x 125 x 200	
Weight (approx.)	m	kg	3.0		3.7	
Degree of protection	-	-	IP20 (EN60529)			
Terminals	A	mm ²	0.2 ... 6		0.2 ... 16	
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	200	225	310	420
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			
Storage temperature	T _L	°C	-25 ... 55			
Transport temperature	T _T	°C	-25 ... 70			
Rel. air humidity	-	%	15 ... 85; not condensing			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁶⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
4.0 kW	18.0 A ²⁾	18.0 A ²⁾	18.0 A ²⁾	15.1 A ²⁾	12.2 A
5.5 kW ⁴⁾	23.0 A ¹⁾	22.7 A ^{1), 5)}	22.0 A ^{1), 5)}	18.5 A ⁵⁾	15.0 A ⁵⁾
7.5 kW ⁴⁾	32.0 A ¹⁾	32.0 A ¹⁾	32.0 A ¹⁾	26.9 A ¹⁾	21.8 A
9.2 kW ⁴⁾	40.0 A ¹⁾	38.3 A ^{1), 5)}	35.0 A ^{1), 5)}	29.4 A ^{1), 5)}	23.8 A ⁵⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ One- and two-phase connection requires a commutating choke.

³⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter „Electrical installation“)

⁴⁾ Three-phase connection permissible only.

⁵⁾ Reduction of switching frequency in thermal limit range

⁶⁾ Maximum current in continuous operation

⁷⁾ The device for single phase connection is not listed in the product catalogue and only available on request.

4.6 ACU 401 (0.25 to 1.5 kW, 400 V)

Type								
ACU 401			-01	-03	-05	-07	-09	-11
Construction Size			1					
Output, motor side								
Recommended motor shaft power	P	kW	0.25	0.37	0.55	0.75	1.1	1.5
Output current	I	A	1.0	1.6	1.8	2.4	3.2	3.8 ³⁾
Long-term overload current (60 s)	I	A	2.0	3.2	2.7	3.6	4.8	5.7
Short-time overload current (1 s)	I	A	2.0	3.2	3.6	4.8	6.4	7.6
Output voltage	U	V	Maximum input voltage, three-phase					
Protection	-	-	Short circuit / earth fault proof					
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency					
Switching frequency	f	kHz	2, 4, 8, 12, 16					
Output, brake resistor								
Min. brake resistance	R	Ω	300	300	300	300	300	300
Recommended brake resistor (U _{dBc} = 770 V)	R	Ω	930	930	930	634	462	300
Input, mains side								
Mains current ²⁾ 3ph/PE	I	A	1.0	1.6	1.8	2.4	2.8 ¹⁾	3.3 ¹⁾
Mains voltage	U	V	320 ... 528					
Mains frequency	f	Hz	45 ... 66					
Fuses	I	A	6					
UL type 600 VAC RK5	I	A	6					
Mechanics								
Dimensions	HxWxD	mm	190 x 60 x 175					
Weight (approx.)	m	kg	1.2					
Degree of protection	-	-	IP20 (EN60529)					
Terminals	A	mm ²	0.2 ... 1.5					
Form of assembly	-	-	vertical					
Ambient conditions								
Energy dissipation (2 kHz switching frequency)	P	W	30	35	40	46	58	68
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)					
Storage temperature	T _L	°C	-25 ... 55					
Transport temperature	T _T	°C	-25 ... 70					
Rel. air humidity	-	%	15 ... 85, not condensing					

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
0.25 kW	1.0 A	1.0 A	1.0 A	0.8 A	0.7 A
0.37 kW	1.6 A	1.6 A	1.6 A	1.3 A	1.1 A
0.55 kW	1.8 A	1.8 A	1.8 A	1.5 A	1.2 A
0.75 kW	2.4 A	2.4 A	2.4 A	2.0 A	1.6 A
1.1 kW	3.2 A ¹⁾	3.2 A ¹⁾	3.2 A ¹⁾	2.7 A ¹⁾	2.2 A
1.5 kW ¹⁾	3.8 A	3.8 A ³⁾	3.8 A ³⁾	3.2 A ³⁾	2.6 A ³⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter „Electrical installation“)

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

4.7 ACU 401 (1.85 to 4.0 kW, 400 V)

Type						
ACU 401			-12	-13	-15	-18
Construction Size			2			
Output, motor side						
Recommended motor shaft power	P	kW	1.85	2.2	3.0	4.0
Output current	I	A	4.2	5.8	7.8	9.0 ³⁾
Long-term overload current (60 s)	I	A	6.3	8.7	11.7	13.5
Short-time overload current (1 s)	I	A	8.4	11.6	15.6	18.0
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8, 12, 16			
Output, brake resistor						
Min. brake resistance	R	Ω	136	136	136	92
Recommended brake resistor (U _{dBc} = 770 V)	R	Ω	300	220	148	106
Input, mains side						
Mains current ²⁾ 3ph/PE	I	A	4.2	5.8	6.8 ¹⁾	7.8 ¹⁾
Mains voltage	U	V	320 ... 528			
Mains frequency	f	Hz	45 ... 66			
Fuses	I	A	6	10		
UL type 600 VAC RK5	I	A	6	10		
Mechanics						
Dimensions	HxWxD	mm	250 x 60 x 175			
Weight (approx.)	m	kg	1.6			
Degree of protection	-	-	IP20 (EN60529)			
Terminals	A	mm ²	0.2 ... 1.5			
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	68	87	115	130
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			
Storage temperature	T _L	°C	-25 ... 55			
Transport temperature	T _T	°C	-25 ... 70			
Rel. air humidity	-	%	15 ... 85, not condensing			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
1.85 kW	4.2 A	4.2 A	4.2 A	3.5 A	2.9 A
2.2 kW	5.8 A	5.8 A	5.8 A	4.9 A	3.9 A
3.0 kW	7.8 A ¹⁾	7.8 A ¹⁾	7.8 A ¹⁾	6.6 A ¹⁾	5.3 A
4.0 kW	9.0 A ¹⁾	9.0 A ^{1) 3)}	9.0 A ^{1) 3)}	7.6 A ^{1) 3)}	6.1 A ³⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter „Electrical installation“)

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

4.8 ACU 401 (5.5 to 15.0 kW, 400 V)

Type							
ACU 401			-19	-21	-22	-23	-25
Construction Size			3			4	
Output, motor side							
Recommended motor shaft power	P	kW	5.5	7.5	9.2	11.0	15.0
Output current	I	A	14.0	18.0	22.0 ³⁾	25.0	32.0
Long-term overload current (60 s)	I	A	21.0	26.3	30.3	37.5	44.5
Short-time overload current (1 s)	I	A	28.0	33.0	33.0	50.0	64.0
Output voltage	U	V	Maximum input voltage, three-phase				
Protection	-	-	Short circuit / earth fault proof				
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency				
Switching frequency	f	kHz	2, 4, 8, 12, 16				
Output, brake resistor							
Min. brake resistance	R	Ω	48	48	48	32	32
Recommended brake resistor (U _{dBC} = 770 V)	R	Ω	80	58	48	48	32
Input, mains side							
Mains current ²⁾ 3ph/PE	I	A	14.2	15.8 ¹⁾	20.0 ¹⁾	26.0	28.2 ¹⁾
Mains voltage	U	V	320 ... 528				
Mains frequency	f	Hz	45 ... 66				
Fuses	I	A	16	25		35	
UL type 600 VAC RK5	I	A	20			30	40
Mechanics							
Dimensions	HxWxD	mm	250 x 100 x 200			250 x 125 x 200	
Weight (approx.)	m	kg	3.0			3.7	
Degree of protection	-	-	IP20 (EN60529)				
Terminals	A	mm ²	0.2 ... 6			0.2 ... 16	
Form of assembly	-	-	vertical				
Ambient conditions							
Energy dissipation (2 kHz switching frequency)	P	W	145	200	225	240	310
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)				
Storage temperature	T _L	°C	-25 ... 55				
Transport temperature	T _T	°C	-25 ... 70				
Rel. air humidity	-	%	15 ... 85, not condensing				

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾					
Frequency inverter nominal power	Switching frequency				
	2 kHz	4 kHz	8 kHz	12 kHz	16 kHz
5.5 kW	14.0 A	14.0 A	14.0 A	11.8 A	9.5 A
7.5 kW	18.0 A ¹⁾	18.0 A ¹⁾	18.0 A ¹⁾	15.1 A ¹⁾	12.2 A
9.2 kW ¹⁾	23.0 A	22.7 A ³⁾	22.0 A ³⁾	18.5 A ³⁾	15.0 A ³⁾
11 kW	25.0 A	25.0 A	25.0 A	21.0 A	17.0 A
15 kW	32.0 A ¹⁾	32.0 A ¹⁾	32.0 A ¹⁾	26.9 A ¹⁾	21.8 A

¹⁾ Three-phased connection demands mains commutating choke

²⁾ Mains current with relative mains impedance ≥ 1% (see chapter „Electrical installation“)

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

4.9 ACU 401 (18.5 to 30.0 kW, 400 V)

Type					
ACU 401			-27	-29	-31
Construction Size			5		
Output, motor side					
Recommended motor shaft power	P	kW	18.5	22.0	30.0
Output current	I	A	40.0	45.0	60.0
Long-term overload current (60 s)	I	A	60.0	67.5	90.0
Short-time overload current (1 s)	I	A	80.0	90.0	120.0
Output voltage	U	V	Maximum input voltage, three-phase		
Protection	-	-	Short circuit / earth fault proof		
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency		
Switching frequency	f	kHz	2, 4, 8		
Output, brake resistor					
Min. brake resistance	R	Ω	16		
Recommended brake resistor (U _{dBC} = 770 V)	R	Ω	26	22	16
Input, mains side					
Mains current ²⁾ 3ph/PE	I	A	42.0	50.0	58.0 ¹⁾
Mains voltage	U	V	320 ... 528		
Mains frequency	f	Hz	45 ... 66		
Fuses	I	A	50	63	
UL type 600 VAC RK5	I	A	50	60	
Mechanics					
Dimensions	HxWxD	mm	250x200x260		
Weight (approx.)	m	kg	8		
Degree of protection	-	-	IP20 (EN60529)		
Terminals	A	mm ²	up to 25		
Form of assembly	-	-	vertical		
Ambient conditions					
Energy dissipation (2 kHz switching frequency)	P	W	445	535	605
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)		
Storage temperature	T _L	°C	-25 ... 55		
Transport temperature	T _T	°C	-25 ... 70		
Rel. air humidity	-	%	15 ... 85, not condensing		

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ³⁾			
Frequency inverter nominal power	Switching frequency		
	2 kHz	4 kHz	8 kHz
18.5 kW	40.0 A	40.0 A	40.0 A
22 kW	45.0 A	45.0 A	45.0 A
30 kW	60.0 A ¹⁾	60.0 A ¹⁾	60.0 A ¹⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter „Electrical installation“)

³⁾ Maximum current in continuous operation

4.10 ACU 401 (37.0 to 65.0 kW, 400 V)

Type						
ACU 401			-33	-35	-37	-39
Construction Size			6			
Output, motor side						
Recommended motor shaft power	P	kW	37.0	45.0	55.0	65.0
Output current	I	A	75.0	90.0	110.0	125.0
Long-term overload current (60 s)	I	A	112.5	135.0	165.0	187.5
Short-time overload current (1 s)	I	A	150.0	180.0	220.0	250.0
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8			
Output, brake resistor ⁵⁾						
Min. brake resistance	R	Ω	7.5			
Recommended brake resistor (U _{DBC} = 770 V)	R	Ω	13	11	9	7.5
Input, mains side						
Mains current ²⁾ 3ph/PE	I	A	87.0	104.0	105.0 ¹⁾	120.0 ¹⁾
Mains voltage	U	V	320 ... 528			
Mains frequency	f	Hz	45 ... 66			
Fuses	I	A	100	125	125	125
UL type 600 VAC RK5	I	A	100	125	125	125
Mechanics						
Dimensions	HxWxD	mm	400x275x260			
Weight (approx.)	m	kg	20			
Degree of protection	-	-	IP20 (EN60529)			
Terminals	A	mm ²	up to 70			
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	665	830	1080	1255
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			
Storage temperature	T _L	°C	-25 ... 55			
Transport temperature	T _T	°C	-25 ... 70			
Rel. air humidity	-	%	15 ... 85, not condensing			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾			
Frequency inverter nominal power	Switching frequency		
	2 kHz	4 kHz	8 kHz
37 kW	75.0 A	75.0 A	75.0 A
45 kW	90.0 A	90.0 A	90.0 A
55 kW	110.0 A ¹⁾	110.0 A ¹⁾	110.0 A ¹⁾
65 kW	125.0 A ^{1) 3)}	125.0 A ^{1) 3)}	125.0 A ^{1) 3)}

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter „Electrical installation“)

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

⁵⁾ Optional the frequency inverter of this size is purchasable without brake transistor.

4.11 ACU 401 (75.0 to 132.0 kW, 400 V)

Type						
ACU 401			-43	-45	-47	-49
Construction Size			7			
Output, motor side						
Recommended motor shaft power	P	kW	75	90	110	132
Output current	I	A	150	180	210	250
Long-term overload current (60 s)	I	A	225	270	315	332
Short-time overload current (1 s)	I	A	270	325	375	375
Output voltage	U	V	Maximum input voltage, three-phase			
Protection	-	-	Short circuit / earth fault proof			
Rotary field frequency	f	Hz	0 ... 1000, depending on switching frequency			
Switching frequency	f	kHz	2, 4, 8			
Output, brake resistor ⁵⁾						
Min. brake resistance	R	Ω	4.5		3.0	
Recommended brake resistor (U _{DBC} = 770 V)	R	Ω	6.1	5.1	4.1	3.8
Input, mains side						
Mains current ²⁾ 3ph/PE	I	A	143 ¹⁾	172 ¹⁾	208 ¹⁾	249 ¹⁾
Mains voltage	U	V	320 ... 528			
Mains frequency	f	Hz	45 ... 66			
Fuses 3ph	I	A	160	200	250	315
Fuses according to UL ⁶⁾ Cooper Bussmann	Type		FWH-250A	FWH-300A	FWH-350A	FWH-400A
Mechanics						
Dimensions	HxWxD	mm	510 x 412 x 351			
Weight (approx.)	m	kg	45			
Degree of protection	-	-	IP20 (EN60529)			
Terminals	A	mm ²	up to 2 x 95			
Form of assembly	-	-	vertical			
Ambient conditions						
Energy dissipation (2 kHz switching frequency)	P	W	1600	1900	2300	2800
Coolant temperature	T _n	°C	0 ... 40 (3K3 DIN IEC 721-3-3)			
Storage temperature	T _L	°C	-25 ... 55			
Transport temperature	T _T	°C	-25 ... 70			
Rel. air humidity	-	%	15 ... 85, not condensing			

If required by the customer, the switching frequency may be increased if the output current is reduced at the same time. Comply with the applicable standards and regulations for this operating point.

Output current ⁴⁾			
Frequency inverter nominal power	Switching frequency		
	2 kHz	4 kHz	8 kHz
75 kW	150 A	150 A	150 A
90 kW	180 A	180 A	180 A
110 kW	210 A	210 A	210 A ³⁾
132 kW	250 A	250 A	250 A ³⁾

¹⁾ Three-phase connection requires a commutating choke.

²⁾ Mains current with relative mains impedance $\geq 1\%$ (see chapter „Electrical installation“)

³⁾ Reduction of switching frequency in thermal limit range

⁴⁾ Maximum current in continuous operation

⁵⁾ Optional the frequency inverter of this size is purchasable without brake transistor.


⁶⁾ For the UL conform fuse protection the mentioned fuses of the company Cooper Bussmann must be used. Other fuses must not be used for the UL conform fuse protection.

4.12 Operation diagrams


The technical data of the frequency inverters refer to the nominal point which was selected to enable a wide range of applications. A functionally and efficient dimensioning (derating) of the frequency inverters is possible based on the following diagrams.

Installation height

Power reduction (Derating),
5%/1000 m above sea level,
 $h_{\max} = 4000$ m




max. coolant temperature,
3.3 °C/1000 m above sea level,




Coolant temperature

Power reduction (Derating)
2.5%/K upper 40 °C, $T_{\max} = 55$ °C



Mains voltage

Reduction of output current at constant output power (Derating)
0.22%/ V upper 400 V, $U_{\max} = 480$ V



5 Mechanical Installation

The frequency inverters of degree of protection IP20 are designed, as a standard, for installation in electrical cabinets.

- During installation, both the installation and the safety instructions as well as the device specifications must be complied with.



WARNING

To avoid serious physical injuries or major material damage, only qualified persons are allowed to work on the devices.



WARNING

During assembly, make sure that no foreign particles (e.g. chips, dust, wires, screws, tools) can get inside the frequency inverter. Otherwise there is the risk of short circuits and fire.

The frequency inverters comply with protection class IP20 only if the covers and terminals are mounted properly.

Overhead Installation or installation in horizontal position is not permissible.


NOTE

Mount the devices with sufficient clearance to other components so that the cooling air can circulate freely. Avoid soiling by grease and air pollution by dust, aggressive gases, etc.

5.1 ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings.

The following illustration shows the different mounting possibilities.




Assembly is affected by inserting the long side of the fixing plate in the heat sink and screwing it to the mounting plate.

The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Installation dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
201	0.25 kW ... 1.1 kW	190	60	178	210 ... 230	260	30	133
	1.5 kW ... 3.0 kW	250	60	178	270 ... 290	315	30	133
401	0.25 kW ... 1.5 kW	190	60	178	210 ... 230	260	30	133
	1.85 kW ... 4.0 kW	250	60	178	270 ... 290	315	30	133

5.2 ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the standard fitting.




Assembly is done by screwing the two fixing brackets to the heat sink of the frequency inverter and the assembly panel.

The frequency inverters are provided with fixing brackets, which are fitted using four thread-cutting screws. The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Installation dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
201	4.0 ... 5.5 kW	250	100	200	270 ... 290	315	12	133
	7.5 ... 9.2 kW	250	125	200	270 ... 290	315	17.5	133
401	5.5 ... 9.2 kW	250	100	200	270 ... 290	315	12	133
	11.0 ... 15.0 kW	250	125	200	270 ... 290	315	17.5	133

5.3 ACU 401 (18.5 to 30.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the standard fitting.




Assembly is done by screwing the two fixing brackets to the heat sink of the frequency inverter and the assembly panel.

The frequency inverters are provided with fixing brackets, which are fitted using four thread-cutting screws. The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]					Installation dimensions [mm]			
ACU		a	b	c	a1	a2	b1	c1
401	18.5...30.0 kW	250	200	260	270 ... 290	315	20	160

5.4 ACU 401 (37.0 to 65.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel by means of the standard fittings. The following illustration shows the standard fitting.




Assembly is done by screwing the two fixing brackets to the heat sink of the frequency inverter and the assembly panel.

The frequency inverters are provided with fixing brackets, which are fitted using four thread-cutting screws. The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]				Installation dimensions [mm]				
ACU		a	b	c	a1	a2	b1	c1
401	37...65 kW	400	275	260	425 ... 445	470	20	160

5.5 ACU 401 (75.0 to 132.0 kW)

The frequency inverter is mounted in a vertical position on the assembly panel. The following illustration shows the standard fitting.



The diameter of the fixing holes is 9 mm.

Assembly is done by screwing the back wall of the frequency inverter to the assembly panel.

The dimensions of the device and the installation dimensions are those of the standard device without optional components and are given in millimeters.

Dimensions [mm]				Installation dimensions in mm							
ACU	a	b	c	a1	b1	b2	b3	c1	c2	c3	
401 75...132 kW	510	412	351	480	392	382	342	338	305	110	

6 Electrical Installation



WARNING

The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

The documentation and device specification must be complied with during installation.

Before any assembly or connection work, discharge the frequency inverter. Verify that the frequency inverter is discharged.

Do not touch the terminals because the capacitors may still be charged.

Only connect suitable voltage sources. The nominal voltage of the frequency inverter must correspond to the supply voltage.

The frequency inverter must be connected to ground potential.

If voltage supply is switched on, no covers of the frequency inverter may be removed.

The connecting cables must be protected externally, considering the maximum voltage and current values of the fuses. The mains fuses and cable cross-sections are to be selected according to EN 60204-1 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter. According to UL/CSA, the frequency inverter is suitable for operation at a supply network of a maximum of 480 VAC which delivers a maximum symmetrical current of 5000 A (effective value) if protected by fuses of class RK5. Only use copper cables with a temperature range of 60/75 °C.

The frequency inverters are to be grounded properly, i.e. large connection area and with good conductivity. The leakage current of the frequency inverters may be > 3.5 mA. According to EN 50178 a permanent connection must be provided. The protective conductor cross-section required for grounding the fixing plate must be selected according to the size of the unit. In these applications, the cross-section must correspond to the recommended cross-section of the wire.



CAUTION

Degree of protection IP20 is only achieved with terminals plugged and properly mounted covers.

Connection conditions

- The frequency inverter is suited for connection to the public or industrial supply mains according to the technical data. If the transformer output of the supply mains is ≤ 500 kVA, a mains commutation choke is only necessary for the frequency inverters identified in the technical data. The other frequency inverters are suitable for connection without a mains commutating choke with a relative mains impedance $\geq 1\%$.
- It must be checked, based on the specifications of EN 61000-3-2, if the devices can be connected to the public supply means without taking additional measures. The frequency inverters ≤ 9.2 kW with integrated EMC filter comply with the emission limits of the product standard EN 61800-3 up to a motor cable length of 10 m, without additional measures being required. Increased requirements in connection with the specific application of the frequency inverter are to be met by means of optional components. Commutating chokes and EMC filters are optionally available for the series of devices.
- Operation on unearthed mains (IT mains) is admissible after disconnection of the Y capacitors in the interior of the device.


- Interference-free operation with residual current device is guaranteed at a tripping current ≥ 30 mA if the following points are observed:
 - one-phase power supply (L1/N): Pulse current and alternating current sensitive residual current devices (Type A to EN 50178)
 - two-phase power supply (L1/L2) or three-phase power supply (L1/L2/L3): All-current sensitive residual current devices (Type B to EN 50178)
 - Use EMC filters with reduced leakage current or, if possible, do not use EMC filters at all.
 - The length of the shielded motor cable is ≤ 10 m and there are no additional capacitive components between the mains or motor cables and PE.


6.1 EMC Information

The frequency inverters are designed according to the requirements and limit values of product norm EN 61800-3 with an interference immunity factor (EMI) for operation in industrial applications. Electromagnetic interference is to be avoided by expert installation and observation of the specific product information.

Measures

- Install the frequency inverters and commutating chokes on a metal mounting panel. Ideally, the mounting panel should be galvanized, not painted.
- Provide proper equipotential bonding within the system or the plant. Plant components such as control cabinets, control panels, machine frames, etc. must be connected by means of PE cables.
- The shield of the control cables is to be connected to ground potential properly, i.e. with good conductivity, on both sides (shield clamp). Mount shield clamps for cable shields close to the unit.
- Connect the frequency inverter, the commutating choke, external filters and other components to an earthing point via short cables.
- Keep the cables as short as possible, make sure that cables are installed properly using appropriate cable clamps, etc.
- Contactors, relays and solenoids in the electrical cabinet are to be provided with suitable interference suppression components.





A Mains Connection

The length of the mains supply cable is not limited. However, it must be installed separate from the control, data and motor cables.

B DC link connection

The frequency inverters are to be connected to the same mains potential or a common direct voltage source. Cables longer than 300 mm are to be shielded. The shield must be connected to the mounting panel on both sides.

C Control Connection

Keep control and signal cables physically separate from the power cables. Analog signal lines are to be connected to the shield potential on one side. Install sensor cables separate from motor cables.

D Motor and brake resistor

The shield of the motor cable is to be connected to ground potential properly on both sides. On the motor side use a metal compression gland. On the frequency inverter side an appropriate shield clamp is to be used. The signal cable used for monitoring the motor temperature must be kept separate from the motor cable. Connect the shield of this line on both sides. If a brake resistor is used, the connection cable must also be shielded, and the shield is to be connected to earth potential on both sides.

Line choke

Line chokes reduce mains harmonics and reactive power. Additionally the increase of product life is possible. Consider the reduction of the maximum output voltage if a line choke is installed.

The line choke must be installed between mains connection and input filter.

Input filter


Input filters reduce the conducted radio-frequency interference voltage. The input filter must be installed upstream on mains side of the frequency inverter.



CAUTION

The frequency inverters meet the requirements of the low-voltage directive 2006/95/EC and the requirements of the EMC directive 2004/108/EC. The EMC product standard EN 61800-3 relates to the drive system. The documentation provides information on how the applicable standards can be complied if the frequency inverter is a component of the drive system. The declaration of conformity is to be issued by the supplier of the drive system.

6.2 Block diagram



A Relay connection S3OUT

Change-over contact, response time approx. 40 ms,

- make-contact AC 5 A / 240 V, DC 5 A (ohmic) / 24 V
- break-contact AC 3 A / 240 V, DC 1 A (ohmic) / 24 V

B Voltage output/input

Bidirectional, DC 20 V voltage output ($I_{\max}=180$ mA) or input for external power supply DC 24 V $\pm 10\%$

C Digital input S1IND/STOA

Digital signal, STOA (1st shutdown path for safety function STO – „Safe Torque Off“), response time: approx. 10 ms (On), 10 μ s (Off), U_{\max} = DC 30 V, 10 mA at DC 24 V, PLC compatible

D Digital inputs S2IND ... S6IND

Digital signal: response time approx. 2 ms, U_{\max} = DC 30 V, 10 mA at 24 V, PLC compatible, frequency signal: DC 8...30 V, 10 mA at DC 24 V, f_{\max} = 150 kHz

E Digital input S7IND/STOB/STOB

Digital signal, STOB (2nd shutdown path for safety function STO – „Safe Torque Off“), response time: approx. 10 ms (On), 10 μ s (Off), U_{\max} = DC 30 V, 10 mA at DC 24 V, PLC compatible

F Digital output S1OUT

Digital signal, DC 24 V, I_{\max} = 50 mA, PLC compatible, overload and short-circuit proof

G Multi-Function Output MFO1

Analog signal: DC 24 V, I_{\max} = 50 mA, pulse-width modulated, f_{PWM} = 116 Hz,
 Digital signal: DC 24 V, I_{\max} = 50 mA, PLC compatible,
 Frequency signal: DC 0...24 V, I_{\max} = 40 mA, f_{\max} = 150 kHz,
 overload and short-circuit proof

H Multi-Function Input MFI1

Analog signal: resolution 12 Bit, 0...10 V (R_i = 70 k Ω), 0...20 mA (R_i = 500 Ω),
 Digital signal: response time approx. 4 ms, U_{\max} = DC 30 V, 4 mA at 24 V, PLC compatible

6.3 Optional Components

Thanks to the modular hardware components, the frequency inverters can be integrated in the automation concept easily. The standard and optional modules are recognized during the initialization, and the controller functionality is adjusted automatically. For the information required for installation and handling of the optional modules, refer to the corresponding documentation.

WARNING




The hardware modules at slots B and C may only be assembled and disassembled after the frequency inverter has been disconnected safely from power supply. Wait for some minutes until the DC link capacitors have discharged before starting the work.

The unit may only be connected with the power supply switched off.

Make sure that the frequency inverter is discharged.

Hardware modules



A Control Unit KP500

Connection of the optional control unit KP500 or an interface adapter KP232.

B Communication module CM

Plug-in section for connection to various communication protocols:

- CM-232: RS232 interface
- CM-485: RS485 interface
- CM-PDP: Profibus-DP interface
- CM-CAN: CANopen interface

C Expansion module EM

Slot for customer-specific adaptation of the control inputs and outputs to various applications:

- EM-ENC: extended speed sensor evaluation
- EM-RES: resolver evaluation
- EM-IO: analog and digital inputs and outputs
- EM-SYS: system bus
(system bus in combination with CM-CAN communication module upon request)

CAUTION



If two optional components with CAN-Protocol controller are installed, the system bus interface in the EM expansion module is deactivated!

6.4 Connection of Unit

6.4.1 Dimensioning of conductor cross-section

The cable dimensions should be selected according to the current load and voltage drop to be expected. Select the cable cross-section of the cables such that the voltage drop is as small as possible. If the voltage drop is too great, the motor will not reach its full torque. Also comply with any additional national and application-specific regulations and the separate UL instructions. For typical mains fuses, refer to chapter "Technical Data".

According to EN61800-5-1, the cross sections of the PE conductor shall be dimensioned as follows:

Mains cable	Protective conductor
Mains cable up to 10 mm ²	Install two protective conductors of the same size as the mains cable, or one protective conductor of a size of 10 mm ² .
Mains cable 10...16 mm ²	Install one protective conductor of the same size as the mains cable.
Mains cable 16...35 mm ²	Install one protective conductor of a size of 16 mm ²
Mains cable > 35 mm ²	Install one protective conductor of half the size of the mains cable.

6.4.1.1 Typical cross-sections

The following tables provide an overview of typical cable cross-sections (copper cable with PVC insulation, 30 °C ambient temperature, and continuous mains current max. 100% rated input current). Actual mains cable cross-section requirements may deviate from these values due to actual operating conditions.

230 V: One-phase (L/N) and two-phase (L1/L2) connection

201	Mains cable	PE-conductor	Motor cable
-01 -03 -05 -07 -09 <i>0.25 kW</i> <i>0.37 kW</i> <i>0.55 kW</i> <i>0.75 kW</i> <i>1.1 kW</i>	1.5 mm ²	2x1.5 mm ² or 1x10 mm ²	1.5 mm ²
-11 -13 -15 <i>1.5 kW</i> <i>2.2 kW</i> <i>3 kW</i>	2.5 mm ²	2x2.5 mm ² or 1x10 mm ²	1.5 mm ²
-18 <i>4 kW</i>	4 mm ²	2x4 mm ² or 1x10 mm ²	4 mm ²

230 V: Three-phase connection (L1/L2/L3)

	201	Mains cable	PE-conductor	Motor cable
-01	0.25 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ²	1.5 mm ²
-03	0.37 kW			
-05	0.55 kW			
-07	0.75 kW			
-09	1.1 kW			
-11	1.5 kW			
-13	2.2 kW	4 mm ²	2x4 mm ² or 1x10 mm ²	4 mm ²
-15	3 kW			
-18	4 kW	6 mm ²	2x6 mm ² or 1x10 mm ²	6 mm ²
-19	5.5 kW			
-21	7.5 kW	10 mm ²	1x10 mm ²	10 mm ²
-22	9.2 kW			

400V: Three-phase connection (L1/L2/L3)

	401	Mains cable	PE-conductor	Motor cable
-01	0.25 kW	1,5 mm ²	2x1,5 mm ² or 1x10 mm ²	1,5 mm ²
-03	0.37 kW			
-05	0.55 kW			
-07	0.75 kW			
-09	1,1 kW			
-11	1,5 kW			
-12	1,85 kW			
-13	2,2 kW			
-15	3 kW	2,5 mm ²	2x2,5 mm ² or 1x10 mm ²	2,5 mm ²
-18	4 kW			
-19	5,5 kW	4 mm ²	2x4 mm ² or 1x10 mm ²	4 mm ²
-21	7,5 kW			
-22	9,2 kW	6 mm ²	2x6 mm ² or 1x10 mm ²	6 mm ²
-23	11 kW			
-25	15 kW	10 mm ²	1x10 mm ²	10 mm ²
-27	18,5 kW			
-29	22 kW	16 mm ²	1x16 mm ²	16 mm ²
-31	30 kW			
-33	37 kW	35 mm ²	1x16 mm ²	25 mm ²
-35	45 kW	50 mm ²	1x25 mm ²	35 mm ²
-37	55 kW	50 mm ²	1x25 mm ²	50 mm ²
-39	65 kW	70 mm ²	1x35 mm ²	70 mm ²
-43	75 kW	70 mm ²	1x50 mm ²	95 mm ²
-45	90 kW	95 mm ²	1x70 mm ²	2x70 mm ²
-47	110 kW	2x70 mm ²	1x70 mm ²	2x70 mm ²
-49	132 kW	2x70 mm ²	1x70 mm ²	2x70 mm ²

6.4.2 Mains Connection



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

The mains fuses and cable cross-sections are to be selected according to EN 60204-1 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter. According to UL/CSA, approved Class 1 copper lines with a temperature range of 60/75°C and matching mains fuses are to be used for the power cables. The electrical installation is to be done according to the device specifications and the applicable standards and directives.



CAUTION

The control, mains and motor lines must be kept physically separate from one another.

The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.

6.4.3 Motor Connection



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

BONFIGLIOLI VECTRON recommends using shielded cables for the connection of the motor and the brake resistor to the frequency inverter. The shield is to be connected to PE potential properly, i.e. with good conductivity, on both sides. The control, mains and motor lines must be kept physically separate from one another. The user must comply with the applicable limits stipulated in the relevant national and international directives as regards the application, the length of the motor cable and the switching frequency.

6.4.3.1 Length of motor cables, without filter

Permissible length of motor cable without output filter		
Frequency inverter	unshielded cable	shielded cable
0.25 kW ... 1.5 kW	50 m	25 m
1.85 kW ... 4.0 kW	100 m	50 m
5.5 kW ... 9.2 kW	100 m	50 m
11.0 kW ... 15.0 kW	100 m	50 m
18.5 kW ... 30.0 kW	150 m	100 m
37.0 kW ... 65.0 kW	150 m	100 m
75.0 kW ... 132.0 kW	150 m	100 m

The specified lengths of the motor cables must not be exceeded if no output filter is installed.



The frequency inverters ≤ 9.2 kW with integrated EMC filter comply with the emission limits of the product standard EN 61800-3 up to a motor cable length of 10 m. The frequency inverters ≤ 9.2 kW with integrated EMC filter comply with the emission limits stipulated in EN 61800-3 if the motor cable is not longer than 20 m. Customer-specific requirements can be met by means of an optional filter.

6.4.3.2 Motor cable length, with output filter dU/dt

Longer motor cables can be used after taking appropriate technical measures, e.g. use of low-capacitance cables and output filters. The following table contains recommended values for the use of output filters.

Motor cable length with output filter		
Frequency inverter	unshielded cable	shielded cable
0.25 kW ... 1.5 kW	upon request	upon request
1.85 kW ... 4.0 kW	150 m	100 m
5.5 kW ... 9.2 kW	200 m	135 m
11.0 kW ... 15.0 kW	225 m	150 m
18.5 kW ... 30.0 kW	300 m	200 m
37.0 kW ... 65.0 kW	300 m	200 m
75.0 kW ... 132.0 kW	300 m	200 m

6.4.3.3 Motor cable length, with sinus filter

Motor cables can be much longer if sinus filters are used. By conversion in sinus-shaped currents, high-frequency portions which might limit the cable length are filtered out. Also consider the voltage drop across the cable length and the resulting voltage drop at the sinus filter. The voltage drop results in an increase of the output current. Check that the frequency inverter can deliver the higher output current. This must be considered in the projecting phase already.

If the motor cable length exceeds 300 m, please consult BONFIGLIOLI.

6.4.3.4 Group drive

In the case of a group drive (several motors at one frequency inverter), the total length shall be divided across the individual motors according to the value given in the table. Please note that group drive with synchronous servomotors is not possible.

Use a thermal monitoring element on each motor (e.g. PTC resistor) in order to avoid damage.

6.4.3.5 Speed sensor connection

Install sensor cables physically separate from motor cables. Comply with the sensor manufacturer's specifications.

Connect the shield close to the frequency inverter and limit the length to the necessary minimum.

6.4.4 Connection of a Brake Resistor

Install a brake resistor if feedback of generator energy is expected. Overvoltage shutdowns can be avoided by this.



⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.



⚠ WARNING

During operation, the surface of the brake resistor can reach high temperatures. The surface can keep high temperatures after operation for a certain time. Do not touch the brake resistor during operation or operational readiness of the frequency inverter. Non-compliance may result in skin burn.

Install a safeguard for protection against contact or fix warning labels.

Do not install the brake resistor in the proximity to flammable or heat-sensitive materials.

Do not cover the brake resistor.




⚠ CAUTION

Bonfiglioli Vectron recommends using a temperature switch. Depending on the selected resistor the temperature switch is integrated as a standard or optional available. The temperature switch disconnects the frequency inverter from mains supply if the brake resistor is overloaded.

Using Brake resistors without temperature switches can result in critical states.

Connection of a brake resistor is done via terminal **X2**.



Limit the length of the brake resistor cables to the necessary minimum.

6.5 Connection of types

6.5.1 ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)

The mains connection of the frequency inverter is via plug-in terminal **X1**. The connection of motor and brake resistor to the frequency inverter is done via plug-in terminal X2. Degree of protection IP20 (EN60529) is only guaranteed with the terminals plugged.



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.


Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.


Switch off power supply before connecting or disconnecting the keyed plug-in terminals **X1** and **X2**.

Mains connection ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)




- 1 With a mains current above 10 A, the mains power connection 230 V 1ph/N/PE and the mains power connection 230 V 2ph/N/PE are to be done on two terminals.

Motor connection ACU 201 (up to 3.0 kW) and 401 (up to 4.0 kW)




Phoenix ZEC 1,5/ .. ST7,5


	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16




Delta connection




Star connection



Connection of brake resistor with temperature switch



X2



Phoenix ZEC 1,5/ .. ST7,5

	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.2 ... 1.5 mm ² AWG 24 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16
	0.25 ... 1.5 mm ² AWG 22 ... 16

6.5.2 ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.



Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.


When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.


Mains connection ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)




ACTIVE Cube 201-18 (4.0 kW):



4.0 kW ... 9.2 kW
6qmm / RM7,5




11 kW ... 15 kW
16qmm / RM10+15



ACU 201-18 (4.0 kW): one- and three-phase connection possible

ACU 201-19 (5.5 kW) and higher: three-phase connection possible

Motor connection ACU 201 (4.0 to 9.2 kW) and 401 (5.5 to 15.0 kW)




4.0 kW ... 9.2 kW
6qmm / RM7,5

	0.2 ... 6 mm ² AWG 24 ... 10
	0.2 ... 6 mm ² AWG 24 ... 10
	0.25 ... 4 mm ² AWG 22 ... 12
	0.25 ... 4 mm ² AWG 22 ... 16

11.0 kW ... 15.0 kW
16qmm / RM10+15

	0.2 ... 16 mm ² AWG 24 ... 6
	0.2 ... 16 mm ² AWG 24 ... 6
	0.25 ... 10 mm ² AWG 22 ... 8
	0.25 ... 10 mm ² AWG 22 ... 8

Connection of brake resistor with temperature switch



4.0 kW ... 9.2 kW
6qmm / RM7,5

	0.2 ... 6 mm ² AWG 24 ... 10
	0.2 ... 6 mm ² AWG 24 ... 10
	0.25 ... 4 mm ² AWG 22 ... 12
	0.25 ... 4 mm ² AWG 22 ... 16

11.0 kW ... 15.0 kW
16qmm / RM10+15

	0.2 ... 16 mm ² AWG 24 ... 6
	0.2 ... 16 mm ² AWG 24 ... 6
	0.25 ... 10 mm ² AWG 22 ... 8
	0.25 ... 10 mm ² AWG 22 ... 8

6.5.3 ACU 401 (18.5 to 30.0 kW)



⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.


Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.


Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.

- The unit may only be connected with the power supply switched off.
- Make sure that the frequency inverter is discharged.

Mains connection ACU 401 (18.5 to 30.0 kW)




X1







3ph / 400V AC


2.5 Nm
22.1 lb-in




18.5 kW ... 30.0 kW
PHOENIX MKDSP 25/ 6-15,00-F

	0.5 ... 35 mm ² AWG 20 ... 2
	0.5 ... 25 mm ² AWG 20 ... 4
	1.00 ... 25 mm ² AWG 18 ... 4
	1.5 ... 25 mm ² AWG 16 ... 4

Motor connection ACU 401 (18.5 to 30.0 kW)



Connection of brake resistor with temperature switch



6.5.4 ACU 401 (37.0 to 65.0 kW)



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.




Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.


Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.

Mains connection ACU 401 (37.0 to 65.0 kW)




37.0 kW ... 65.0 kW
threaded bolt M8x25
wire cross section up to 70 mm²

Motor connection ACU 401 (37.0 to 65.0 kW)



Connection of brake resistor with temperature switch



Optional, the inverters in this size can be purchased without brake chopper and are then not provided with the terminal Rb2 for a brake resistor connection.

6.5.5 ACU 401 (75.0 to 132.0 kW)



DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.


Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.


Switch off power supply before connecting or disconnecting the mains cable to/from terminal **X1**, the motor cables and the brake resistor to/from terminal **X2**.

Mains connection ACU 401 (75.0 to 132 kW)




Threaded bolt M8x20

Motor connection ACU 401 (75.0 to 132 kW)



Threaded bolt M8x20

Connection of brake resistor with temperature switch



Threaded bolt M8x20



Optional, the inverters in this size can be purchased without brake chopper and are then not provided with the terminal Rb2 for a brake resistor connection.

6.6 Control Terminals

The control and software functionality can be configured as required to ensure a reliable and economical operation. The operating instructions describe the factory settings of the standard connections in the relevant *Configuration 30* as well as the software parameters to be set up.

CAUTION




The unit may only be connected with the power supply switched off.


Verify that the frequency inverter is discharged.


Switch off power supply before connecting or disconnecting the control inputs and outputs. Verify that the keyed control inputs and outputs are deenergized before connecting or disconnecting them. Otherwise, components may be damaged.


Control Terminals




Wieland DST85 / RM3,5

 0.14 ... 1.5 mm²
AWG 30 ... 16

 0.14 ... 1.5 mm²
AWG 30 ... 16

 0.25 ... 1.0 mm²
AWG 22 ... 18

 0.25 ... 0.75 mm²
AWG 22 ... 20

0.2 ... 0.3 Nm
1.8 ... 2.7 lb-in

Control terminal X210A	
Ter.	Description
1	- Voltage output 20 V, $I_{\max}=180$ mA ¹⁾ or - input for external power supply DC 24 V $\pm 10\%$
2	GND 20 V and GND 24 V (ext.)
3	Digital signal, STOA (1st shutdown path for safety function STO – „Safe Torque Off “), $U_{\max}=\text{DC } 30$ V, 10 mA at DC 24 V, input resistance: 2.3 k Ω , PLC compatible, response time approx. 10 ms
4	Digital input S2IND, $U_{\max}=30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, response time approx. 2 ms
5	Digital input S3IND, $U_{\max}=30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, response time approx. 2 ms
6	Digital input S4IND, $U_{\max}=30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, frequency signal: 0...30 V, 10 mA at 24 V, $f_{\max} = 150$ kHz
7	Digital input S5IND, $U_{\max}=30$ V, 10 mA at DC 24 V, Input resistance: 2.3 k Ω , PLC compatible, frequency signal: 0...30 V, 10 mA at 24 V, $f_{\max} = 150$ kHz
Control terminal X210B	
Ter.	Description
1	Digital input S6IND, $U_{\max}=30$ V, 10 mA at 24 V, input resistance: 2.3 k Ω , PLC compatible, response time approx. 2 ms
2	Digital input STOB (2nd shutdown path for function "Safe Torque Off “), $U_{\max}=30$ V, 10 mA at 24 V, input resistance: 2.3 k Ω , PLC-compatible, response time approx. 10 ms
3	Digital output S1OUT, $U=24$ V, $I_{\max}=50$ mA, overload and short-circuit proof
4	Multi-function output MFO1, analog signal: $U=24$ V, $I_{\max}=50$ mA, pulse-width modulated, $f_{\text{PWM}}=116$ Hz Digital signal: $U=24$ V, $I_{\max}=50$ mA, overload and short-circuit proof frequency signal: 0...24 V, $I_{\max}=50$ mA, $f_{\max}=150$ kHz
5	Reference output 10 V, $I_{\max}=4$ mA
6	Multi-Function Input MFI1, Analog signal: resolution 12 Bit, 0...+10 V ($R_i = 70$ k Ω), 0...20 mA ($R_i= 500$ Ω), Digital signal: response time approx. 4 ms, $U_{\max} = 30$ V, 4 mA at 24 V, PLC compatible
7	Ground / GND 10 V

- ¹⁾ The power output on terminal X210A.1 may be loaded with a maximum current of $I_{\max} = 180$ mA. The maximum current available is reduced by the digital output S1OUT and multifunctional output MFO1.

	Level:
Digital inputs (X210A.3 ... X210B.2)	Low: 0 V ... 3 V, High: 12 V ... 30 V
Digital output (X210B.3)	

6.6.1 External DC 24 V power supply

The bidirectional control terminals X210A.1/ X210A.2 can be used as a voltage output or voltage input. By connecting an external power supply of DC 24 V $\pm 10\%$ to terminals X210A.1/X210A.2, the function of inputs and outputs as well as the communication can be maintained.

Requirements to be met by external power supply	
Input voltage range	DC 24 V $\pm 10\%$
Rated input current	Max. 1.0 A (typical 0.45 A)
Peak inrush current	Typical: < 20 A
External fuse	Via standard fuse elements for rated current, characteristic: slow
Safety	Safety extra low voltage (SELV) according to EN 61800-5-1

NOTE

The digital inputs and the DC 24 V terminal of the electronic control equipment can withstand external voltage up to DC 30 V. Higher voltages may destroy the unit.



Use suitable external power supply units with a maximum output current of DC 30 V or use appropriate fuses to protect the unit.



Comply with the application manual "Safe Torque Off – STO", especially if you apply this safety-related function.

6.6.2 Relay Output

By default, the freely programmable relay output is linked to the monitoring function (factory setting). The logic link to various functions can be freely configured via the software parameters. Connection of the relay output is not absolutely necessary for the function of the frequency inverter.

Relay Output	
	<p>X10</p>  <p>Phoenix ZEC 1,5/3ST5,0</p> <ul style="list-style-type: none"> 0.2 ... 1.5 mm² AWG 24 ... 16 0.2 ... 1.5 mm² AWG 24 ... 16 0.25 ... 1.5 mm² AWG 22 ... 16 0.25 ... 1.5 mm² AWG 22 ... 16

Control terminal X10	
Ter.	Description
1 ... 3	Relay output, floating change-over contact, response time approx. 40 ms, maximum contact load: <ul style="list-style-type: none"> – make contact: AC 5 A / 240 V, DC 5 A (ohmic) / 24 V – break-contact: AC 3 A / 240 V, DC 1 A (ohmic) / 24 V

6.6.3 Motor Thermo-Contact

The ACU frequency inverters can evaluate the thermal switch of motor. By default, terminal X210B.1 (S6IND) is configured as an input for this evaluation. Connect the thermal switch to the digital input and the DC 24 V supply unit X210A.1. For configuration, refer to sections 13.6 "Motor Temperature" and 15.4.5 "Thermo contact".

6.6.4 Control terminals – Connection diagrams of configurations

The control hardware and the software of the frequency inverter are freely configurable to a great extent. Certain functions can be assigned to the control terminals, and the internal logic of the software modules can be freely selected.

Thanks to the modular design, the frequency inverter can be adapted to a great range of different driving tasks.

The demands made of the control hardware and software are well known in the case of standard driving tasks. This control terminal logic and internal function assignments of the software modules are available in standard configurations. These assignments can be selected via parameter *Configuration 30*. The configurations are described in the following section.



The ACU units of the ACTIVE Cube series feature the function STO („Safe Torque Off“). If this function is not required, the "Controller release" signal must be connected to inputs S1IND/STOA and S7IND/STOB.

Inputs S1IND/STOA and S7IND/STOB are connected in series.



WARNING

If the same signal is used for the digital inputs S1IND/STOA and S2IND, safe disconnection of power supply to the motor according to safety function STO („Safe Torque Off ") is not guaranteed.

6.7 Configurations overview

Refer to following table in order to learn which combinations of functions and control methods are possible. Configurations „Standard“, „Technology Controller“ and „Torque Control“ will be described in the following sections. For configurations „Electronic Gear“, „Positioning“ and „Brake Control“, please refer to the corresponding application manuals.

Configurations:

Function	V/f	Sensorless vector	Speed controlled	Servo	Sensor-less Servo
Standard	110	410	210	510	610
Technology Controller	111	411	211		611
Electronic gear with position controller ¹⁾	115	415	215	515	
Electronic gear + index controller ¹⁾	116		216	516	
Torque control		430	230	530	630
Positioning ²⁾		440	240	540	640
Brake control ³⁾	160	460	260	560	

Please also comply with the following manuals:

- 1) Application Manual: Electronic Gear, Position Control and Index Control
- 2) Application Manual: Positioning
- 3) Application Manual: Lifting Gear Drives and Load Estimation


Note: The control methods 2xx can be used with **HTL** sensors (with or without reference track) connected to the basic device or to an expansion module.
The control methods 2xx with **TTL** sensors require an expansion module.
An expansion module EM-RES for evaluation of resolver signals is required for operation of a synchronous machine (control method 5xx).



The control methods 2xx can be used with **HTL** sensors (with or without reference track) connected to the basic device or to an expansion module.
The control methods 2xx with **TTL** sensors require an expansion module.
An expansion module EM-RES for evaluation of resolver signals is required for operation of a synchronous machine (control method 5xx).
An expansion module EM-ABS is required for evaluation of Absolute encoders (Hiperface, EnDat2.1, SSI).

6.7.1 Configuration 110 – Sensorless Control

Configuration 110 contains the functions for variable-speed control of a 3-phase machine in a wide range of standard applications. The motor speed is set according to the selected ratio of the reference frequency to the necessary voltage.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V for reference value potentiometer
X210B.6	Reference speed 0 ... +10 V
X210B.7	Ground 10 V

6.7.2 Configuration 111 – Sensorless Control with Technology Controller

Configuration 111 extends the functionality of the sensorless control by software functions for easier adaptation to the customer's requirements in different applications. The Technology Controller enables flow rate, pressure, level or speed control.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Fixed percentage value change-over 1
X210A.5	Fixed percentage value change-over 2
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V
X210B.6	Actual percentage value 0 ... +10 V
X210B.7	Ground 10 V

6.7.3 Configuration 410 – Sensorless Field-Oriented Control

Configuration 410 contains the functions for sensorless, field-oriented control of a 3-phase machine. The current motor speed is determined from the present currents and voltages in combination with the machine parameters. Separate control of torque and flux-forming current enables a high drive dynamics at a high load moment.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V for reference value potentiometer
X210B.6	Reference speed 0 ... +10 V
X210B.7	Ground 10 V

6.7.4 Configuration 411 – Sensorless Field-Oriented Control with Technology Controller

Configuration 411 extends the functionality of the sensorless field-oriented control of Configuration 410 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Fixed percentage value change-over 1
X210A.5	no function assigned
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V
X210B.6	Actual percentage value 0 ... +10 V
X210B.7	Ground 10 V

6.7.5 Configuration 430 – Sensorless FOC, Speed and Torque Controlled

Configuration 430 extends the functionality of the sensorless field-oriented control of Configuration 410 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ... +10 V or reference torque as percentage value
X210B.7	Ground 10 V

6.7.6 Configuration 210 – Field-Oriented Control, Speed Controlled




The control methods 2xx can be used with **HTL** sensors (with or without reference track) connected to the basic device or to an expansion module.

The control methods 2xx with **TTL** sensors require an expansion module.

An expansion module EM-ABS is required for evaluation of Absolute encoders (Hiperface, EnDat2.1, SSI).

Configuration 210 contains the functions for speed-controlled, field-oriented control of a 3-phase machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Speed sensor track B
X210A.7	Speed sensor track A

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V for reference value potentiometer
X210B.6	Reference speed 0 ... +10V
X210B.7	Ground 10 V

6.7.7 Configuration 211 – Field-Oriented Control with Technology Controller

Configuration 211 extends the functionality of the speed-controlled, field-oriented control of Configuration 210 by a Technology Controller. This enables a control based on parameters such as flow rate, pressure, filling level or speed.




Control terminal X210A	
X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Fixed percentage value change-over 1
X210A.5	no function assigned
X210A.6	Speed sensor track B
X210A.7	Speed sensor track A

Control terminal X210B	
X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V
X210B.6	Actual percentage value 0 ... +10 V
X210B.7	Ground 10 V

6.7.8 Configuration 230 – Field-Orientated Control, Speed and Torque Controlled

Configuration 230 extends the functionality of Configuration 210 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A	
X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Speed sensor track B
X210A.7	Speed sensor track A

Control terminal X210B	
X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ... +10 V or reference torque as percentage value
X210B.7	Ground 10 V

6.7.9 Configuration 510 – FOC of Synchronous Machine, Speed Controlled




An expansion module EM-RES for evaluation of resolver signals is required for operation of a synchronous machine (control method 5xx).

An expansion module EM-ABS is required for evaluation of Absolute encoders (Hiperface, EnDat2.1, SSI).

Comply with the operating instructions for the expansion module for the connection of the resolver or absolute encoder.

Configuration 510 contains the functions for speed-controlled, field-oriented control of a synchronous machine with resolver feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The necessary resolver feedback results in a precise speed and torque performance.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V for reference value potentiometer
X210B.6	Reference speed 0 ... +10V
X210B.7	Ground 10 V

6.7.10 Configuration 530 – FOC of a Synchronous Machine, Speed and Torque Controlled

Configuration 530 extends the functionality of Configuration 510 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ... +10 V or reference torque as percentage value
X210B.7	Ground 10 V

6.7.11 Configuration 610 – Sensorless FOC of Synchronous Machine, Speed Controlled

Configuration 610 contains the functions for speed-controlled, field-oriented control of a synchronous machine without resolver feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The missing resolver feedback compared to configuration 510 results in a small loss of dynamic and speed performance.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	Start of anticlockwise operation
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V for reference value potentiometer
X210B.6	Reference speed 0 ...+10 V
X210B.7	Ground 10 V

6.7.12 Configuration 611 – Sensorless FOC of a Synchronous Machine with Technology Controller

Configuration 611 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Control terminal X210A


X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Fixed percentage value change-over 1
X210A.5	no function assigned
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10V
X210B.6	Actual percentage value 0 ... +10 V
X210B.7	Ground 10 V

6.7.13 Configuration 630 – Sensorless FOC of a Synchronous Machine, Speed and Torque Controlled

Configuration 630 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.



Control terminal X210A

X210A.1	Voltage output +20 V or input for external power supply DC 24 V $\pm 10\%$
X210A.2	GND 20 V/ GND 24 V (ext.)
X210A.3	Digital input STOA (1st shutdown path of safety function STO)
X210A.4	Start of clockwise operation
X210A.5	n-/M change-over control function
X210A.6	Data set change-over 1
X210A.7	Data set change-over 2

Control terminal X210B

X210B.1	Motor thermal contact
X210B.2	Digital input STOB (2 nd shutdown path of safety function STO)
X210B.3	Run Signal
X210B.4	Analog signal of actual frequency
X210B.5	Supply voltage +10 V for reference value potentiometer
X210B.6	Reference speed 0 ...+10 V or reference torque as percentage value
X210B.7	Ground 10 V

6.8 Installation notes according to UL508c

The thermal motor protection according to UL508c can be realized in devices that are marked with "TM included" below the nameplate. For devices without the mark "TM included" note according to UL508c: Motor overtemperature sensing is not provided by the drive.

The connection and the parameter settings for the temperature motor supervision is described in chapter 13.6 "Motor Temperature", 15.4.5 "Thermo contact" and 18.5 "Motor Protection".

For an installation according to UL508c only allowed fuses can be used for mains protection. The allowed fuses are described in chapter 4 "Technical Data".

For an installation according to UL508c the in chapter 4 "Technical Data" described maximum temperatures must not be exceeded.


For an installation according to UL508c only 60/75°C copper conductors are allowed to be used.

For an installation according to UL508c the devices are only allowed to be used in environments according to Pollution Degree 2.

According to UL508c Warn- or Marking labels are not allowed to be removed.

7 Control Unit KP500


The optional KP500 control unit is a practical tool for controlling the frequency inverter and setting and displaying the frequency inverter parameters. The control unit is not absolutely necessary for the operation of the frequency inverter and can be plugged on when required.



Keys		
A	RUN	Used for starting the drive and opening the CTRL menu. Press the RUN key to open the motor potentiometer function.
	STOP	Used for opening the CTRL menu, stopping the drive and acknowledging faults.
J	▲ ▼	Used for navigating in the menu structure and selecting parameters. Increasing/decreasing of parameter values.
	ENT	Used for opening parameters or switching to another menu within the menu structure. Confirmation of the selected function or the set parameter.
	ESC	Used for aborting parameters or switching back to the previous menu within the menu structure. Canceling the function or resetting the parameter value.
	FUN	Used for switching over the key function, access to special functions.
Display		
B	Three-digit 7-segment display to show the parameter number.	
C	One-digit 7-segment display for display of the active data record, direction of rotation etc.	
D	Display of the selected menu branch:	
	VAL	Display actual values.
	PARA	Select parameters and adjust parameter values.
	CTRL	Select a function for adjustment and/or display via the operating unit: SETUP guided commissioning. Ctrl motor potentiometer and jog function.
	CPY	Copy parameters via the control unit: ALL All the parameter values are copied. Act Active parameter values are copied only. For Control unit memory is formatted and deleted.
E	Status and operating messages:	
	WARN	Warning about a critical operating behavior.
	FAULT	Message indicating that the unit was switched off due to a fault.
	RUN	Flashing: signals readiness for operation. Lights up: signals that the unit is operating and the output stage is enabled.
	REM	Active remote control via interface connection.
F	F	Function switch-over with the FUN key.
	Five-digit 7-segment display for display of parameter value and sign.	
	Physical unit of the parameter value displayed.	
	Active acceleration or deceleration ramp.	
	Current direction of rotation of the drive.	

7.1 Menu Structure


The menu structure of the control unit is arranged as shown in the following illustration. Use the arrow keys as well as ESC and ENT to navigate through the menu. The software contains the full set of information and enables a flexible use of the parameter setting and control options.



7.2 Main Menu

The various parameters and information of the frequency inverter can be displayed by means of the control unit. The different functions and parameters are grouped together in four menu branches. From any point in the menu structure you can return to the main menu by pressing the ESC key either continuously or repeatedly.

Note: In the following description of the key functions, a plus (+) between the key symbols indicates that the keys have to be pressed at the same time. A comma (,) between the key symbols indicates that the keys have to be pressed one after the other.



Menu branch VAL

Display of actual values

Menu branch PARA

Display and edit parameters

Menu branch CPY

Copy parameters

Menu branch CTRL

Select control and test functions

Use the arrow keys to select the required menu branch. The selected menu branch is displayed (flashing).


Select the menu branch by pressing the ENT key. The first parameter or the first function in the selected menu branch will be displayed.

If you press the ESC key you will return to the main menu of the control unit.

Keys	
▲ ▼	Navigate through the menu structure and select a menu branch.
ENT	Open the selected menu branch.
ESC	Cancel the current menu branch and return to the main menu.

7.4 Parameter Menu (PARA)

The parameters to be configured during the guided commissioning procedure were selected from common applications and can be supplemented as required by further settings in the PARA menu branch. The parameters and basic software functions linked to the corresponding actual value are documented in the operating instructions.



A

Use the arrow keys to select the required number from the parameters displayed in numerical order. The parameter number is displayed with the active data set (flashes).

If the highest parameter number is achieved, actuating the ▲-key displays the lowest parameter number.

If the lowest parameter number is achieved, actuating the ▼-key displays the highest parameter number.

Parameter numbers > 999 are displayed hexadecimal at the leading digit (999, A00 ... B5 ... C66).

In the current data set, the related parameters are displayed, including the corresponding data set number. The seven-segment display shows data set 0 if the parameter values in the four data sets are identical.

Keys	
▲ + ▼	Change to the last parameter edited.
FUN , ▲	Display of last parameter (highest number).
FUN , ▼	Display of first parameter (lowest number).

B	<p>Use the ENT key to select the parameter. The parameter is displayed including its value, unit and the active data set. If settings are edited in data set 0, the parameter values are changed in the four data sets.</p>
----------	---

C

Use the arrow keys to adjust the parameter value or to select an operation mode. The adjustment possibilities you have depend on the parameter. Keep the arrow keys pressed for a while to change the displayed values quickly. If you release the keys again, the speed at which the values change is reduced again. If the parameter value starts to flash, the speed at which the values change is reset to the initial value again.

Keys

▲ + ▼

Set parameter to factory setting.

FUN , ▲

Set parameter to highest value.

FUN , ▼

Set parameter to smallest value.

FUN , ENT

Change of the data set in the case of data set related parameters.

D

Use the ENT key to save the parameter. For a short time, the message SET including the parameter number and the data set is displayed. To leave the parameter unchanged, press the ESC key.	
Messages	
Err1: EEPrO	Parameter has not been saved.
Err2: StOP	Parameter can only be read (i.e. not edited) when the unit is in operation.
Err3: Error	Other error.

E	<p>After saving the parameter, you can edit the value again or return to the parameter selection menu by pressing the ESC key.</p>
----------	--

7.5 Copy Menu (CPY)

With the copy function of the control unit you can copy parameter values from the frequency inverter to a non-volatile memory of the control unit (upload) and store (download) them to a frequency inverter again.

The copy function makes the parameterization of recurring applications much easier. The function archives all parameter values, regardless of access control and value range. The memory space available in the control unit for the files is dynamically scaled to match the scope of the data.



The Copy Menu (CPY) is accessible in control level 3. The control level can be adjusted, if necessary, via parameter *Control Level* **28**.

7.5.1 Reading the Stored Information

When you open the CPY menu branch, the data stored in the control unit are read out. This process takes a few seconds. During this time, **init** and a progress indicator are displayed. After the initialization in the copy menu, the function can be selected.

If the information stored in the control unit is not valid, the initialization is stopped and an error message is displayed.

In this case, the memory in the control unit must be formatted as follows:





- Use the ENT key to confirm the error message.
- Use the arrow keys to select the function **For**.
- Use the ENT key to confirm the selection.

During the formatting process, **FCOPY** and a progress indicator are displayed.

The process takes a few seconds. When the process is complete, the message **rdY** is displayed.

- Confirm the message by pressing the ENT key.

Now, you can select the copy function as described in the following.




7.5.2 Menu Structure

The copy menu CPY contains three main functions. Use the arrow keys to select the required function. Select the source and the destination for the process. The memory space available in the non-volatile memory of the control unit is displayed on the three-digit seven-segment display as a percentage value.

Function – FOr


Use the function For to format and delete the memory in the control unit. This may be necessary if a new control unit is used for the first time.



Function – ALL

All readable and writable parameter values are transferred.

- Confirm this selection by pressing the ENT key and continue by selecting the source.




Function – Act

The active parameter values of the frequency inverter are copied to the control unit only. The number of active parameter values depends in the current or selected configuration of the frequency inverter.

When copying the data from the control unit to the frequency inverter, all stored parameter values are transmitted, like in the case of the ALL function.

- Confirm the selection **Act** by pressing the ENT key and continue by selecting the source.



7.5.3 Selecting the Source

The parameters of the ALL and Act sub-function in the CPY menu branch can be parameterized to meet the requirements of the specific application. The available memory space of the control unit is shown on the seven-segment display.

- Use the arrow keys to select the data source (Src.) for the copy operation (upload). The data sets of the frequency inverter (Src. x) or the files of the control unit (Src. Fy) can be used as the data source.
- Confirm the data source selected by pressing the ENT key and continue by selecting the target.

Display	Description
Src. 0	The data of the four data sets of the frequency inverter are copied.
Src. 1	The data of data set 1 of the frequency inverter are copied.
Src. 2	The data of data set 2 of the frequency inverter are copied.
Src. 3	The data of data set 3 of the frequency inverter are copied.
Src. 4	The data of data set 4 of the frequency inverter are copied.
Src. E	An empty data set for deletion of a file in the control unit.
Src. F1	File 1 is transferred from the memory of the control unit. ¹⁾
Src. F2	File 2 is transferred from the memory of the control unit. ¹⁾
Src. F3	File 3 is transferred from the memory of the control unit. ¹⁾
Src. F4	File 4 is transferred from the memory of the control unit. ¹⁾
Src. F5	File 5 is transferred from the memory of the control unit. ¹⁾
Src. F6	File 6 is transferred from the memory of the control unit. ¹⁾
Src. F7	File 7 is transferred from the memory of the control unit. ¹⁾
Src. F8	File 8 is transferred from the memory of the control unit. ¹⁾

¹⁾ Empty files not yet filled with data will not be offered as signal source. The memory of the control unit is managed dynamically (Chapter 7.5 "Copy Menu (CPY)").

7.5.4 Selecting the Destination

Select the destination (dSt.) of the copy operation (application-specific). The data source is transferred to the selected target (download).

- Use the arrow keys to select the destination (dSt.) of the copied data (download). Depending on the data source selected, either the data sets of the frequency inverter (dSt. x) or still empty files of the control unit (dSt. F y) are available as the target.
- Confirm your selection by pressing the ENT key. The copy operation will start and **COPY** will be displayed.

Display	Description
dSt. 0	The four data sets of the frequency inverter are overwritten.
dSt. 1	The data are copied to data set 1 of the frequency inverter.
dSt. 2	The data are copied to data set 2 of the frequency inverter.
dSt. 3	The data are copied to data set 3 of the frequency inverter.
dSt. 4	The data are copied to data set 4 of the frequency inverter.
dSt. F1	The data are copied to file 1 of the control unit. ¹⁾
dSt. F2	The data are copied to file 2 of the control unit. ¹⁾
dSt. F3	The data are copied to file 3 of the control unit. ¹⁾
dSt. F4	The data are copied to file 4 of the control unit. ¹⁾
dSt. F5	The data are copied to file 5 of the control unit. ¹⁾
dSt. F6	The data are copied to file 6 of the control unit. ¹⁾
dSt. F7	The data are copied to file 7 of the control unit. ¹⁾
dSt. F8	The data are copied to file 8 of the control unit. ¹⁾

¹⁾ Already existing files will not be offered as copy target.

7.5.5 Copy Operation




Before the parameter settings are transferred to the frequency inverter, the individual parameter values are checked.

The value range and the parameter settings can differ according to the power range of the frequency inverter. Parameter values which are outside of the value range will trigger a copy error message. If through the changing of parameters via copying a device fault is triggered, this device fault is displayed after the copying of the parameters is finished.


While the copy operation is in process, the message **COPY** and, as a progress indicator, the number of the currently copied parameter will be displayed.

In the case of the Act function, the active parameter values are copied only. Using the ALL function, parameters which are not relevant to the selected configuration are copied, too.




Depending on the configuration selected (ALL or Act), the copy operation will be completed after approx. 100 seconds and the message **rdY** will be displayed.

Press the ENT key to switch to the copy menu. Use the ESC key to switch to the target selection menu.




If the ESC key is pressed during the copy operation, the copy operation is aborted before the transmission of the data is complete. The message **Ab** and the number of the last parameter which was copied are displayed.

Press the ENT key to return to the selection in the copy menu. Use the ESC key to switch to the target selection menu.




7.5.6 Error Messages

The copy function archives all parameters, regardless of the access control and the value range. Some of the parameters are only writable if the frequency inverter is not in operation. The controller enable input (S1IND/STOA, S7IND/STOB) may not be activated during the copy operation, otherwise the data transmission is aborted. The message **StO** and the number of the last parameter which was copied are displayed. If the controller enable input is deactivated again, the aborted copy operation is continued.



The data transmission from the selected source to the destination is continuously monitored by the copy function. If an error occurs, the copy operation is aborted and the message **Err** and an error code are displayed.



Error Messages		
Code		Meaning
0	1	Write error in memory of control unit; repeat the copy operation. If error message is displayed again, format the memory.
	2	Read error in memory of control unit; repeat the copy operation. If error message is displayed again, format the memory.
	3	The size of the memory of the control unit was not determined correctly. If this error occurs repeatedly, replace the control unit.
	4	Not enough memory; the data are incomplete. Delete the incomplete file and data no longer needed from the control unit.
	5	The communication has been disturbed or interrupted; repeat the copy function, delete the incomplete file if necessary.
1	0	Invalid identification of a file in the operating unit; delete faulty file and format memory if necessary.
	2	The memory space of the selected target file is occupied; delete file or use different target file in the operating unit.
	3	The source file to be read in the control unit is empty; only files containing reasonable data should be selected as a source.
	4	Defective file in the control unit; delete defective file and format memory if necessary.
2	0	The memory in the control unit is not formatted; format the memory via the FOr function in the copy menu.
3	0	Error during reading of a parameter from the frequency inverter; check connection between the control unit and the frequency inverter and repeat reading operation.
	1	Error during writing of a parameter in the frequency inverter; Check connection between the control unit and the frequency inverter and repeat the writing operation.
	2	Unknown parameter type; delete faulty file and format memory if necessary.
4	0	The communication has been disturbed or interrupted; repeat the copy function, delete the incomplete file if necessary.

7.6 Reading Data from Control Unit

"Parameter transmission" enables the transmission of parameter values from the control unit KP 500 to the frequency inverter. In this operation mode, all other functions of the control unit are disabled, except for the COPY function. Transmission from the frequency inverter to the control unit is also disabled.

Activation of the control unit KP 500 for parameter transfer is prepared via parameter *Program(ming)* **34**. The control unit KP 500 must be connected to the frequency inverter.

<i>Program(ming)</i> 34	Function
111 - Parameter transmission	Control unit P 500 is prepared for parameter transmission. A connected frequency inverter can receive data from the control unit.
110 - Standard operation	Resetting of control unit KP 500 to standard operation mode.



Parameter transmission mode can be activated on the control unit KP 500 only if at least 1 file is stored in the control unit. Otherwise, the error message "**FOA10**" will be displayed as soon as activation is attempted.

7.6.1 Activation

The control unit KP 500 can be configured both via the keys of the KP 500 and via any available CM communication module. For configuration and activation of the KP 500 control unit, proceed as follows:

Activation via keyboard of control unit

- In the parameter menu PARA, use the arrow keys to select parameter *Program(ming)* **34**, and confirm your selection by pressing the ENT key.
- Use the arrow keys to set value **111** – Parameter transmission and confirm your selection by pressing the ENT key.
Now the control unit is ready for activation.

Before data transmission, the control unit must be initialized:

- Unplug the control unit from the frequency inverter and connect again to the same or another frequency inverter.
The initialization is started. During the time of initialization, **init** and a progress indicator are displayed. After initialization, the control unit KP 500 is ready for transfer of data to the frequency inverter.



Adjustment of parameter *Program(ming)* **34** to the value - Parameter transmission, can be undone via the control unit, provided that the control unit has not been initialized yet.

- In parameter *Program(ming)* **34**, use the arrow keys to set the value **110** – Normal operation again and confirm by pressing the ENT key.

Activation via communication module CM



Activation of the control unit through a communication connection is possible only if the frequency inverter is fitted with an optional communication module CM, and communication takes place via this module. The control unit must be connected to the frequency inverter.

- Establish connection to frequency inverter.
- Start communication and select parameter *Program(ming)* **34** via the communication interface.
- Via the communication interface enter value 111 in parameter *Program(ming)* **34** and confirm this value.
- Via the communication interface enter value 123 in parameter *Program(ming)* **34** and confirm this value.
The frequency inverter is re-initialized. The display of the control unit reads "rE-SEt". After that, the unit is initialized.

7.6.2 Data transfer

In order to transmit a file from the control unit to the frequency inverter, proceed as follows:

- Connect control unit KP 500 to the frequency inverter.
After initialization, the data sources available for transmission are displayed.
- Use the arrow keys to select the data source (Src. Fy) for the transmission to the frequency inverter.
The files stored in the control unit are available as data sources.



The files stored in the control unit contain all information and parameters stored according to the selected copy function ALL or Act (see Chapter "Copy Menu") in the control unit.

- Confirm your selection by pressing the ENT key.
The copy process is started. While the copy operation is in process, **COPY** and, as a progress indicator the number of the currently processed parameter will be displayed.

As soon as the copy operation is complete, the control unit will be re-initialized.

7.6.3 Resetting to Normal Operation

A control unit KP 500 activated for parameter transmission can be reset to full functionality (standard operation) via a specific key code on the control unit or via each available communication module CM.

Resetting on control unit

- Press RUN and STOP keys on control unit simultaneously for approx. 1 second. When the process is complete, — — — — — is displayed briefly. Then the top menu level of the control unit is available.
- In the parameter menu PARA, use the arrow keys to select parameter *Program(ming)* **34**, and confirm your selection by pressing the ENT key.
- Use the arrow keys to set value **110** – Normal operation and confirm your selection by pressing the ENT key.
The control unit is set to normal operation.

Resetting via communication module CM and/or using control software VPlus



Resetting of the control unit through a communication connection is possible only if the frequency inverter is fitted with an optional communication module CM, and communication takes place via this module.

- Establish connection to frequency inverter.
- Start communication and select parameter *Program(ming)* **34** via the communication connection.
- Via the communication connection, enter value 110 in parameter *Program(ming)* **34** and confirm this value.
- Via the communication connection enter value 123 in parameter *Program(ming)* **34** and confirm this value by pressing Enter.
The frequency inverter is reset. The display of the control unit reads "rESEt".
After resetting, the control unit is available again with full functionality.

7.7 Control Menu (CTRL)



In order to be able to control the drive via the control unit, the digital inputs S1IND/STOA and S7IND/STOB must be connected for enabling the output.



⚠ CAUTION

The unit may only be connected with the power supply switched off.
Verify that the frequency inverter is discharged.
Switch off power supply before connecting or disconnecting the control inputs and outputs. Verify that the keyed control inputs and outputs are deenergized before connecting or disconnecting them. Otherwise, components may be damaged.

In the CTRL menu branch, various functions are available which make commissioning easier and enable the control of the inverter via the control unit.

The frequency inverters can be controlled by means of the control unit and/or a communication module.

If you want to control the frequency inverter via an optional communication module, the necessary adjustments can be made via parameter *Local/Remote* **412**. Via this parameter, you can specify which functions will be available to the controller. Depending on the operation mode selected, only some of the control menu functions are available. Refer to chapter 18.3 "Bus controller" for a detailed description of parameter *Local/Remote* **412**.

7.8 Controlling the Motor via the Control Unit

The control unit enables controlling the connected motor in accordance with the selected operation mode of parameter *Local/Remote* **412**.




In order to be able to control the drive via the control unit, the digital inputs S1IND/STOA and S7IND/STOB must be connected for enabling the output.

CAUTION

The unit may only be connected with the power supply switched off.

Verify that the frequency inverter is discharged.

Switch off power supply before connecting or disconnecting the control inputs and outputs. Verify that the keyed control inputs and outputs are deenergized before connecting or disconnecting them. Otherwise, components may be damaged.







UU: When the RUN key was pressed, the drive was in operation already.

The CTRL menu branch can be accessed via the navigation within the menu structure. The Ctrl function contains sub-functions which are displayed according to the operating point of the frequency inverter.

Pressing the RUN key leads to a direct change from anywhere within the menu structure to the motorpoti function **PotF** for clockwise rotation or **Potr** for anticlockwise rotation.


If the drive is already running, the display reads **intF** (forward, clockwise) / **intr** (reverse, anticlockwise) for the function internal reference value or **inPF** (forward, clockwise) / **inPr** (reverse, anticlockwise) for the function „Motorpoti (KP)“.

The function „Motorpoti (KP)“ enables linking to other reference sources in the reference frequency channel. The function is described in chapter „Reference values, Motorpoti (KP)“.




Motor potentiometer function **Pot**

Using the arrow keys, you can adjust the output frequency of the frequency inverter from the *minimum frequency 418* to the *maximum frequency 419*. The acceleration corresponds to the factory setting (2 Hz/s) for the parameter *Ramp Keypad-Motorpoti 473*. The parameters *Acceleration (clockwise) 420* and *Deceleration (clockwise) 421* are taken into account with lower acceleration figures.




Internal reference value **int**

The drive is in operation, i.e. output signals are present at the frequency inverter and the current actual value is displayed. Press an arrow key to switch to the motor potentiometer function **Pot**. The current frequency value is taken over in the motor potentiometer function **Pot**.




Function Motorpoti (KP) **inP**

Using the arrow keys, you can adjust the output frequency of the frequency inverter from *Minimum frequency 418* to *Maximum frequency 419*. The frequency value adjusted via the control unit can be linked to other reference values via the *Reference frequency source 475* (Chapter „Reference frequency source“ and „Motorpoti (KP)“).



JOG frequency **JOG**

This function is useful for manual setup and positioning of a machine. The frequency of the output signal is set to the entered value if the FUN key is pressed.



- Press FUN key to switch from the internal reference value **int** or the motor potentiometer function **Pot** to parameter *JOG frequency 489*.
- While keeping the FUN key pressed, press the arrow keys to adjust the required frequency.
- (The frequency value last adjusted is saved as the *JOG frequency 489*.)
- Release the FUN key to stop the drive.
- (The display returns to the previous function **Pot** or **int**. or **inP** if function „Motorpoti (KP)“ is activated).

Key functions	
ENT	Reversal of the sense of rotation independent of the control signal on the terminals Clockwise S2IND or Anticlockwise S3IND.
ESC	Cancel function and return to the menu structure.
FUN	Switch from internal set point int or motor potentiometer function Pot to JOG frequency; the drive starts. Release the key to switch to the sub-function and stop the drive.
RUN	Start drive; alternative to control signal S2IND or S3IND.
STOP	Stop drive; alternative to control signal S2IND or S3IND.



CAUTION

If you press the ENT key, the **sense of rotation is changed** independent of the signal on the terminals Clockwise S2IND or Anticlockwise S3IND.
If the *minimum frequency 418* has been set to 0.00 Hz, the **sense of rotation** of the motor changes as soon as the sign of the reference frequency value changes.

8 Commissioning of the Frequency Inverter

8.1 Switching on Mains Voltage

After completion of the installation work, make sure to check all control and power connections again before switching on the mains voltage. If all electrical connections are correct, make sure that the frequency inverter is not enabled (control inputs S1IND/STOA and S7IND/STOB open). After power-up, the frequency inverter carries out a self-test and the relay output (X10) reports "Fault".

After a few seconds, the self-test is complete, the relay (X10) picks up and signals "no fault".

If the unit is in "as-delivered" condition or after resetting the unit to the factory settings, the guided commissioning procedure is started automatically. On the control unit, the "SetUP" menu from the menu branch CTRL is displayed.

8.2 Setup Using the Control Unit

The guided commissioning of the frequency inverter determines all parameter settings relevant to the required application. The available parameters were selected based on known standard drive applications. This facilitates the selection of the important parameters. After successful completion of the SETUP routine, the actual value *Actual frequency* **241** from the VAL menu branch is displayed on the control unit. Now, the user should check whether further parameters are relevant for the application.



The guided commissioning contains the function for parameter identification. The parameters are determined by way of measurement and set accordingly. You must carry out the guided commissioning procedure with cool machine because part of the machine data depends on the operating temperature.



WARNING

For control of a synchronous machine and successful setting of parameter *Configuration* **30** to "510 - FOR syn. speed control", the guided commissioning must be stopped after the message "SEtUP" by pressing the ESC key in order to set parameter *Offset* **382** first. To do this, proceed according to the operating instructions for the expansion module EM-RES installed. Otherwise, personal or machine damage may occur.


When the unit is in "as-delivered" condition, the guided commissioning procedure is started automatically. After successful commissioning, the guided commissioning can be carried out again later via the sub-menu CTRL, and the function can be called again.

- Use the ENT key to switch to the CTRL sub-menu.
- In the CTRL sub-menu, select the menu item "SEtUP" and confirm by pressing the ENT key.
- Use the ENT key to select parameter *Configuration* **30**.

The available configurations are displayed automatically depending on the selected *Control level* **28**.

- Use the arrow keys to enter the number of the required configuration. (for a description of the configurations, refer to the following chapter)

If the setup was changed, the hardware and software functionality will be configured. The message "SEtUP" is displayed again. Confirm this message by pressing the ENT key in order to continue the commissioning procedure.




- Switch to the next parameter.
- After initialization, confirm the selected configuration by pressing the ENT key.
- Continue the guided commissioning procedure according to the following chapters.

8.2.1 Configuration


Parameter *Configuration 30* determines the assignment and basic function of the control inputs and outputs as well as the software functions. The software of the frequency inverter offers several configuration options. These differ with respect to the way in which the drive is controlled. Analog and digital inputs can be combined and complemented by optional communication protocols as further reference value sources. The operating instructions describe the configurations and the relevant parameters in the third *Control level 28* (adjustment of parameter *Control level 28* to value 3). Please also comply with the following manuals:

Manual	Configuration
Application Manual – Electronic Gear	(x15, x16)
Application Manual – Positioning	(x40)
Application Manual – Hoisting Gear Drives	(x60)




Configuration 110, sensorless control

Configuration 110 contains the functions for variable-speed control of a 3-phase machine in a wide range of standard applications. The motor speed is set according to the V/f characteristic in accordance with the voltage/frequency ratio.




Configuration 111, sensorless control with technology controller

Configuration 111 extends the functionality of the sensorless control by software functions for easier adaptation to the customer's requirements in different applications. The Technology Controller enables flow rate, pressure, level or speed control.




Configuration 410, sensorless field-oriented control

Configuration 410 contains functions for sensorless, field-oriented control of a 3-phase machine. The current motor speed is determined from the present currents and voltages in combination with the machine parameters. In this configuration, parallel connection of several 3-phase motors is possible to a limited extent only.




Configuration 411, sensorless field-oriented control with technology controller

Configuration 411 extends the functionality of Configuration 410 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.




Configuration 430, sensorless field-oriented control with speed/torque control

Configuration 430 extends the functionality of Configuration 410 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. The switch-over between variable-speed control is done without jerk in operation.




Configuration 210, field-oriented control

Configuration 210 contains the functions for speed-controlled, field-oriented control of a 3-phase machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.




Configuration 211, field-oriented control with technology controller

Configuration 211 extends the functionality of Configuration 210 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.




Configuration 230, field-oriented control with speed/torque control

Configuration 230 extends the functionality of Configuration 210 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. The switch-over between variable-speed control and torque-dependent control is done without jerk in operation.




Configuration 510, field-oriented control of synchronous machine, speed-controlled

Configuration 510 contains the functions for speed-controlled, field-oriented control of a synchronous machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.




Configuration 530, field-oriented control of synchronous machine with speed/torque control

Configuration 530 extends the functionality of Configuration 510 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. The switch-over between variable-speed control and torque-dependent control is done without jerk in operation.




Configuration 610, Sensorless Field-Oriented Control of Synchronous Machine, Speed Controlled

Configuration 610 contains the functions for speed-controlled, field-oriented control of a synchronous machine without resolver feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The missing resolver feedback compared to configuration 510 results in a small loss of dynamic and speed performance.



Configuration 611, Sensorless Field-Orientated Control of a Synchronous Machine with Technology Controller


Configuration 611 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.



Configuration 630, Sensorless Field-Orientated Control of a Synchronous Machine, Speed and Torque Controlled

Configuration 630 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

8.2.2 Data Set




The data set change-over function enables the selection of one of four data sets for storing parameter settings.

If data set 0 is selected (factory setting), the parameter values saved in data set 0 are copied to data sets 1 through 4. In this way, all values determined during the guided commissioning procedure are saved in all data sets. In the factory settings, the frequency inverter uses data set 1 as the active data set. (For information on data set change-over via logic signals, refer to the chapter "Data Set Change-Over"). For example, if data set 2 is selected for guided commissioning ("SETUP"), all values which were determined or entered are saved in this data set. In this case, the other data sets still contain the factory settings. For the operation of the frequency inverter, data set 2 must be selected as the active data set in this case.

Data Set Setup	
dS	Function
0	All data sets (DS0)
1	Data set 1 (DS1)
2	Data set 2 (DS2)
3	Data set 3 (DS3)
4	Data set 4 (DS4)

8.2.3 Motor Type



The properties of the control functions and methods to be set vary depending on the motor which is connected. The parameter *Motor type* **369** offers a range of motor variants with the corresponding values. The verification of the entered rated values and the guided commissioning are carried out on the basis of the parameterized motor type. The selection of motor types varies according to the applications of the different control methods. In operating instructions the functionality and operating performance are described for 3-phase motors.

<i>Motor type</i> 369	Function
0 - Unknown	The motor is not a standard type.
1 - Asynchronous	Three-phase asynchronous motor, squirrel cage.
2 - Synchronous	Three-phase synchronous motor.
3 - Reluctance	Three-phase reluctance motor.
10 - Transformer ¹⁾	Transformer with three primary windings.

¹⁾ For setting of parameter *Motor type* **369** to operation mode „10 - Transformer“, no parameter identification is performed.


NOTE

Polling and setting of parameter values depends on the operation mode selected for parameter *Motor type* **369**.

If the motor type is not entered correctly, the drive may be damaged.

When the motor type is specified, the machine data must be entered. This is described in the following chapter. The data are polled in accordance with the table below.

8.2.4 Machine Data



The machine data to be entered during the guided commissioning procedure are indicated on the type plate or the data sheet of the motor. The factory settings of the machine parameters are based on the nominal data of the frequency inverter and the corresponding four-pole three-phase motor. The entered and calculated machine data are checked for plausibility during the guided commissioning procedure. The user should verify the factory-set rated data of the three-phase motor.

U_{FUN} , I_{FUN} , P_{FUN} are rated values of the frequency inverter.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
370	Rated voltage	$0.17 \cdot U_{FUN}$	$2 \cdot U_{FUN}$	U_{FUN}
371	Rated current	$0.01 \cdot I_{FUN}$	$10 \cdot I_{FUN}$	I_{FUN}
372	Rated speed	96 min^{-1}	60.000 min^{-1}	n_N
374	Rated cosine Phi	0.01	1.00	$\cos(\varphi)_N$
375	Rated frequency	10.00 Hz	1000.00 Hz	50.00
376	Rated mechanical power	$0.01 \cdot P_{FUN}$	$10 \cdot P_{FUN}$	P_{FUN}

- Use the arrow keys to select the required parameter and edit the parameter value.
- Use the ENT key to confirm the selected parameter and the parameter values entered.




The rated data of the motor are to be entered according to the specifications on the rating plate for the motor connection type used (star or delta connection).

If the data entered deviate from the rating plate, the parameters will not be identified correctly. Parameterize the rated data according to the rating plate of the motor for the wiring of the motor winding. Consider the increased rated current of the connected three-phase motor.

Example: BONFIGLIOLI BN 90LA Motor

Parameter		Star	Delta
370	Rated voltage	400 V	230 V
371	Rated current	3.7 A	6.4 A
372	Rated speed	1410 min^{-1}	1410 min^{-1}
374	Rated cosine Phi	0.77	0.77
375	Rated frequency	50 Hz	50 Hz
376	Rated mechanical power	1.5 kW	1.5 kW

8.2.5 Plausibility check



After the machine data (and the speed sensor data, if applicable) have been entered, the calculation or examination of the parameters is started automatically. The display changes over to "CALC" for a short time. If the verification of the machine data is successful, the guided commissioning procedure continues with the identification of the parameters.


Verification of the machine data should only be skipped by experienced users. The configurations contain complex control processes which depend to a large degree on the correctness of the machine parameters entered.

The warning and error messages displayed during the verification process have to be observed. If a critical condition is detected during the guided commissioning, it is displayed by the control unit. Depending on the deviation from the expected parameter value, either a warning or an error message is displayed.

- To ignore the warning or error messages, press the ENT key. The guided commissioning is continued. However, it is recommended that the data be checked and corrected if necessary.
- To correct the entered parameter values after the warning or error message, press the ESC key. Use the arrow keys to switch to the parameter value which is to be corrected.

If an error message is displayed, the rated values must be checked and corrected. The guided commissioning procedure is repeated until the rated values have been entered correctly. Aborting the guided commissioning procedure by pressing ESC key should only be done by expert users because it may be possible that rated values have not been entered or determined correctly.

8.2.6 Parameter identification



In addition to the parameterized rated data, the selected configuration demands knowledge of further machine data not stated on the rating plate of the three-phase machine. In addition to entering the rated motor parameters or as an alternative, the required machine data can also be measured during the guided commissioning process. The machine data are measured while the drive is at a standstill. The measured values are entered in the parameter automatically either directly or after the calculation. The procedure and the duration of the parameter identification depend on the type of machine connected and the device.


After checking the machine data entered, the guided commissioning switches to the parameter identification.

Confirm the display "PAIdE" by pressing the ENT key.

During the parameter identification, the connected load is measured.



For the setting of parameter *Motor type* **369** to operation mode „10 - Transformer“, no parameter identification is affected.



The safety functions of the frequency inverter avoid enabling of the power unit if no signal is present at digital input S1IND/STOA (terminal X210A.3) and S7IND/STOB (terminal X210B.2). If signals were already applied at the beginning of the guided commissioning, the "StO" message is not displayed.



In order to be able to control the drive via the control unit, the digital inputs S1IND/STOA (terminal X210A.3) and S7IND/STOB (terminal X210B.2) must be connected for enabling the output.



WARNING

The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

The documentation and device specification must be complied with during installation.


Before any assembly or connection work, discharge the frequency inverter. Verify that the frequency inverter is discharged.

Do not touch the terminals because the capacitors may still be charged.

Only connect suitable voltage sources. The nominal voltage of the frequency inverter must correspond to the supply voltage.

The frequency inverter must be connected to ground potential.

If voltage supply is switched on, no covers of the frequency inverter may be removed.



Confirm the final "rEAdY" message by pressing the ENT key.

Canceling the operation with the ESC key or withdrawing the enable signal S1IND/STOA and S7IND/STOB results in an incomplete take-over of the values.



You must carry out the guided commissioning procedure with cool machine because part of the machine data depends on the operating temperature.

After completion of the parameter identification, warning messages may be displayed.

Depending on the warning message code, the following instructions should be followed and the measures indicated should be taken.

8.2.7 Status messages during commissioning (SS...)

The following status messages are possible during commissioning (setup):

Status message		Meaning
SS000	OK	Auto setup routine has been carried out.
SS001	PC Phase 1	The plausibility check (PC) of the motor data is active.
SS002	PC Phase 2	The calculation of dependent parameters is active.
SS003	STO	The parameter identification demands enable on digital input STOA and STOB.
SS004	Parameter identification	The rated motor values are checked by the parameter identification feature.
SS010	Setup already active	The setup routine via the operator panel is being carried out.
SS030	No Release	No enable signal. The parameter identification demands enable on digital input STOA and STOB.
SS031	Error – see 259	Error during the auto set-up routine. Check the value of <i>Actual error</i> 259 .
SS032	Warning Phase Asymmetry	The parameter identification feature diagnosed an unbalance during the measurements in the three motor phases.
SS099	Setup not carried out	The setup is not carried out until now.

8.2.8 Warnings during commissioning (SA...)

Warning Messages	
Code	Measures / Remedy
SA000	No warning message present. This message can be read out via an optional communication board.
SA001	The value of the parameter <i>Rated voltage</i> 370 is out of the rated voltage range of the frequency inverter. The maximum reference voltage is indicated on the nameplate of the frequency inverter.
SA002	For a three-phase motor, the calculated efficiency is in the limit range. Check the values entered for the parameters <i>Rated voltage</i> 370 , <i>Rated current</i> 371 and <i>Rated power</i> 376 .
SA003	The value entered for parameter <i>Rated cos phi</i> 374 is outside of the normal range (0.6 to 0.95). Check the value.
SA004	For three-phase motor, the calculated slip is in the limit range. Check the values entered for parameters <i>Rated speed</i> 372 and <i>Rated frequency</i> 375 .
SA011	Current Controller non typical value; refer to 17.5.1.
SA012	Current Controller non typical value with 2 kHz; refer to chapter 17.5.1.
SA014	Current Controller non typical value with 4 kHz; refer to chapter 17.5.1.
SA018	Current Controller non typical value with 8 kHz; refer to chapter 17.5.1.
SA021	The stator resistance is very high. The following causes are possible: <ul style="list-style-type: none"> – The motor cable cross-section is not sufficient. – The motor cable is too long. – The motor cable is not connected correctly. – The contacts are not in a proper condition (corrosion).
SA022	The rotor resistance is very high. The following causes are possible: <ul style="list-style-type: none"> – The motor cable cross-section is not sufficient. – The motor cable is too long. – The motor cable is not connected correctly. – The contacts are not in a proper condition (corrosion).
SA031	Shorten Motor Line using Switching frequency 16 kHz.
SA032	Shorten Motor Line using Switching frequency 12 kHz and higher.
SA033	Shorten Motor Line using Switching frequency 8 kHz and higher.
SA041	The slip speed was not determined correctly. Check the values entered for parameters <i>Rated speed</i> 372 and <i>Rated frequency</i> 375 .
SA042	The slip speed was not determined correctly. Check the values entered for parameters <i>Rated speed</i> 372 and <i>Rated frequency</i> 375 .

SA051	The machine data for star connection were entered, the motor, however, is connected in delta. For star operation, change the motor cable connection. For delta operation, check the entered rated motor values. Repeat the parameter identification.
SA052	The machine data for delta connection were entered, the motor, however, is connected in star. For delta operation, change the motor cable connection. For star operation, check the entered rated motor values. Repeat the parameter identification.
SA053	A phase asymmetry was measured. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion.
SA053	The Resolver angle was not estimated correctly.

8.2.9 Error messages during commissioning (SF...)

After completion or during the parameter identification, error messages may be displayed. Depending on the error code, the following instructions should be followed and the measures indicated should be taken.

Error Messages	
Code	Measures / Remedy
SF000	No error message exists.
SF001	The value entered for parameter <i>Rated Current</i> 371 is too low. Correct the value.
SF002	The value for parameter <i>Rated Current</i> 371 is too high, referred to parameters <i>Rated Power</i> 376 and <i>Rated Voltage</i> 370 . Correct the values.
SF003	The value entered for parameter <i>Rated Cosine Phi</i> 374 is wrong (greater than 1 or smaller than 0.3). Correct the value.
SF004	The calculated slip frequency is negative. Check and, if necessary, correct the values entered for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .
SF005	The calculated slip frequency is too high. Check and, if necessary, correct the values entered for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .
SF006	The calculated total output of the drive is lower than the rated power. Correct and check, if necessary, the value entered for parameter <i>Rated Power</i> 376 .
SF007	The set configuration is not supported by the set-up routine.
SF011	The main inductance measurement has failed because the motor has a high slip. Correct the rated motor values in parameters 370, 371, 372, 374, 375 and 376 . Carry out the guided commissioning once again. In case an error message is displayed again, enter the value 110 for parameter <i>Configuration</i> 30 (sensorless regulation according to U/f-characteristic) if value 410 was set so far. Carry out the guided commissioning once again.
SF012	The leakage inductance measurement has failed because the motor has a high slip. Correct the rated motor values in parameters 370, 371, 372, 374, 375 and 376 . Carry out the guided commissioning once again. In case an error message is displayed again, enter the value 110 for parameter <i>Configuration</i> 30 (sensorless regulation according to U/f-characteristic) if value 410 was set so far. Carry out the guided commissioning once again.
SF021	The measurement of the stator resistance did not deliver a plausible value. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion and safe contact. Repeat the parameter identification
SF022	The measurement of the rotor resistance did not deliver a plausible value. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion and safe contact. Repeat the parameter identification
SF026	The setup-routine is aborted.

8.2.10 Application data

Due to the wide range of drive applications with the resulting parameter settings it is necessary to check further parameters. The parameters polled during the guided commissioning procedure were selected from standard applications. After completion of commissioning, further parameters can be set in the PARA menu branch.



At the control unit KP500 parameter numbers > 999 are displayed hexadecimal at the leading digit (999, A00 ... B5 ... C66).

8.2.10.1 Acceleration and deceleration

The settings define how fast the output frequency changes after a reference value change or a start, stop or brake command.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
420	Acceleration (clockwise)	0.00 Hz/s	999.99 Hz/s	5.00 Hz/s
421	Deceleration (clockwise)	0.00 Hz/s	999.99 Hz/s	5.00 Hz/s

NOTE

The deceleration of the drive is monitored in the default parameter setting *Voltage controller operation mode 670*. The deceleration ramp can be extended in the case of an increase in the DC link voltage during regenerative operation and/or during the braking process.

8.2.10.2 Set points at multi-functional input


The multi-functional input MF11 can be parameterized for a reference value signal in *Operation mode 452*. Operation mode 3 should only be selected by expert users for drive control via *Fixed frequency 1 480* and *Fixed frequency 2 481*.

Operation mode 452	Function
1 - Voltage Input	voltage signal (MF11A), 0 V ... 10 V
2 - Current Input	current signal (MF11A), 0 mA ... 20 mA
3 - Digital Input	digital signal (MF11D), 0 V ... 24 V




Use multifunction input MF11 as digital input for slow signals. For rapidly and regularly changing signals, a digital input S2IND...S6IND or a digital input of an expansion module EM should be used.

8.2.11 Quitting commissioning



Confirm the "End" display by pressing the ENT key.

The guided commissioning of the frequency inverter is terminated via a reset and the initialization of the frequency inverter. The relay output X10 signalizes a fault, because of the factory setting *Op. Mode Digital Output 3* **532** = "103 - Inv. Error Signal" (Inv: inverted).



After successful initialization of the frequency inverter, the factory-set parameter *Actual frequency* **241** is displayed.

The drive is accelerated to the set *min. frequency* **418** (factory setting 3.50 Hz in configurations 110, 111, 410, 411, 430 or to 0.00 Hz in configurations 210, 211, 230, 510) by:

- signals at digital inputs S1IND/STOA and S7IND/STOB and
- Start clockwise by rising signal edge at S2IND or
Start anticlockwise by rising signal edge at S3IND

Status signals

160 -	Ready Signal	1)	Indicates initialization and operating readiness of the inverter.
1 -	Ready or Standby Signal	2)	Indicates initialization and operating readiness of the inverter.
161 -	Run Signal	1)	Indicates enable and start command (output frequency available).
2 -		2)	Indicates enable and start command (output frequency available).
162 -	Error Signal	1)	Monitoring function signalizes a fault with display in parameter <i>Current Error</i> 259 .
3 -		2)	

1) For linking with inverter functions

2) For digital output

8.2.12 Selection of an actual value for display

After commissioning, the value of parameter *Actual frequency* **241** is displayed at the control unit KP500.

If another actual value is to be displayed after a restart, make the following settings:

- Use the arrow keys to select the actual value to be displayed as from now.
- Use the ENT key to display the value of the parameter.
- Press the ENT key again. "SEt" is displayed for confirmation.

As from now, the selected actual value is displayed after each restart.

If the parameter settings were made via the optional control software or in the PARA menu branch of the operating unit, the display of the selected actual value must be activated manually. Use the ESC key to switch to the selection of the actual value for display again.

8.3 Check direction of rotation



WARNING

The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

The documentation and device specification must be complied with during installation.

Before any assembly or connection work, discharge the frequency inverter. Verify that the frequency inverter is discharged.

Do not touch the terminals because the capacitors may still be charged.

Only connect suitable voltage sources. The nominal voltage of the frequency inverter must correspond to the supply voltage.

The frequency inverter must be connected to ground potential.

If voltage supply is switched on, no covers of the frequency inverter may be removed.

To check if the reference value and the actual direction of rotation of the drive correspond to one another, proceed as follows:

- Operate the drive at low speed, i.e. specify a reference value of approx. 10%.
- Switch on release of frequency inverter briefly:
Connect digital inputs S1IND/STOA and S7IND/STOB as well as S2IND (Start clockwise) or connect S1IND/STOA and S7IND/STOB as well as S3IND (Start anticlockwise).
- Check if the motor shaft turns in the required direction.
In case the sense of rotation is wrong, exchange two motor phases, e.g. U and V at the terminals of the frequency inverter. The mains-side connection of the frequency inverter does not affect the sense of rotation of the drive. In addition to checking the drive, the corresponding actual values and operating messages can be read out by means of the operating unit.



The commissioning of the frequency inverter is complete and can be complemented by further settings in the PARA menu. The set parameters have been selected in such a way that they are sufficient for commissioning in most applications. The other settings which are relevant to the application can be checked according to the operating instructions.

If the controller release of the frequency inverter at S1IND/STOA and S7IND/STOB is switched off the power output stage will be disabled. The motor will coast down or, if installed, a break will be activated.

8.4 Speed sensor

For some configurations an incremental speed sensor must be connected. Dependent on the speed sensor type it can be connected to the basic device or to an expansion module. Some applications require the connection to the basic device as well as to the expansion module.



The source of the actual speed value is selected via parameter *Actual Speed Source 766*. By default, speed sensor 1 is used as the actual speed source. If speed sensor 2 of an expansion module delivers the actual value signal for the speed controller, speed sensor 2 must be selected as the source.

<i>Actual Speed Source 766</i>	Function
1 - Speed Sensor 1	The actual speed source is speed sensor 1 of the basic device (factory setting).
2 - Speed Sensor 2	The actual speed source is speed sensor 2 of an expansion module. ¹⁾

¹⁾ Only available if an expansion module is installed.

Dependent on the application and applied speed sensors the settings of parameters must be adapted according to the following table.

Parameter		Only speed sensor 1	Only speed sensor 2	Both speed sensors
490	Operation Mode speed sensor 1	> 0	0 - Off	> 0
491	Division Marks speed sensor 1	1...8192	X	1...8192
493	Operation Mode speed sensor 2	0 - Off	> 0	> 0
494	Division Marks speed sensor 2	X	1...8192	1...8192
495	Level	X	Selection	Selection
766	Actual Speed Source	1	2	1 or 2

X: can be set to any value, it is not evaluated

The above-mentioned parameters are selectable dependent on configuration setting and installed expansion module.



Some applications require two speed sensors. Parameter *Actual Speed Source 766* must be set to the motor speed sensor for motor control. The other speed sensor is used external. Comply with the application manuals "Electronic gear" and "Positioning".

8.4.1 Speed sensor 1

Connect the speed sensor tracks to the digital inputs S5IND (track A), S4IND (track B) and S6IND (track Z).

The speed sensor type and the evaluation required are adjusted via the *Operation Mode 490* of speed sensor 1.

For a detailed description of possible settings refer to section 10.4.

Parameter		Settings		
No.	Description	Min.	Max.	Fact.
490	Operation Mode speed sensor 1	Selection		
491	Division Marks speed sensor 1	1	8192	1024



Dependent on the *Operation Mode 490* of speed sensor 1 the digital inputs S4IND, S5IND and S6IND are disabled for other functions. The functions will not be evaluated. The actual speed and frequency of speed sensor 1 is displayed in Parameters **217** and **218**.

8.4.2 Speed sensor 2

Speed sensor 2 must be connected to an expansion module. For connection, functions and detailed parameter description refer to the applicable operation instructions manual of the expansion module.

Parameter		Settings		
No.	Description	Min.	Max.	Fact.
493	Operation Mode speed sensor 2	Selection		
494	Division Marks speed sensor 2	1	8192	1024
495	Level	Selection		

The parameters 493, 494 and 495 are selectable dependent on the installed expansion module.



Dependent on the *Operation Mode 493* of speed sensor 2 some digital inputs of the expansion module are disabled for other functions. The functions will not be evaluated. The actual speed and frequency of speed sensor 2 is displayed in Parameters **219** and **220**.

8.5 Set-up via the Communication Interface

Parameter-setting and commissioning of the frequency inverter via one of the optional communication interfaces include the plausibility check and the parameter identification functions. The parameters can be adjusted by qualified users. The parameter selection during the guided commissioning procedure includes the basic parameters. These are based on standard applications of the corresponding configuration and are therefore useful for commissioning.



WARNING

Parameter settings may only be changed by qualified staff. Before starting the commissioning process, read the documentation carefully and comply with the safety instructions.

The parameter *SETUP Selection 796* defines the function which is carried out directly after the selection (if controller enabling signal is present at digital inputs S1IND/STOA and S7IND/STOB). The operation modes include functions which are also carried out automatically one after the other during the guided commissioning procedure.

<i>SETUP Selection 796</i>	Function
0 - Clear Status	The auto set-up routine does not perform a function.
1 - Continue	The warning message is acknowledged and the auto set-up routine is continued.
2 - Abort	The auto set-up routine is stopped and a RESET of the frequency inverter is performed.
10 - Complete Setup, DS0	The auto set-up routine is performed in data set 0 and the parameter values are stored in all of the four data sets identically.
11 - Auto set-up complete, DS1	The parameter values of the auto set-up are stored in data set 1.
12 - Auto set-up complete, DS2	The parameter values of the auto set-up are stored in data set 2.
13 - Auto set-up complete, DS3	The parameter values of the auto set-up are stored in data set 3.
14 - Auto set-up complete, DS4	The parameter values of the auto set-up are stored in data set 4.
20 - Check Machine Data, DS0	The auto set-up routine checks the rated motor parameters in the four data sets.
21 - Plaus. contr. motor data, DS1	The rated motor parameters in data set 1 are checked for plausibility.
22 - Plaus. contr. motor data, DS2	The rated motor parameters in data set 2 are checked for plausibility.
23 - Plaus. contr. motor data, DS3	The rated motor parameters in data set 3 are checked for plausibility.
24 - Plaus. contr. motor data, DS4	The rated motor parameters in data set 4 are checked for plausibility.
30 - Calculation and Para-Ident., DS0	The auto set-up routine determines extended motor data via the parameter identification feature, calculates dependent parameters and stores the parameter values in all of the four data sets identically.
31 - Calc. and para ident., DS1	Additional motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 1.
32 - Calc. and para ident., DS2	Additional motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 2.

SETUP Selection 796	Function
33 - Calc. and para ident., DS3	Additional motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 3.
34 - Calc. and para ident., DS4	Additional motor data are measured, dependent parameters are calculated and the parameter values are saved in data set 4.
40 - Para-Ident. Machine Data only, DS0	Additional motor data are measured and saved in all of the four data sets.
41 - Para-Ident. Machine Data only, DS1	Additional motor data are measured and saved in data set 1.
42 - Para-Ident. Machine Data only, DS2	Additional motor data are measured and saved in data set 2.
43 - Para-Ident. Machine Data only, DS3	Additional motor data are measured and saved in data set 3.
44 - Para-Ident. Machine Data only, DS4	Additional motor data are measured and saved in data set 4.
110 - Complete Setup w/o Para-Ident., DS0	The auto set-up routine is performed in data set 0 and the parameter values are stored in all of the four data sets identically. Extended motor data are not measured.
111 - Complete Setup w/o Para-Ident., DS1	The parameter values of the auto set-up are stored in data set 1. Extended motor data are not measured.
112 - Complete Setup w/o Para-Ident., DS2	The parameter values of the auto set-up are stored in data set 2. Extended motor data are not measured.
113 - Complete Setup w/o Para-Ident., DS3	The parameter values of the auto set-up are stored in data set 3. Extended motor data are not measured.
114 - Complete Setup w/o Para-Ident., DS4	The parameter values of the auto set-up are stored in data set 4. Extended motor data are not measured.



The “additional motor data” also contain values of the current controller settings.

The individual steps of the auto set-up routine can be monitored and checked via parameter **SETUP Status 797**. The setup routine via the communication interface continuously updates the status parameter which can be read out via the interface.



For the status message of the Auto set-up comply with

- Chapter 8.2.7 “Status messages during commissioning (SS...)”
- Chapter 8.2.8 “Warnings during commissioning (SA...)”
- Chapter 8.2.9 “Error messages during commissioning (SF...)”

9 Inverter Data

The series ACU frequency inverters are suited for a wide range of applications. The modular hardware and software structure enables customer-specific adaptation. The available hardware functionality of the frequency inverter is displayed in the control unit and the optional control software VPlus. The software parameters can be adjusted to meet the requirements of the specific application.

9.1 Serial Number

The *Serial Number 0* is entered on the nameplate during the fabrication of the frequency inverter. Information on the device type and the fabrication data (8-digit number) are indicated. Additionally, the serial number is printed on the nameplate.

Serial number 0 : 603409000 ; 06053980 (part no.; serial no.)
Nameplate: Type: ACU 401 – 09 ; Serial No.: 06053980

9.2 Optional Modules

Modular extension of the hardware is possible via the plug-in slots. The *Optional modules 1* detected by the frequency inverter and the corresponding designations are displayed on the control unit and in the optional control software VPlus after initialization. For the parameters required for the expansion module, refer to the corresponding operating instructions.

CM-232 ; EM-IO-01

9.3 Inverter Software Version

The firmware stored in the frequency inverter defines the available parameters and functions of the software. The software version is indicated in parameter *Inverter software version 12*. In addition to the version, the 6-digit software key is printed on the rating plate of the frequency inverter.

Inverter software version 12: 5.4.0
Nameplate: Version: 5.4.0 ; Software: 15 000 190

Copyright 15 (C) 2013 BONFIGLIOLI VECTRON

9.4 Set Password

As a protection against unauthorized access, the parameter *Set password 27* can be set such that anyone who wants to change parameters must enter this password this password before. A change of parameter is only possible if the password is entered correctly. If the *Set password 27* parameter is set to zero, no password is required for access to the parameters. The previous password is deleted.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
27	Set password	0	999	0

9.5 Control Level

The *Control level 28* defines the scope of the functions to be parameterized. The operating instructions describe the parameters on the third control level. These parameters should only be set by qualified users.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
28	Control level	1	3	1

9.6 User Name

The *User name 29* can be entered via the optional control software VPlus. The plant or machine designation cannot be displayed completely via the control unit.

32 alphanumeric characters

9.7 Configuration

The *Configuration 30* determines the assignment and basic function of the control inputs and outputs as well as the software functions. The software of the frequency inverters offers various configuration options. These differ with respect to the way in which the drive is controlled. Analog and digital inputs can be combined and complemented by optional communication protocols. The operating instructions describe the following configurations and the relevant parameters in the third *Control level 28* (adjustment of parameter *Control level 28* to value 3).

Configuration 110, sensorless control

Configuration 110 contains the functions for variable-speed control of a 3-phase machine in a wide range of standard applications. The motor speed is set according to the V/f characteristic in accordance with the voltage/frequency ratio.

Configuration 111, sensorless control with technology controller

Configuration 111 extends the functionality of the sensorless control by software functions for easier adaptation to the customer's requirements in different applications. Depending on the application, the technology controller may be used, which enables the control of flow rate, pressure, contents level or speed.

Configuration 410, sensorless field-oriented control

Configuration 410 contains the functions for sensorless, field-oriented control of a 3-phase machine. The current motor speed is determined from the present currents and voltages in combination with the machine parameters. In this configuration, parallel connection of several 3-phase motors is possible to a limited extent only.

Configuration 411, sensorless field-oriented control with technology controller

Configuration 411 extends the functionality of Configuration 410 by a Technology Controller, which enables a control based on parameters such as flow rate, pressure, contents level or speed.

Configuration 430, sensorless field-oriented control with speed/torque control

Configuration 430 extends the functionality of Configuration 410 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

Configuration 210, field-oriented control

Configuration 210 contains the functions for speed-controlled, field-oriented control of a 3-phase machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.

Configuration 211, field-oriented control with technology controller

Configuration 211 extends the functionality of Configuration 210 by a Technology Controller, which enables a control based on parameters such as flow rate, pressure, contents level or speed.

Configuration 230, field-oriented control with speed/torque control

Configuration 230 extends the functionality of Configuration 210 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

Configuration 510, field-oriented control of synchronous machine, speed controlled

Configuration 510 contains the functions for speed-controlled, field-oriented control of a synchronous machine with speed sensor feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The necessary speed sensor feedback results in a precise speed and torque performance.

Configuration 530, field-oriented control of synchronous machine with speed/torque control

Configuration 530 extends the functionality of Configuration 510 by functions for torque-dependent, field-oriented control. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

Configuration 610, Sensorless Field-Oriented Control of Synchronous Machine, Speed Controlled

Configuration 610 contains the functions for speed-controlled, field-oriented control of a synchronous machine without resolver feedback. The separate control of torque and flux-forming current enables high drive dynamics with a high load moment. The missing resolver feedback compared to configuration 510 results in a small loss of dynamic and speed performance.

Configuration 611, Sensorless Field-Oriented Control of a Synchronous Machine with Technology Controller

Configuration 611 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Technology Controller. The Technology Controller enables a control based on parameters such as flow rate, pressure, filling level or speed.

Configuration 630, Sensorless Field-Oriented Control of a Synchronous Machine, Speed and Torque Controlled

Configuration 630 extends the functionality of the sensorless field-oriented control of Configuration 610 by a Torque Controller. The reference torque is represented as a percentage and it is transmitted into the corresponding operational performance of the application. Change-over between variable-speed control and torque-dependent control is done jerk-free during operation.

In the table, you will find a list of functions which are available in the different configurations.

Function	Chapter	Configuration												
		V/f Characteristic		field-oriented control										
		Sensorless 1xx	Sensorless 4xx	Sensorless 1xx	Sensorless 4xx	Sensorless 4xx	Sensor 2xx	Sensor 2xx	Sensor 2xx	Servo 5xx	Servo 5xx	Servo sensorless 6xx	Servo sensorless 6xx	Servo sensorless 6xx
		110	111	410	411	430	210	211	230	510	530	610	611	630
Speed control	17.5.4			x		x	x	x	x	x	x	x	x	x
Torque control	17.5.2					x			x		x			x
Switch-over speed /torque control	15.4.6					x			x		x			x
Dynamic voltage pre-control	16.1	x	x											
Intelligent current limits	17.1	x	x	x	x	x	x	x	x	x	x	x	x	x
Voltage controller	17.2	x	x	x	x	x	x	x	x	x	x	x	x	x
Technology controller:	17.3		x		x			x					x	
– pressure control	17.3		x		x			x					x	
– Volume flow control	17.3		x		x			x					x	
– Contents level control	17.3		x		x			x					x	
– Speed control	17.3		x		x			x					x	
Slip compensation	17.4.1	x												
Current limit val. controller	17.4.2	x	x											
Current Controller	17.5.1			x	x	x	x	x	x	x	x	x	x	x
Limit Value Sources	17.5.2			x	x	x	x	x	x	x	x	x	x	x
Acceleration Pre-Control	17.5.5			x	x	x	x	x	x	x	x	x	x	x
Field Controller	17.5.6			x	x	x	x	x	x					
Modulation Controller	17.5.7			x	x	x	x	x	x					
Starting behavior:	12.1	x	x	x	x	x	x	x	x	x	x	x	x	x
– Starting current impression	12.1.1.1	x	x	x	x	x						x	x	x
– Flux Formation	12.1.2			x	x	x	x	x	x					
Stopping behavior:	12.2	x	x	x	x	x	x	x	x	x	x	x	x	x
– Direct current brake	12.3	x	x											
Auto Start	12.4	x	x	x	x	x	x	x	x	x	x	x	x	x
Search Run	12.5	x	x	x	x	x	x	x	x	x	x	x	x	x
Reference point positioning	12.6.1	x		x			x			x		x		
Axle Positioning	12.6.2						x			x				
Frequency reference ch.	14.4	x		x		x	x		x	x	x	x		x
Reference percentage ch.	14.5		x		x	x		x	x		x		x	x
Fixed Frequencies	14.6.1	x	x	x	x	x	x		x	x	x	x	x	x
Fixed Percentages	14.6.3		x		x	x		x	x		x		x	x
Block Frequencies	14.9	x	x	x	x	x	x		x	x	x	x	x	x
PWM-/repetition frequency input	14.11	x	x	x	x	x	x	x	x	x	x	x	x	x
Brake chopper	18.4	x	x	x	x	x	x	x	x	x	x	x	x	x
Motor protection switch	18.5	x	x	x	x	x	x	x	x	x	x	x	x	x
V-belt Monitoring	18.5.2	x	x	x	x	x	x	x	x	x	x	x	x	x
Motor Chopper	18.7.1			x	x	x	x	x	x					
Temperature Adjustment	18.7.2			x	x	x	x	x	x					
Speed Sensor Monitoring	18.7.3						x	x	x					

9.8 Language

The parameters are stored in the frequency inverter in various languages. The parameter description is displayed by the PC control software (e.g. VPlus) in the selected *Language 33*.

<i>Language 33</i>	Function
0 - Deutsch	Parameter description in German.
1 - English	Parameter description in English.
2 - Italiano	Parameter description in Italian.
100 -	The language is defined via VPlus (ACU firmware 5.2.0 or higher)



Up to ACU firmware 5.1.11 the language is set via *Language 33* = 0,1,2. Starting with ACU firmware 5.2.0 the texts of the parameters is administered by the PC software VPlus. When *Language 33* is set to 100, the settings 0,1 and 2 are not selectable. Firmware version 5.2.0 or higher requires a compatible VPlus version (VPlus 7.38 or higher).

9.9 Programming

The parameter *Program(ming) 34* enables acknowledgment of a fault message and resetting to the factory settings. The display of the control unit reads "dEFLt" or "rESEt" and the LEDs indicate the status of the frequency inverter.

<i>Program(ming) 34</i>	Function
111 - Parameter transmission	Control unit P 500 is prepared for parameter transmission. A connected frequency inverter can receive data from the control unit.
110 - Standard operation	Resetting of control unit KP 500 to standard operation mode
123 - Reset	The current error message can be acknowledged via digital input S1IND/STOA or the software parameter. The display of the control unit reads "rESEt".
4444 - Default	The parameters of the selected configuration, except for a few exceptions, are reset to the default settings. The display of the control unit reads "dEFLt".



Parameters *Control level 28*, *Language 33* as well as *Configuration 30* are not changed during resetting to factory settings (*Program(ming) 34* = 4444).

10 Machine Data

The input of the machine data is the foundation for the functionality of the control functions and methods. In the course of the guided commissioning, the necessary parameters are inquired according to the selected *Configuration 30*.

10.1 Rated Motor Parameters

Set the rated parameters of the three-phase asynchronous machine according to the rating plate or the data sheet of the motor. The default settings of the machine parameters are based on the nominal data of the frequency inverter and the corresponding four-pole three-phase motor. The machine data required for the control functions and methods are checked for plausibility and calculated in the course of the commissioning.

Check the rated values specified by default.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
370	Rated voltage	$0.17 \cdot U_{FIN}$	$2 \cdot U_{FIN}$	U_{FIN}
371	Rated current	$0.01 \cdot I_{FIN}$	$10 \cdot o \cdot I_{FIN}$	I_{FIN}
372	Rated speed	96 min^{-1}	60000 min^{-1}	n_N
373	No. of pole pairs	1	24	2
374	Rated cosine (φ)	0.01	1.00	$\cos(\varphi)_N$
375	Rated frequency	10.00 Hz	1000.00 Hz	50.00 Hz
376	Rated mechanical power	$0.01 \cdot P_{FIN}$	$10 \cdot P_{FIN}$	P_{FIN}

U_{FIN} = Nominal Voltage of Frequency inverter, typically 400 V or 230 V

I_{FIN} = Nominal Output current of Frequency inverter

P_{FIN} = Nominal Output of Frequency inverter

o: Overload capability of Frequency inverter



The Parameter *Rated cosine(φ) 374* is not available in configurations 5xx and 6xx (Synchronous motor).

In the case of three-phase machines, the speed can be increased at a constant torque if the motor winding can be switched over from star to delta connection. The change-over leads to a modification of the dependent rated figures by a square root of three.

NOTE

The rated data of the motor are to be entered according to the specifications on the rating plate for the motor connection type used (star or delta connection).

If the data entered deviate from the rating plate, the parameters will not be identified correctly. Parameterize the rated data according to the rating plate of the motor for the wiring of the motor winding. Consider the increased rated current of the connected three-phase motor.

10.2 Further motor parameters

In particular the field-oriented control requires the determination of further data which cannot be read off the rating plate of the 3-phase machine for the precise calculation of the machine model. In the course of the guided commissioning, the parameter identification was carried out to measure the further motor parameters.

10.2.1 Stator Resistance

The resistance of the stator winding is measured during the guided commissioning. The measured value is saved as a phase value in parameter *Stator resistance* **377** and is 3 times smaller than the winding resistance in delta connection. By default, the equivalent stator resistance of a standard motor is entered to match the reference output of the frequency inverter.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
377	Stator resistance ¹⁾	0 mΩ	65535 mΩ	R _{SN}
1190	Stator resistance ²⁾	0.001 Ω	100.000 Ω	10.000 Ω

¹⁾ Available in configurations 1xx, 2xx, 4xx (Parameter *Configuration* **30**).

²⁾ Available in configurations 5xx and 6xx (Parameter *Configuration* **30**).

Stator resistance asynchronous motor:

The value of the stator resistance can be optimized while the machine is in no-load operation. At the stationary operating point, the torque-forming current *Isq* **216** and/or the estimated *Active current* **214** should be zero. Due to the temperature-dependent of the stator resistance, the adjustment should be done at a winding temperature which is also reached during normal operation.

A correct measurement will optimize the control functions.

Stator resistance asynchronous motor:

The value of the stator resistance of the synchronous motor is entered during the guided commissioning. The value of the stator resistance is used for adjustments of the current controller and should be therefore entered as exact as possible. The *stator resistance* **1190** is the value between two motor phases and can be taken usually from the data sheet of the motor.

10.2.2 Leakage Coefficient

The leakage coefficient of the machine defines the ratio of the leakage inductivity to the main inductivity. The torque and flux-forming current components are thus coupled via the leakage coefficient. Optimization of the leakage coefficient within the field-orientated control systems demands acceleration to various operating points of the drive. Unlike the torque-forming current *Isq* **216**, the flow-forming current *Isd* **215** should be largely independent of the load torque. The flow-forming current component is inversely proportional to the leakage coefficient. If the leakage coefficient is increased, the torque-forming current increases and the flux-forming component drops. The adjustment should result in a relatively constant actual current *Isd* **215**, matching the set *Rated magnetizing current* **716**, regardless of the load on the drive.

The sensorless control system uses the parameter *Leakage coefficient* **378** in order to optimize the synchronization to one drive.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
378	Leakage Coefficient	1.0 %	20.0 %	7.0 %

10.2.3 Magnetizing Current

The *Rated magnetizing current* **716** is a measure of the flux in the motor and thus of the voltage which is present at the machine in no-load condition depending on the speed. The guided commissioning determines this value at about 30% of the *Rated current* **371**. This current can be compared to the field current of an externally excited direct current machine.

In order to optimize the sensorless field-oriented control system, the machine must be operated without load at a rotational frequency which is below the *Rated frequency* **375**. The accuracy of the optimization increases with the adjusted *Switching frequency* **400** and when the drive is in no-load operation. The flux-forming actual current value *Isd* **215** to be read out should roughly match the set *Rated magnetizing current* **716**.

The field-orientated control with speed sensor feedback uses the parameterized *Rated magnetizing current* **716** for the flux in the motor.

The dependence of the magnetizing on the frequency and voltage at the corresponding operating point in question is taken into account by a magnetizing characteristic. The characteristic is calculated via three points, in particular in the field weakening area above the rated frequency. The parameter identification has determined the magnetizing characteristic and set the parameters *Magnetizing current 50%* **713**, *Magnetizing current 80%* **714** and *Magnetizing current 110%* **715**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
713	Magnetizing current 50%	1.00 %	50.00 %	31.00 %
714	Magnetizing current 80%	1.00 %	80.00 %	65.00 %
715	Magnetizing current 110%	110.00 %	197.00 %	145.00 %
716	Rated magnetizing current	$0.01 \cdot I_{FUN}$	$\ddot{u} \cdot I_{FUN}$	$0.3 \cdot I_{FUN}$

10.2.4 Rated slip correction factor

The rotor time constant results from the inductivity of the rotor circuit and the rotor resistance. Due to the temperature-dependence of the rotor resistance and the saturation effects of the iron, the rotor time constant is also dependent on temperature and current. The load behavior and thus the rated slip depend on the rotor time constant. The guided commissioning determines the machine data during the parameter identification and sets the parameter *Rated slip correction factor* **718** accordingly. For the fine adjustment or a check of the rotor time constant, proceed as follows: Load the machine at fifty percent of the *Rated frequency* **375**. As a result, the voltage must be approximately fifty percent of the *Rated voltage* **370**, with a maximum tolerance of 5 %. If this is not the case, the correction factor must be changed accordingly. The larger the correction factor is set, the stronger the voltage drop when the machine is loaded. The value calculated by the rotor time constants can be read out via the actual value *Current rotor time constant* **227**. The adjustment should be done at a winding temperature which is also reached during normal operation of the motor.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
718	Rated slip correction factor	0.01 %	300.00 %	100.00 %

10.2.5 Voltage constant

In configuration 5xx and 6xx for the control of synchronous machines, the control behavior can be improved for high dynamic requirements by the settings of the parameter *Voltage constant* **383**.

For the voltage constant, refer to the motor data sheet. In the motor data sheet, the value may be indicated in $\frac{V}{1000 \text{ rpm}}$. This value can be taken over for parameter

Voltage constant **383**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
383	Voltage constant	0.0 mVmin	850.0 mVmin	0.0 mVmin

If the guided commissioning (Setup) is not carried out, the auto-setup should be carried out via parameter *SETUP selection* **796** in order to improve the drive behavior, particularly for small speeds. Select one of the settings 10 ... 14 for *SETUP selection* **796**.

During the guided commissioning (via keypad and VPlus) for Bonfiglioli motors the voltage constant is pre-allocated.

For Non-Bonfiglioli motors the voltage constant should be entered if it is known. If the voltage constant is unknown, set *Voltage constant* **383** to 0 mV before the commissioning to ensure the automatic calculation and measurement.

The voltage constant should be optimized after the guided commissioning procedure: In no-load operation, set 50% of the rated speed. Change the voltage constant in small steps until parameter *Rotor flux* **225** displays the value 101% ($\pm 0.5\%$).



In the case of motors with a very high number of pole pairs (e.g. higher than 20), it is possible that the maximum setting range of the parameter is not sufficient. In this case, divide the voltage constant by 10 and enter the value. The division by 10 is considered internally.

10.2.6 Stator inductance

In configuration 5xx for the control of synchronous machines, the control behavior can be improved for high dynamic requirements by setting the parameter *Stator inductance* **384**.

The *stator inductance* **384** is the value between two motor phases and can be taken usually from the data sheet of the motor.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
384	Stator inductance	0.1 mH	500.0 mH	1.0 mH

10.2.7 Peak current

The parameter *Peak Current* **1192** is used during the guided commissioning to set the limits for the I_{sq} set value in the frequency inverter. This serves the protection of the connected synchronous motor. The value can be taken from the motor name plate or the motor data sheet. Exceeding the values given by the motor manufacturer can lead to damages in the motor.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
1192	Peak current	0.01 % $I_{FI,N}$	100 000 % $0 \cdot I_{FI,N}$	100 % $I_{FI,N}$

$I_{FI,N}$: Nominal value of Frequency inverter

o: Overload capability of Frequency inverter

10.2.8 Change sense of rotation

The parameter *Change sense of rotation* **1199** reverses the rotating direction of the motor.

Operation mode 1199	Positive Set value	Negative Set value
0 - Off	Motor rotates forward (clockwise)	Motor rotates reverse (anti clockwise)
1 - On	Motor rotates reverse (anti clockwise)	Motor rotates forward (clockwise)



BONFIGLIOLI VECTRON defines with view on the motor A side and correct connection of the motor phases the sense of rotation clockwise (forward) with a positive set value. With a changed sense of rotation, the motor reverses with the same set value. Existing gear boxes and transmissions have to be considered.



The sense of rotation can only be changed while the output stage is inhibited.



With the parameter *Change sense of rotation* **1199** the sense of direction of the complete system (motor control and encoder evaluation) is reversed.

When the sense of direction is different between motor and encoder, this can be changed by two actions:

- 1.) Change the track A and track B at the encoder inputs at the terminals of ACU.
- 2.) Change the evaluation of the sense of rotation of the connected encoder with parameter **490** respectively **493**.

10.3 Internal values

The following parameters are used for internal calculation of motor data and do not require any set-up.

Parameter	
No.	Description
399	Internal value 01
402	Internal value 02
508	Internal value 03
702	Internal value 04
703	Internal value 05
704	Internal value 06
705	Internal value 07

Parameter	
No.	Description
706	Internal value 08
707	Internal value 09
708	Internal value 10
709	Internal value 11
745	Internal value 12
798	Internal value 13

10.4 Speed Sensor 1

The frequency inverters are to be adapted to the application depending on the requirements. A part of the available *Configuration 30* demand continuous measurement of the actual speed for the control functions and methods. The necessary connection of an incremental speed sensor is done on the digital control terminals S5IND (track A) and S4IND (track B) of the frequency inverter.



With expansion modules EM and sensor input modules, it is also possible to connect and evaluate sensors as speed sensor 2. Please refer to the corresponding operating instructions. Speed sensor 1 and speed sensor 2 are configured independently from one another.

10.4.1 Operation Mode Speed Sensor 1

Operation mode 490 for speed sensor 1 can be selected according to the connected incremental speed sensor. Connect an unipolar speed sensor to the standard control terminals.

<i>Operation mode 490</i>	Function
0 - Off	Speed measurement is not active; the digital inputs are available for other functions.
1 - Single evaluation	Two-channel speed sensor with recognition of direction of rotation via track signals A and B; one signal edge is evaluated per division mark.
4 - Quadruple evaluation	Two-channel speed sensor with recognition of direction of rotation via track signals A and B; four signal edges are evaluated per division mark.
11 - Single evaluation without sign	One-channel speed sensor via track signal A; the actual speed value is positive. One signal edge is evaluated per division mark. The digital input S4IND is available for further functions.
12 - Double evaluation without sign	One-channel speed sensor via track signal A; the actual speed value is positive. Two signal edges are evaluated per division mark. The digital input S4IND is available for further functions.
31 - Single evaluation, sense of rot. via contact	One-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. One signal edge is evaluated per division mark.
32 - Double evaluation, sense of rot. via contact	One-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark.
101 - Single evaluation inverted	Same as in operation mode 1. The actual speed value is inverted. (Alternative to exchanging the track signals)
104 - Quadruple evaluation inverted	Same as in operation mode 4. The actual speed value is inverted. (Alternative to exchanging the track signals)
111 - Single evaluation negative	Same as operation mode 11. The actual speed value is negative.
112 - Double evaluation negative	Same as operation mode 12. The actual speed value is negative.
131 - Single evaluation, sense of rot. via contact inverted	One-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. One signal edge is evaluated per division mark.
132 - Double evaluation, sense of rot. via contact inverted	One-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark.

Operation mode 490	Function
1001 – Single evaluation with reference track	Two-channel speed sensor with recognition of direction of rotation via track signals A and B, reference track via digital input S6IND. One signal edge is evaluated per division mark.
1002 – Double evaluation with reference track	Two-channel speed sensor with recognition of direction of rotation via track signals A and B, reference track via digital input S6IND. Two signal edges are evaluated per division mark.
1004 – Quadruple evaluation with reference track	Two-channel speed sensor with recognition of direction of rotation via track signals A and B, reference track via digital input S6IND. Four signal edges are evaluated per division mark.
1011 – Single evaluation with sense of rot. without sign with ref. track	One-channel speed sensor via track signal A; the actual speed value is positive. The reference track is connected to digital input S6IND. One signal edge is evaluated per division mark. The digital input S4IND is available for further functions.
1012 – Double evaluation with sense of rot. without sign with ref. track	One-channel speed sensor via track signal A; the actual speed value is positive. The reference track is connected to digital input S6IND. Two signal edges are evaluated per division mark. The digital input S4IND is available for further functions.
1031 – Single evaluation sense of rot. via contact with ref. track	One-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. One signal edge is evaluated per division mark. The reference track is connected to digital input S6IND.
1032 – Double evaluation sense of rot. via contact with ref. track	One-channel speed sensor via track signal A. The actual speed value is positive for signal "Low" and negative for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark. The reference track is connected to digital input S6IND.
1101 – Single evaluation inverted with reference track	Same as operation mode 1001. The actual speed value is negative.
1102 – Double evaluation inverted with reference track	Same as operation mode 1002. The actual speed value is negative.
1104 – Quadruple evaluation inverted with reference track	Same as operation mode 1004. The actual speed value is negative.
1111 – Single evaluation inv. with sense of rot. without sign with ref. track	Same as operation mode 1011. The actual speed value is negative.
1112 – Double evaluation inv. with sense of rot. without sign with ref. track	Same as operation mode 1012. The actual speed value is negative.
1131 – Single evaluation inv. sense of rot. via contact with ref. track	One-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. One signal edge is evaluated per division mark. The reference track is connected to digital input S6IND.
1132 – Double evaluation inv. sense of rot. via contact with ref. track	One-channel speed sensor via track signal A. The actual speed value is negative for signal "Low" and positive for signal "High" at digital input S4IND. Two signal edges are evaluated per division mark. The reference track is connected to digital input S6IND.



In configurations 210, 211 and 230, digital input S4IND is by default set for the evaluation of a speed sensor signal (track B).

If an operation mode without sign is selected (*Operation Mode 11* or *Operation Mode 12*), this input is not set for the evaluation of a speed sensor signal and can be used for other functions.

10.4.2 Division marks, speed sensor 1

The number of increments of the connected speed sensor can be adjusted via parameter *Division marks, speed sensor 1* **491**. Select the division marks of the speed sensor according to the speed range of the application.

The maximum number of division marks S_{\max} is defined by the frequency limit of $f_{\max}=150$ kHz of the digital inputs S5IND (track A) and S4IND (track B).

$$S_{\max} = f_{\max} \cdot \frac{60}{n_{\max}}$$

$$f_{\max} = 150000 \text{ Hz}$$

$$n_{\max} = \text{max. speed of the motor in RPM}$$

for example:

$$S_{\max} = 150000 \text{ Hz} \cdot \frac{60 \text{ s}}{1500} = 6000$$

To guarantee true running of the drive, an encoder signal must be evaluated at least every 2 ms (signal frequency $f = 500$ Hz). The minimum number of division marks S_{\min} of the incremental encoder for a required minimum speed n_{\min} can be calculated from this requirement.

$$S_{\min} = f_{\min} \frac{60}{A \cdot n_{\min}}$$

$$n_{\min} = \text{min. speed of the motor in RPM}$$

$$A = \text{evaluation (1, 2, 4)}$$

for example:

$$S_{\min} = 500 \text{ Hz} \cdot \frac{60 \text{ s}}{2 \cdot 10} = 1500$$


Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
491	Division marks, speed sensor 1	1	8192	1024

10.4.3 Gear factor speed sensor 1

Setting of parameters *EC1 Gear Factor Numerator* **511** and *EC1 Gear Factor Denominator* **512** is required if a gear is installed between the speed sensor and the motor shaft. The parameters define the mechanical transmission ratio between the speed sensor and the motor side. The parameters must be set such that the gear factor numerator corresponds to the motor rotations and the gear factor denominator corresponds to the sensor rotations.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
511	EC1 Gear Factor Numerator	-300.00	300.00	1.00
512	EC1 Gear Factor Denominator	0.01	300.00	1.00

Example: The motor shaft turns twice while the load shaft rotates once (16/8).



$$\frac{\text{Revolutions of motor axis}}{\text{Revolutions of load axis}} = \frac{\text{EC1 Gear Factor Numerator } \mathbf{511}}{\text{EC1 Gear Factor Denominator } \mathbf{512}}$$

In this example, parameter *EC1 Gear factor Numerator* **511** must be set to 2 and parameter *EC1 Gear factor Denominator* **512** must be set to 1.



For optimum motor control, BONFIGLIOLI VECTRON recommends installing a speed sensor directly at the motor.

10.4.4 Filter time constant speed sensor 1

EC1: Filter time constant **1193** can be used to filter the speed of speed sensor 1. This can filter can be applied in cases, where the speed sensor fluctuates (in example due to mechanical reasons). Bonfiglioli Vectron recommends to change the value in small steps and check the result and not to change the values in big steps.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
1193	EC1: Filter time constant	0 us	32000 us	0 us

10.5 Sensor evaluation

In the field of drive engineering, TTL and HTL sensors with 512, 1024 or 2048 division marks are widely used. However, other division mark values are used, too. These division marks (often also referred to as „increments“) determine the resolution (accuracy) at which a machine can be operated. A “division mark” is defined as a pulse including the pause following the pulse – the pulse-duty factor is typically 1:1, i.e. with each revolution, a track delivers the number of increments for evaluation. Depending on the characteristics of the sensor and the requirements in the machine, different degrees of sensor evaluation accuracy are possible. Typical evaluation accuracy levels include:


- Single evaluation: One edge of a pulse of a track is counted and evaluated.
- Double evaluation: Two edges (the positive and the negative edge) of a pulse of a track are counted and evaluated.
- Quadruple evaluation: A second (offset) track delivers additional edges which can be evaluated. Any status change of the two tracks is registered and evaluated. Thanks to the offset arrangement of the tracks, the direction of rotation can be detected additionally. The two tracks are commonly referred to as A and B. Depending on when the edges occur, it can be determined if the motor rotates in clockwise or in anticlockwise direction.

With double or quadruple evaluation, internal calculation for motor control is improved. The number of division marks does not change.

In addition to tracks A and B, sensors often feature a reference track (also referred to as Z track, zero track, C track). The reference track delivers one pulse per revolution. This track is used for plausibility checking or for additional functions.



If an operation mode with reference track is selected for the speed sensor, the frequency inverter will make sure that the Z track occurs according to the parameterized *Division marks, speed sensor 1 491*. If the evaluation is not consistent, a reaction as per parameter *Operation mode 760* is triggered.



HTL sensors can be connected to the basic device. The connection of TTL sensors requires an expansion module type EM-ENC. The connection of SinCos encoders or Absolute encoders requires an expansion module type EM-ABS.

11 System Data

The various control functions and methods according to the selected *Configuration 30* are supplemented by control and special functions. For monitoring the application, process parameters are calculated from electrical control parameters.

11.1 Actual System Value

The parameter *Actual system value factor 389* can be used if the drive is monitored via the actual value *Actual system value 242*.

The *Actual frequency 241* to be monitored is multiplied by the *Actual system value factor 389* and can be read out via the parameter *Actual system value 242*, i.e. *Actual frequency 241* x *Actual system value factor 389* = *Actual system value 242*.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
389	Factor Actual Value System	-100.000	100.000	1.000


11.2 Volume Flow and Pressure

The parameterization of the factors *Nominal Volumetric Flow 397* and *Nominal Pressure 398* is necessary if the matching actual values *Volumetric Flow 285* and *Pressure 286* are used to monitor the drive. The conversion is done using the electrical control parameters.

Volume flow 285 and *Pressure 286* are referred to the *Effective current 214* in the case of the sensorless control methods. In the case of the field-oriented control methods, they are referred to the torque-forming current component *Isq 216*.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
397	Nominal volumetric flow	1 m ³ /h	99999 m ³ /h	10 m ³ /h
398	Nominal pressure	0.1 kPa	999.9 kPa	100.0 kPa

Line mains or channel characteristic:



Point A in the figure describes the rating point of a pump. The transition to partial load operation mode B1 can be affected at a constant pressure H (change of conveying flow Q, pressure H remains constant). The transition to partial load operation mode B2 can be affected according to the bad point method (change of pressure H and conveying flow Q). Both methods can be realized with the integrated technology controller in configurations 111, 211, 411 and 611. The actual values displayed are calculated according to the bad point method independently of the selected *Operation mode 440* of the technology controller.

12 Operational Behavior

The operational behavior of the frequency inverter can be adjusted to the application by setting the parameters appropriately. In particular the acceleration and deceleration behavior can be selected according to the selected *Configuration 30*. Additionally, features such as Auto Start, and the synchronization and positioning functions facilitate the integration in the application.

12.1 Starting Behavior

The start of the 3-phase machine can be parameterized in accordance with the control functions and methods. In contrast to the sensorless control method, the field-oriented control methods only require the definition of the limit values *Maximum flux formation time 780* and *Current during flux formation 781* for the adjustment of the acceleration behavior. The acceleration behavior of the sensorless control method in configurations 110 and 111 can be selected as described in the following chapter.

12.1.1 Starting Behavior of Sensorless Control System

The parameter *Operation mode 620* for the starting behavior is available in configurations 110 and 111. Depending on the operation mode selected, the machine is magnetized first or a starting current is impressed. The voltage drop across the stator resistance which reduces the torque in the lower frequency range can be compensated by the IxR compensation.

To ensure the correct function of the IxR compensation, the stator resistance is determined during the guided commissioning. The IxR compensation is only activated when the stator resistance was determined correctly.

<i>Operation mode 620</i>	Starting Behavior
0 - Off	At the start the voltage with the value of parameter <i>Starting Voltage 600</i> is set at an output frequency of 0 Hz. After this, the output voltage and the output frequency are changed according to the control method. The break-away torque and the current at the start are determined by the adjusted starting voltage. It may be necessary to optimize the starting behavior via the parameter <i>Starting voltage 600</i> .
1 - Magnetization	In this operation mode, the <i>Current during flux-formation 781</i> for magnetization is impressed into the motor after release. The output frequency is kept at zero Hz for the <i>Maximum flux-formation time 780</i> . After this time has expired, the output frequency follows the adjusted V/f characteristic. (see operation mode 0- Off)
2 - Magnetization and current impression	Operation mode 2 includes operation mode 1. After the <i>Maximum flux-formation time 780</i> has elapsed, the output frequency is increased according to the set acceleration. If the output frequency reaches the value set with the parameter <i>Frequency limit 624</i> , the <i>Starting current 623</i> is withdrawn. There is a smooth transition to 1.4 times the frequency limit to the set V/f characteristic. As from this operating point, the output current depends on the load.
3 - Magnetization + IxR compensation	Operation mode 3 includes operation mode 1 of the start function. When the output frequency reaches the value set with parameter <i>Frequency limit 624</i> , the increase of the output voltage by the IxR compensation becomes effective. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.

Operation mode 620	Starting Behavior
Magnetization + 4 - current impr. + IxR-K.	In this operation mode, the current set with the parameter <i>Current during flux-formation</i> 781 is impressed into the motor for magnetization after release. The output frequency is kept at zero Hz for the <i>Maximum flux-formation time</i> 780 . After the time has elapsed, the output frequency is increased according to the set acceleration. If the output frequency reaches the value set with the parameter <i>Frequency limit</i> 624 , the <i>Starting current</i> 623 is withdrawn. There is a smooth transition to the V/f characteristic, and a load-dependent output current is obtained. At the same time, the increase of the output voltage by the IxR compensation becomes effective as from this output frequency. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.
Magn. + 12 - current impr. + w. ramp stop	Operation mode 12 contains an additional function to guarantee a starting behavior under difficult conditions. The magnetization and starting current impression are done according to operation mode 2. The ramp stop takes the current consumption of the motor at the corresponding operating point into account and controls the frequency and voltage change by stopping the ramp. The <i>Controller status</i> 275 signals the intervention of the controller by displaying the message "RSTP".
Magn. + 14 - current impr. + w. R+ IxR-K.	In this operation mode, the functions of operation mode 12 are extended by the compensation of the voltage drop across the stator resistance. When the output frequency reaches the value set with parameter <i>Frequency limit</i> 624 , the increase of the output voltage by the IxR compensation becomes effective. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.

In contrast to field-oriented control systems, sensorless control systems feature a current controller which controls the starting behavior. The PI controller checks the current impression by parameter *Starting current* **623**. The proportional and integrating parts of current controller can be adjusted via parameters *Amplification* **621** and *Integral time* **622**, respectively. The control functions can be deactivated by setting the parameters to 0.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
621	Amplification	0.01	10.00	1.00
622	Integral time	1 ms	30000 ms	50 ms

12.1.1.1 Starting Current

The *Starting current 623* ensures, particularly for high-torque start, a sufficient torque until the *Frequency limit 624* is reached.

Applications in which high current is permanently needed at a low speed are to be realized using forced-ventilated motors to prevent thermal overload.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
623	Starting Current	0.0 A	$0 \cdot I_{FIN}$	I_{FIN}

I_{FIN} = Nominal Output current of Frequency inverter

0: Overload capability of Frequency inverter

In the following settings, the starting current impression is used for the starting behavior:

- *Configuration 30* = 1xx (V/f control of asynchronous motor),
Operation mode 620 = 2, 4, 12 or 14
- *Configuration 30* = 4xx (FOC of an asynchronous motor)
- *Configuration 30* = 610 (PMSM: sensor-less field-orientated control -DMC), synchronous motor

12.1.1.2 Frequency Limit

The *Starting current 623* is impressed in configurations 1xx, 4xx and 6xx for control in the selected configuration until the *Frequency limit 624* is reached. Permanent operating points below the frequency limit are only admissible if forced-ventilated motors are used.

The transition to the control method of the selected *configuration 30* takes place above the frequency limit.

The *Frequency limit 624* is set up automatically during the guided motor commissioning in field oriented control configurations 4xx and 6xx. In V/f control configurations 1xx the parameter *Frequency limit 624* is not changed by the guided motor commissioning.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
624	Frequency Limit	0.00 Hz	100.00 Hz	2.60 Hz

12.1.1.3 Brake release time

In order to protect the motor holding brake against damage, the motor may only start after the brake has been released. Startup to reference speed is affected only after the *Brake release time 625* has elapsed. The time should be set such that it is at least as long as the time required for releasing the holding brake. By using negative values for the parameter, release of the brake is delayed. This can be done in order to prevent loads from falling down, for example.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
625	Brake release time	-5000 ms	5000 ms	0 ms

12.1.2 Flux Formation

Field-oriented control in the configurations 2xx and 4xx are based on separate regulation of the flux-forming and torque-forming current components. Upon startup, the machine is magnetized and a current is impressed first. With the parameter *Current during flux formation* **781** the magnetization current I_{sd} is set, with the parameter *Maximum Flux-Formation Time* **780** the maximum time for the current impression is set.

The current impression is done until the reference value of the rated magnetizing current is reached or the *Maximum Flux-Formation Time* **780** is exceeded.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
780	Maximum Flux-Formation Time	1 ms	10000 ms	300 ms ¹⁾
				1000 ms ²⁾
				50 ms ³⁾
781	Current during flux formation	$0.1 \cdot I_{FUN}$	$\ddot{u} \cdot I_{FUN}$	I_{FUN}

The factory setting of parameter *Maximum Flux Formation Time* **780** depends on the setting of parameter *Configuration* **30**:

- ¹⁾- configurations 1xx
- ²⁾- configurations 2xx/4xx
- ³⁾- configurations 6xx

The magnetizing current changes according to the rotor time constant of the motor. By setting the parameters *Max. Flux-Formation Time* **780** and *Min. Flux-Formation Time* **779** a constant flux formation time can be achieved. With parameter *Min. Flux-Formation Time* **779** the minimum time for flux-forming current can be set. This enables a defined time between start signal and run-up of the drive. For an optimum setting of the parameters the rotor time constant, the required starting torque and *Current during Flux-Formation* **781** have to be considered.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
779	Min. Flux-Formation Time	1 ms	10000 ms	10 ms ¹⁾
				50 ms ²⁾

The factory setting of parameter *Min. Flux-Formation Time* **779** depends on the setting of parameter *Configuration* **30**:

- ²⁾- configurations 2xx/4xx
- ³⁾- configurations 6xx

<i>Min. Flux-Formation Time</i> 779 = 0	Flux-forming ends when – reference flux value is reached or – after flux-formation time
<i>Min. Flux-Formation Time</i> 779 > 0	The current for flux-forming is impressed at least for this time, even if the reference flux value is reached.
<i>Min. Flux-Formation Time</i> 779 = <i>Max. Flux-Formation Time</i> 780	Flux-forming ends after flux-formation time, even if the reference flux value is not reached.
<i>Min. Flux-Formation Time</i> 779 > <i>Max. Flux-Formation Time</i> 780	Flux-forming ends after maximum flux-formation time.

12.2 Stopping Behavior

The stopping behavior of the three-phase machine can be defined via parameter *Operation mode 630*. Via the logic signals or digital inputs for the parameters *Start clockwise 68* and *Start anticlockwise 69*, stopping is activated. Assign digital inputs or logic signals to these parameters. Dependent on the setting of *Configuration 30* the parameters are preset to digital inputs. By combining the digital input signals or logic signals the stopping behavior can be selected from the following table.

		Stopping Behavior							
		Start clockwise = 0 and Start anticlockwise = 0							
<i>Operation mode 630</i>		Stopping behavior 0	Stopping behavior 1	Stopping behavior 2	Stopping behavior 3	Stopping behavior 4	Stopping behavior 5	Stopping behavior 6	Stopping behavior 7
Start clockwise = 1 and Start anticlockwise = 1	Stopping behavior 0 (Free stopping)	0	1	2	3	4	5	6	7
	Stopping behavior 1 (Stop and Switch off)	10	11	12	13	14	15	16	17
	Stopping behavior 2 (Stop and Hold)	20	21	22	23	24	25	26	27
	Stopping behavior 3 (Stop and DC brakes)	30	31	32	33	34	35	36	37
	Stopping behavior 4 (Emergency Stop and Switch off)	40	41	42	43	44	45	46	47
	Stopping behavior 5 (Emergency Stop and Hold)	50	51	52	53	54	55	56	57
	Stopping behavior 6 (Emergency Stop and Brake)	60	61	62	63	64	65	66	67
	Stopping behavior 7 (DC brakes)	70	71	72	73	74	75	76	77

Operation mode 630 of the stopping behavior is to be parameterized according to the matrix. The selection of the operation modes can vary according to the control method and the available control inputs.

Example: The machine is to stop according to stopping behavior 2 if the digital logic signals *Start clockwise 68* = 0 and *Start anticlockwise 69* = 0.

Additionally, the machine is to stop according to stopping behavior 1 if the digital logic signals *Start clockwise 68* = 1 and *Start anticlockwise 69* = 1.

To achieve this, the parameter *Operation mode 630* must be set to 12.

By selecting the stopping behavior you also select the control of a mechanical brake if operation mode „41- Brake release“ is used for one digital output for controlling the brake.

Stopping Behavior	
Stopping behavior 0 Free stopping	The inverter is disabled immediately. The drive deenergized immediately and coasts freely.
Stopping behavior 1 Stop + Switch off	The drive is brought to a standstill at the set deceleration. As soon as the drive is at a standstill, the inverter is disabled after a after a holding time. The holding time can be set via the parameter <i>Holding time 638</i> . Depending on the setting of the parameter <i>Starting function 620</i> , the <i>Starting current 623</i> is impressed or the <i>Starting voltage 600</i> is applied for the duration of the holding time.
Stopping behavior 2 Stop + Hold	The drive is brought to a standstill at the set deceleration and remains permanently supplied with current. Depending on the setting of the parameter <i>Starting function 620</i> , the <i>Starting current 623</i> is impressed as from standstill or the <i>Starting voltage 600</i> is applied. In configurations 2xx the magnetizing current is used instead of the <i>Starting current 623</i> . The magnetizing current results from <i>Rated magnetizing current 716</i> and <i>Reduction Factor Flux 778</i> .
Stopping behavior 3 Stop + DC brakes	The drive is brought to a standstill at the set deceleration. As from standstill, the DC set via parameter <i>Braking current 631</i> is impressed for the <i>Braking time 632</i> . Comply with the notes in chapter "DC brake". Stopping behaviors 3, 6 and 7 are only available in the configurations for V/f sensor-less control (1xx).
Stopping behavior 4 Emergency stop + switch off	The drive is brought to a standstill at the emergency stop deceleration. As soon as the drive is at a standstill, the inverter is disabled after a after a holding time. The holding time can be set via the parameter <i>Holding time 638</i> . Depending on the setting of the parameter <i>Starting function 620</i> , the <i>Starting current 623</i> is impressed as from standstill or the <i>Starting voltage 600</i> is applied.
Stopping behavior 5 Emergency stop + Hold	The drive is brought to a standstill at the emergency stop deceleration and remains permanently supplied with current. Depending on the setting of the parameter <i>Starting function 620</i> , the <i>Starting current 623</i> is impressed as from standstill or the <i>Starting voltage 600</i> is applied.
Stopping behavior 6 Emergency stop + Brake	The drive is brought to a standstill at the set emergency stop deceleration. As from standstill, the DC set via parameter <i>Braking current 631</i> is impressed for the <i>Braking time 632</i> . Comply with the notes in chapter "DC brake". Stopping behaviors 3, 6 and 7 are only available in the configurations for V/f sensor-less control (1xx).
Stopping behavior 7 Direct current brake	Direct current braking is activated immediately. The direct current set with the parameter <i>Braking current 631</i> is impressed for the die <i>Braking time 632</i> . Comply with the notes in chapter "DC brake". Stopping behaviors 3, 6 and 7 are only available in the configurations for V/f sensor-less control (1xx).

Please refer to the notes for controlling a mechanical brake in chapter 15.3.5 Brake release.

For connection of a synchronous motor BONFIGLIOLI VECTRON recommends the setting of *Operation Mode 630* = 22.

12.2.1 Switch-Off Threshold

The *Switch-off threshold stop function 637* defines the frequency as from which a standstill of the drive is recognized. This percentage parameter value is relative to the set *Maximum frequency 419*.

The switch-off threshold is to be adjusted according to the load behavior of the drive and the device output, as the drive must be controlled to a speed below the switch-off threshold.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
637	Switch-off threshold	0.0 %	100.0 %	1.0 %

WARNING



If the motor builds up a stopping torque, it may be possible that the switch-off threshold stop function is not reached due to the slip frequency and the standstill of the drive is not recognized. In this case, increase the value of the *Switch-off threshold stop function 637*.

12.2.2 Holding Time

The *Holding time stop function 638* is considered in stopping behavior 1, 3, 4 and stopping behavior 6. Controlling to speed zero leads to a heating of the motor and should only be done for a short period in internally ventilated motors.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
638	Holding time stop function	0.0 s	200.0 s	1.0 s

12.3 Direct current brake

Stopping behaviors 3, 6, 7 and the search run function include the direct current brake. Depending on the setting of the stop function, a direct current is impressed into the motor either directly or, when it is at a standstill, after the demagnetization time. The impression of the *Braking current 631* results in the motor heating up and should only be done for a short period in the case of internally ventilated motors.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
631	Braking current	0.00 A	$\sqrt{2} \cdot I_{FIN}$	$\sqrt{2} \cdot I_{FIN}$

I_{FIN} = Nominal Output current of Frequency inverter

The setting of the parameter *Braking time 632* defines the time-controlled stopping behavior. Contact-controlled operation of the direct current brake is activated by entering the value zero for the *Braking time 632*.

Time controlled:

The direct current is controlled by the status of the signals Start clockwise and Start anticlockwise. The current set by the parameter *Braking current 631* flows until the time set by the parameter *Braking time 632* has expired.

For the duration of the braking time, the control signals Start clockwise and Start anticlockwise are logical 0 (Low) or 1 (High).

Contact-controlled:

If the parameter *Braking time* **632** is set to the value 0.0 s, the direct current brake is controlled by the Start clockwise and Start anticlockwise signals. The time monitoring and limitation by *Braking time* **632** are deactivated. The braking current will be impressed until the controller enable control signal (S1IND/STOA and S7IND/STOB) becomes logical 0 (low).

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
632	Braking time	0.0 s	200.0 s	10.0 s

To avoid current surges, which can possibly lead to a fault switch-off of the frequency inverter, a direct current may only be impressed into the motor after the motor has been demagnetized. As the demagnetization time depends on the motor used, it can be set with the parameter *Demagnetizing time* **633**.

The selected demagnetizing time should be approximately three times the *Act. Rotor Time Constant* **227**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
633	Demagnetizing time	0.1 s	30.0 s	5.0 s

The selected stopping behavior is supplemented by a current controller to control the direct current brake. The PI controller checks the current impression of the set *Braking current* **631**. The proportional and integrating parts of current controller can be adjusted via parameters *Amplification* **634** and *Integral time* **635**, respectively. The control functions can be deactivated by setting the parameters to 0.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
634	Amplification	0.00	10.00	1.00
635	Integral time	0 ms	1000 ms	50 ms

12.4 Auto Start



WARNING

Comply with standard EN 60204 and VDE provision 0100 part 227 and provision 0113, in particular Sections 5.4, protection against automatic restart after main line voltage failure and voltage recovery, and Section 5.5, undervoltage protection. Appropriate measures must be taken to exclude any risk for staff, machines and production goods.

In addition to that, all specific regulations relevant to the application as well all national directives are to be complied with.

The Auto Start function is suitable for applications which permit a start at mains voltage by their function. By activation of the auto-start function via parameter *Operation mode* **651**, the frequency inverter accelerates the drive after application of the mains voltage. The controller enabling signal and the start command are necessary according to the regulations. When the motor is switched on, it is accelerated according to the parameterization and the reference value signal.

<i>Operation mode</i> 651	Function
0 - Off	The drive is accelerated, after application of the mains voltage, as soon as the controller enabling signal and the start command are switched from stop to start (edge evaluation).
1 - Switched on	The drive is accelerated by the frequency inverter as soon as the mains voltage is applied (level evaluation).

12.5 Search Run

The synchronization to a rotating drive is necessary in applications which drive the motor by their behavior or in which the drive is still rotating after a fault switch-off. Via *Operation mode search run 645*, the motor speed is synchronized to the current motor speed without an "Overcurrent" fault message. After this, the motor is accelerated to the reference speed at the set acceleration. This synchronization function determines the current rotary frequency of the drive via a search run in operation modes 1 to 5.

The synchronization in operation modes 10 to 15 is accelerated by short test impulses. Rotary frequencies of up to 175 Hz are determined within 100 ms to 300 ms. For higher frequencies, a wrong frequency is determined and the synchronization fails. In the "Quick synchronization" operation modes, the search run cannot determine whether a synchronization attempt has failed.

For operation of a synchronous motor, the flux direction can be determined in order to prevent alignment of the motor shaft (jerking) during start-up. Determining the flux direction takes approx. 20 ms. In this process, there are short torque pulses. This method is not suitable for very dynamic drives since the torque pulses result in a rotation of the drive and consequently in wrong measurements. Once the flux direction was determined, the flux is formed (Parameter *Minimum flux-formation time 779*, *Maximum flux-formation time 780*, *Current during flux-formation 781*) in order to improve the starting behavior.

Operation mode 645	Function
0 - Off	The synchronization to a rotating drive is deactivated.
1 - Search Dir. acc. to Preset Val., DCB	The search direction is defined by the sign in front of the reference value. If a positive reference value (clockwise field of rotation) is entered, the search is in a positive direction (clockwise field of rotation), with a negative reference value, the search is in a negative direction (anticlockwise field of rotation).
2 - First clockw. then anticlockw., DCB	The first attempt is to synchronize to the drive in positive direction (clockwise field of rotation). If this attempt fails, it is tried to synchronize to the drive in negative direction (anticlockwise field of rotation).
3 - First anticlockw. then clockw., DCB	The first attempt is to synchronize to the drive in negative direction (anticlockwise field of rotation). If this attempt fails, it is tried to synchronize to the drive in positive direction (clockwise field of rotation).
4 - Clockw. only, DCB	Synchronization to the drive is only done in positive direction (clockwise field of rotation).
5 - Anticlockw. only, DCB	Synchronization to the drive is only done in negative direction (anticlockwise field of rotation).
10 - Quick Synchronization	An attempt is made to synchronize to the drive in positive direction (clockwise field of rotation) and in negative direction (anticlockwise field of rotation).
11 - Quick Synch. acc. to Preset Value	The search direction is defined by the sign in front of the reference value. If a positive reference value (clockwise field of rotation) is entered, the search is in a positive direction (clockwise field of rotation), with a negative reference value, the search is in a negative direction (anticlockwise field of rotation).
14 - Quick synch., clockw. only	Synchronization to the drive is only done in positive direction (clockwise field of rotation).
15 - Quick synch., anticlockw. only	Synchronization to the drive is only done in negative direction (anticlockwise field of rotation).

Operation modes 1, 4 and 5 define a direction of rotation for the search run and avoid a deviating direction. The search run can accelerate drives by checking the rotary frequency if the drives have a low moment of inertia and/or a small load mo-

ment.

In operation modes 10 to 15, it cannot be ruled out that a wrong direction of rotation is determined in quick synchronization. For example, a frequency not equal to zero may be determined although the drive is at a standstill. If there is no overcurrent, the drive is accelerated accordingly. The direction of rotation is defined in operation modes 11, 14 and 15.

The synchronization changes the parameterized starting behavior of the selected configuration. First, the start command activates the search run in order to determine the rotary frequency of the drive. In operation modes 1 to 5, the *Current / Rated motor current* **647** is used for synchronization as a percentage of the *Rated current* **371**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
647	Current / Rated Motor Current	1.00 %	100.00 %	70.00 %

The sensor-less control is extended for the search run by a PI-Controller, which regulates the parameterized *Current / Rated Motor Current* **647**. The proportional and integrating part of the current controller can be set via the parameters *Amplification* **648** and *Integral Time* **649**. The control functions can be deactivated by setting the parameters to 0.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
648	Amplification	0.00	10.00	1.00
649	Integral time	0 ms	1000 ms	20 ms

If the *Operation mode Synchronization* **645** parameter was set to operation mode 1 to 5 (search run), the search run is not started before the *Demagnetization time* **633** has elapsed.

If synchronization to the drive mechanism is not possible, the *Braking current* **631** is impressed into the motor in operation modes 1 to 5 for the duration of the *Braking time after search run* **646**. The impress of the direct current set in the parameters of the direct current brake (DCB) leads to a heating of the motor and should only be done for a short period in internally ventilated motors.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
646	Brak. time after search run	0.0 s	200.0 s	10.0 s

NOTE

The Flying Start (or Search) function is designed for the operation of motors without brake. Brake motors may not be operated optimum in individual cases (depending of parameterization and brake control) with the Flying start function.

12.6 Positioning

Positioning is done in operation mode "Reference positioning" via the definition of the positioning distance or in operation mode "Axle positioning" via the definition of the position angle.

Reference positioning uses a digital reference signal from a selectable signal source for positioning the drive independent of the speed.

Axle positioning uses a digital reference signal from a speed sensor.

The function "Reference positioning" is available in configurations 110, 210, 410, 510 and 610 and is activated by selecting operation mode 1 for parameter *Operation mode* **458**.

The function "Axle positioning" is available in configurations 210 and 510 (Parameter *Configuration* **30**) and is activated by selecting operation mode 2 for parameter *Operation mode* **458**.

<i>Operation mode</i> 458	Function
0 - Off	Positioning switched off.
1 - Reference positioning	Positioning from reference point via definition of positioning distance (rotations). The reference point is acquired via a <i>Signal Source</i> 459 . Available in Configuration: 110, 210, 410, 510, 610.
2 - Axle positioning	Reference positioning via definition of the positioning angle, reference signal from speed sensor. Available in Configuration: 210, 510.

12.6.1 Reference Positioning

The feedback of the current position is referred to the revolutions of the motors relative to the time of the reference signal. The accuracy of the positioning for the application to be realized is dependent on the current *Actual frequency* **241**, the *deceleration (clockwise)* **421**, the *No. of pole pairs* **373**, the selected *Positioning distance* **460** and the parameterized control behavior.

The distance between the reference point and the required position is to be defined in motor revolutions. The calculation of the distance covered is done with the selected *Positioning distance* **460** according to the application.

The setting 0.000 U for the *Positioning distance* **460** causes an immediate stop of the drive according to the selected stopping behavior for *Operation mode* **630**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
460	Positioning distance	0.000 U	1000 000.000 U	0.000 U

The actual value parameter *Revolutions* **470** facilitates the setting and optimization of the function. The revolutions of the motor displayed should correspond to the *Positioning distance* **460** at the required position.

The minimum number of revolutions needed until the required position is reached depends on the *Actual frequency* **241** and *Deceleration (clockwise)* **421** (or *Deceleration anticlockwise* **423**) as well as the *No. of pole pairs* **373** of the motor.

$$U_{\min} = \frac{f^2}{2 \cdot a \cdot p}$$

U_{\min} = min. number of rotations
 f = *Actual frequency* **241**
 a = *Deceleration* **421** (**423**)
 p = *No. of pole pairs* **373** of motor

Example: $f = 20 \text{ Hz}$, $a = 5 \text{ Hz/s}$, $p = 2 \Rightarrow \text{rpm} = 20$

With an actual frequency of 20 Hz and a delay of 5 Hz/s, at least 20 rotations are needed until standstill at the required position. This is the minimum value for the *Positioning distance* **460**; a shorter positioning distance is not possible. If the number of rotations until the required position is reached is to be lower, the frequency must be reduced, the deceleration increased, or the reference point must be shifted.

The digital signal for registration of the reference point and the logical assignment are to be chosen from a selection of *Signal source* **459**. The link of the digital inputs S2IND, S3IND and S6IND to further functions is to be checked according to selected *Configuration* **30** (e.g., in configurations 110 and 210, digital input S2IND is linked to the function "Start of clockwise operation").

The signals for positioning and a stopping behavior should not be assigned to the same digital input.

<i>Signal source</i> 459	Function
2 - S2IND, neg. edge	The positioning starts with the change of the logic signal from 1 (HIGH) to 0 (LOW) at the reference point.
3 - S3IND, neg. edge	
6 - S6IND, neg. edge	
1x - SxIND, pos. edge	The positioning starts with the change of the logic signal from 0 (LOW) to 1 (HIGH)
2x - SxIND, pos./neg. edge	The positioning begins with the change of the logic signal

The registration of the reference position via a digital signal can be influenced by a variable dead time while the control command is read and processed. The signal running time is compensated by a positive figure for the *Signal correction* **461**. The setting of a negative signal correction decelerates the processing of the digital signal.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
461	Signal correction	-327.68 ms	+327.67 ms	0.00 ms

The influences on the positioning which depend on the operating point can be corrected empirically via the *Load correction* **462** parameter. If the required position is not reached, the deceleration duration is increased by a positive load correction value. The distance between the reference point and the required position is extended. Negative values accelerate the braking process and reduce the positioning distance. The limit of the negative signal correction results from the application and the *Positioning distance* **460**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
462	Load correction	-32768	+32767	0

The behavior of the positioning after the required position of the drive is reached can be defined via the *Activity after positioning* **463** parameter.

<i>Activity after positioning</i> 463	Function
0 - End positioning	The drive is stopped with the stopping behavior of <i>Operation mode</i> 630 .
1 - Wait for positioning signal	The drive is stopped until the next signal edge; with a new edge of the position signal, it is accelerated in the previous direction of rotation.
2 - Reversal by new edge	The drive is held until the next signal edge; with a new edge of the position signal, it is accelerated in the opposite direction of rotation.
3 - Positioning; off	The drive is stopped and the power output stage of the inverter is switched off.
4 - Start by time control	The drive is stopped for the <i>Waiting time</i> 464 ; after the waiting time, it is accelerated in the previous direction of rotation.
5 - Reversal by time control	The drive is held for the <i>Waiting time</i> 464 ; after the waiting time, it is accelerated in the opposite direction of rotation.


The position reached can be maintained for the *Waiting time* **464**, then the drive is accelerated according to operation mode 4 or 5.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
464	Waiting time	0 ms	3600,000 ms	0 ms

Positioning, Operation Mode 458 = 1

The diagram shows how the positioning to the set positioning distance is affected. The positioning distance remains constant at different frequency values. At the reference point, the position signal S_{Posi} is generated. Starting from frequency f_{max} , the positioning is affected at the set *Deceleration (clockwise)* **421**. At a lower frequency value f_1 , the frequency remains constant for some time before the drive is stopped at the set deceleration.

If, during acceleration or deceleration of the machine, positioning is started by the signal S_{Posi} , the frequency at the time of the positioning signal is maintained.



Examples of reference positioning as a function of the parameter settings selected.

- The reference point is registered according to the *Signal sources* **459** parameter in operation mode 16–S6IND, pos. edge by a signal on digital input 6.
- The *Positioning distance* **460** with parameter value 0.000U (default) defines a direct stop of the drive with the deceleration behavior selected in parameter *Operation mode* **630** and the selected *Deceleration (clockwise)* **421**. If a *Positioning distance* **460** is set, the positioning is affected at the set deceleration.
- The *Signal correction* **461** of the signal run time from the measurement point to the frequency inverter is not used if it is set to 0ms.
- The *Load correction* **462** can compensate a faulty positioning by the load behavior. By default, this function is deactivated, i.e. set to 0.
- The *Activity after positioning* **463** is defined by operation mode 0–End of positioning.
- The *Waiting time* **464** is not considered because operation mode 0 is selected for the parameter *Action after positioning* **463**.
- The actual value *Revolutions* **470** enables a direct comparison to the required *Positioning distance* **460**. In the case of deviations, a *Signal correction* **461** or *Load correction* **462** can be carried out.

12.6.2 Axle Positioning

For axle positioning a feedback system is mandatory. In most cases, an expansion module for the feedback evaluation is needed as well. The operation modes for parameter *Operation mode Speed sensor 2* **493** are to be set to 1004 or 1104. For information on how to set the parameter, refer to the instructions on the optional expansion module. The positioning is started if a start signal is received and the frequency drops below an adjustable frequency limit. The machine stops with the selected stopping behavior at the entered position angle.

To ensure the correct function of the axle positioning, the speed controller should be optimized after the guided commissioning. This is described in the chapter "Speed controller".

Via the parameter *Reference orientation* **469**, the angle between the reference point and the required position is entered.

If this value is changed while the machine is at a standstill, the positioning operation is carried out again at a frequency of 0.5 Hz. For this, a stopping behavior must be selected for the parameter *Operation mode* **630** which impresses a starting current either permanently when the drive is at a standstill or for the stopping time (refer to chapter „Stopping Behavior“).

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
469	Reference orientation	0.0°	359.9°	0.0°

CAUTION

During the positioning operation, the direction of rotation of the drive may change, regardless of whether the command Start clockwise or Start anticlockwise was activated.
Make sure that the change of the direction of rotation cannot result in any personal or material damage.



The positioning is started by a start command from a signal source (e.g. digital input) which must be assigned to the parameter *Start Positioning of Axle 37*. The signal source can be selected from the operation modes for digital inputs described in chapter "Digital inputs".

The positioning starts on condition that the *Actual frequency 241* of the output signal is smaller than the value entered in parameter *Positioning frequency 471*. Due to a stopping behavior, the actual frequency drops below the positioning frequency.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
471	Positioning frequency	1.00 Hz	50.00 Hz	50.00 Hz

Via the parameter *Max. positional error 472*, the maximum permissible deviation from the *Reference orientation 469* can be set.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
472	Max. positional error	0.1°	90.0°	3.0°

Via parameter *Time constant positioning controller 479*, the time constant for controlling the positional error can be set. The value of the time constant should be increased if oscillations of the drive around the reference orientation occur during the positioning.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
479	time constant positioning contr.	1.00 ms	9999.99 ms	20.00 ms

To make sure that the set position is maintained if a load torque is applied, a stopping behavior should be selected for parameter *Operation mode 630* which impresses a starting current either permanently when the drive is at a standstill or for the stopping time.

The status message "60 - Target Position Reached" which is displayed when the reference orientation is reached can be assigned to a digital output. The message is output on the following conditions:

- Operation mode 2 (axle positioning) for parameter *Operation mode 458* is selected.
- The controller enable signal at digital inputs S1IND/STOA and S7IND/STOB is switched on.
- *Start Positioning of Axle 37* is activated.
- The speed sensor monitoring is activated, i.e. operation mode 2 (error message) for parameter *Operation mode 760* of the speed sensor monitoring is selected.
- Operation mode 1004 or 1104 (quadruple evaluation with reference impulse) is selected for the speed sensor input.
- The *actual frequency 241* is smaller than 1 Hz.
- The deviation of the current position from the reference orientation is smaller than the *max. orientation error 472*.

The current position after *Start Positioning of Axle 37* is recognized by the frequency inverter as follows:

- During commissioning, after switching on the frequency inverter, a search mode is performed for 3 rotations at a rotational frequency of 1 Hz in order to detect the reference signal. As soon as the reference signal was recognized twice, the drive is positioned to the *Reference orientation 469*.
When using a Resolver, the search mode during commissioning is skipped.
- If the motor was already rotating before axle positioning was enabled, the positioning to the *Reference orientation 469* is performed without search mode because the position of the reference point was already detected by the frequency inverter.

If the positioning is carried out, after controller enabling and start command, when the motor is at a **standstill**:

- The motor is positioned clockwise to the reference orientation if the value for the reference orientation is higher than the value adjusted before.
- The motor is positioned anticlockwise to the reference orientation if the value for the reference orientation is smaller than the value adjusted before.

The sense of rotation during the positioning is independent of whether Start Clockwise or Start Anticlockwise was activated.

The time required until the reference orientation is reached depends on:

- Actual frequency
- Frequency ramp for deceleration
- Rotational angle to reference orientation
- Max. positional error
- Time constant positioning contr.

13 Error and warning behavior

Operation of the frequency inverter and the connected load are monitored continuously. The monitoring functions are to be parameterized with the corresponding limit values specific to the application. If the limits were set below the switch-off limit of the frequency inverter, a fault switch-off can be prevented by suitable measures if a warning message is issued.

The warning message is displayed by the LED's and can be read out on the operating unit via parameter *Warnings 269* or output via one of the digital control outputs.

13.1 Overload Ixt

The admissible load behavior depends on various technical data of the frequency inverters and the ambient conditions.

The selected *Switching frequency* **400** defines the rated current and the available overload for one second and sixty seconds, respectively. The *Warning Limit Short Term Ixt* **405** and *Warning Limit Long Term Ixt* **406** are to be parameterized accordingly.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
405	Warning Limit Short Term Ixt	6 %	100 %	80 %
406	Warning Limit Long Term Ixt	6 %	100 %	80 %

Exceeding of warning limit is signaled by 165 - Warning Ixt".

Output signals

Digital signals indicate the attainment of warning limits.

165 -	Warning Ixt	¹⁾	<i>Warning Limit Short Term Ixt</i> 405 or <i>Warning Limit</i>
7 -	Ixt-Warning	²⁾	<i>Long Term Ixt</i> 406 is attained.

¹⁾ For linking with inverter functions

²⁾ For digital output

13.2 Temperature

The ambient conditions and the energy dissipation at the current operating point result in the frequency inverter heating up. In order to avoid a fault switch-off of the frequency inverter, the *Warning Limit Heat Sink Temp.* **407** for the heat sink temperature limit and the *Warning Limit Inside Temp.* **408** as an internal temperature limit are to be parameterized. The temperature value at which a warning message is output is calculated from the type-dependent temperature limit minus the adjusted warning limit.

The switch-off limit of the frequency inverter for the maximum temperature is an internal temperature of 65 °C and a heat sink temperature of 80 °C – 90 °C.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
407	Warning Limit Heat Sink Temp.	-25 °C	0 °C	-5 °C
408	Warning Limit Inside Temp.	-25 °C	0 °C	-5 °C



Minimum temperatures are defined as -10 °C (interior) and 30 °C (heat sink temperature).

Output signals

Digital signals indicate the attainment of warning limits.

166 -	Warning Heat Sink	¹⁾	The value "80 °C minus <i>Warning Limit Heat Sink</i>
8 -	Temperature	²⁾	<i>Temp.</i> 407 " is attained.
167 -	Warning Inside	¹⁾	The value "65 °C minus <i>Warning Limit Inside Temp.</i>
9 -	Temperature	²⁾	408 " is attained.
170 -	Warning Over-temperature	¹⁾	The value
12 -		²⁾	– "80 °C minus <i>Warning Limit Heat Sink Temp.</i> 407 " or – "65 °C minus <i>Warning Limit Inside Temp.</i> 408 " is attained.

¹⁾ For linking with inverter functions

²⁾ For digital output

13.3 Controller status

The intervention of a controller can be indicated via the control unit or LED's. The selected control methods and the matching monitoring functions prevent a switch-off of the frequency inverter. The intervention of the function changes the operating behavior of the application and can be displayed by the status messages with parameter *Controller status* **275**. The limit values and events which result in the intervention by the corresponding controller are described in the corresponding chapters. The behavior during the intervention of a controller is configured with the parameter *Controller status message* **409**.

Operation mode 409	Function
0 - No message	The intervention of a controller is not reported. The controllers influencing the operating behavior are displayed in the <i>Controller status</i> 275 parameter.
1 - Warning Status	The limitation by a controller is displayed as a warning by the control unit.
11 - Warning status and LED	The limitation by a controller is displayed as a warning by the control unit and the LED's.

Refer to chapter 15.3.8 Warning Mask and 21.3 Controller Status for a list of controllers and further possibilities to evaluate the controller states.

13.4 IDC Compensation Limit

At the output of the frequency inverter a DC component can occur in the output current due to unbalances. This DC voltage component can be compensated by the frequency inverter. The maximum output voltage of the compensation is set with parameter *IDC compensation limit* **415**. If a higher voltage than the set limit is needed for the compensation of a DC voltage component, error "F1301 IDC COMPENSATION" is triggered.

If this fault occurs, it should be checked whether the load is defective. The voltage limit may have to be increased.

If the parameter *IDC compensation limit* **415** is reduced to zero, the DC compensation is deactivated.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
415	IDC Compensation Limit	0.0 V	1.5 V	1.5 ¹⁾
				0.0 ²⁾

The factory setting of parameter *Limit IDC compensation* **415** depends on the setting of parameter *Configuration* **30**:

¹⁾ Configurations 1xx

²⁾ Configurations 2xx / 4xx / 5xx / 6xx

13.5 Frequency Switch-Off Limit

The maximum allowed output frequency of the frequency inverter can be set with the parameter *Frequency switch-off limit* **417**. If this frequency limit is exceeded by the *Stator frequency* **210** or *Actual frequency* **241**, the frequency inverter switches off with fault message "F1100".

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
417	Frequency Switch-Off Limit	0.00 Hz	999.99 Hz	999.99 Hz

13.6 Motor Temperature

The configuration of the control terminals includes the monitoring of the motor temperature. The monitoring function can be parameterized specific to the application via the parameter *Motor Temp. Operation Mode* **570**. The integration into the application is improved by an operating mode with a delayed switch-off.

Operation mode 570		Function
0 - Off		Motor temperature monitoring switched off.
1 - Therm.-Cont.: Warning only		The critical point of operation is displayed by the control unit and parameter <i>Warnings</i> 269 .
2 - Error Switch-Off		The fault switch-off is displayed by message F0400. The fault switch-off can be acknowledged via the control unit or the digital input.
3 - Error Switch-Off 1 min del.		The fault switch-off according to operation mode 2 is delayed by one minute.
4 - Error Switch-Off 5 min del.		The fault switch-off according to operation mode 2 is delayed by five minutes.
5 - Error Switch-Off 10 min del.		The fault switch-off according to operation mode 2 is delayed by ten minutes.

Output signals

Warnings are displayed in parameter *Warnings* **269** and indicated via digital signals.

168 -	Warning Motor Temperature	1)	Monitoring – selected via <i>Motor Temp.</i>
10 -		2)	<i>Operation Mode</i> 570 – signalizes a critical point of operation.

1) For linking with inverter functions

2) For digital output

If the temperature value *max.Temp. Windings* **617*** is exceeded a warning or an error switch-off is initiated according to *Motor Temp. Operation Mode* **570**.

Parameter		Setting		
No.	Description	Min.	Max.	Fact. sett.
617	max.Temp. Windings*	50 °C	200 °C	150 °C

* The parameter is only available if an expansion module with KTY temperature sensor input is installed, e.g. EM-IO-04.

Via parameter *Therm. Contact* **204**, a digital input signal can be linked to the *Motor Temp. Operation Mode* **570**.

13.7 Phase Failure

A failure of one of the three motor or mains can lead to a damage in the frequency inverter, the motor and the mechanical drive components. To prevent damage to these components, the phase failure is monitored. Parameter *Phase supervision* **576** allows to adjust the behavior in case of a failure.

<i>Phase Supervision</i> 576	Function
10 - Mains Error Switch-Off	In the case of a phase failure, the fault switch-off takes place after 5 minutes, fault F0703 is displayed. During this time, the warning message A0100 is displayed.
11 - Mains & Motor Error Switch-Off	The phase monitor switches the frequency inverter off: <ul style="list-style-type: none"> – immediately with error message F0403 in the case of a motor phase failure, – after 5 minutes with error message F0703 in the case of a mains phase failure.
20 - Mains Shutdown	In the case of a mains phase failure, the drive is stopped after five minutes, fault F0703 is displayed.
21 - Mains & Motor Shutdown	The drive is stopped: <ul style="list-style-type: none"> – immediately, in the case of a motor phase failure, – after 5 minutes in the case of a mains phase failure.

13.8 Automatic Error Acknowledgment

The automatic error acknowledgment enables acknowledgment of the faults Overcurrent F0500, Overcurrent F0507 and Overvoltage F0700 without intervention by an overriding control system or the user. If one of the aforementioned errors occurs, the frequency inverter switches the power semi-conductors off and waits for the time stated with the parameter *Restart delay* **579**. If the error must be acknowledged, the speed of the machine is determined with the quick Search Run function and synchronized to the rotating machine. The automatic error acknowledgment makes use of "Quick Synchronization" operation mode, regardless of the *Search run operation mode* **645**. The information given on this function in chapter "Search run" must be observed.

With parameter *Allowed no. of auto-acknowl.* **578**, you can define the number of automatic error acknowledgements which are permitted within 10 minutes.

An acknowledgement repeated above the permissible number within 10 minutes will result in the frequency inverter being switched off.

The errors Overcurrent F0500, Overcurrent F0507 and Overvoltage F0700 have separate error acknowledgement counters.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
578	Allowed no. of auto-acknowl.	0	20	5
579	Restart delay	0 ms	1000 ms	20 ms

14 Reference Values

The ACU series frequency inverters can be configured specific to the application and enable customer-specific adaptation of the module hardware and software structure.

14.1 Frequency Limits

The output frequency of the frequency inverter and thus the speed setting range are defined by the parameters *Minimum frequency 418* and *Maximum frequency 419*. The corresponding control methods use the two limit values for scaling and calculating the frequency.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
418	Minimum Frequency	0.00 Hz	999.99 Hz	3.50 Hz ¹⁾
				0.00 Hz ²⁾
419	Maximum Frequency	0.00 Hz	999.99 Hz	50.00 Hz

The factory setting is dependent on the adjustment of parameter *Configuration 30*:

¹⁾ 3.5 Hz in configurations 1xx, 4xx, 6xx

²⁾ 0.00 Hz in configurations 2xx, 5xx

14.2 Slip Frequency

The torque-forming current component and thus the slip frequency of the 3-phase machine depend on the required torque in the case of the field-oriented control methods. The field-oriented control method also includes the parameter *Slip frequency 719* to limit the torque in the calculation of the machine model. The rated slip calculated from the rated motor parameters is limited in accordance with the *Slip frequency 719* which is parameterized as a percentage.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
719	Slip Frequency	0 %	10000 %	330 %

14.3 Percentage Value Limits

The setting range of the percentages is defined by the parameters *Minimum reference percentage 518* and *Maximum reference percentage 519*. The relevant control methods use the two limit values for scaling and calculating the frequency.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
518	Minimum Reference Percentage	0.00 %	300.00 %	0.00 %
519	Maximum Reference Percentage	0.00 %	300.00 %	100.00 %

14.4 Frequency reference channel

The different functions for the defining the reference frequency are connected via the frequency reference value channel. The *Reference frequency source 475* determines the additive assignment of the available reference value sources depending on the hardware installed.

Reference frequency source 475	Function
1 - Abs. value analog value MF11A	Reference value source is the multifunctional input 1 in analog <i>Operation mode 452</i> .
2 - Abs. Analog Value EM-S11NA	Reference value source is the analog input of the expansion module.
4 - Abs. Value MF11A + EM-S11NA	Combination of the operation modes 2 and 1.
10 - Abs. value fixed frequency (FF)	The fixed frequency according to the <i>Fixed frequency change-over 1 66</i> and <i>Fixed frequency change-over 2 67</i> as well as the current data set.
11 - Abs. value MF11A + FF	Combination of the operation modes 10 and 1.
12 - Abs. Value EM-S11NA + FF	Combination of the operation modes 10 and 2.
14 - Abs. Value MF11A + EM-S11NA + FF	Combination of the operation modes 10, 1 and 2.
20 - Abs. value Motorpoti (MP)	Reference value source is the function <i>Frequency Motorpoti Up 62</i> and <i>Frequency Motorpoti Down 63</i> .
21 - Abs. value MF11A + MP	Combination of the operation modes 20 and 1.
22 - Abs. Value EM-S11NA + MP	Combination of the operation modes 20 and 2.
24 - Abs. Value MF11A + EM-S11NA + MP	Combination of the operation modes 20, 1 and 2.
30 - Abs.Val. Speed Sensor 1 (F1)	The frequency signals in <i>Operation mode 490</i> are evaluated as a reference value.
31 - Abs. value MF11A + F1	Combination of the operation modes 30 and 1.
32 - Abs. value repetition freq./PWM input (F3)	The frequency signal on the digital input according to <i>Operation mode 496</i> for the PWM-/ repetition frequency input.
33 - Abs. value MF11A + F3	Combination of operation modes 1 and 32.
34 - Abs.Val. Speed Sensor 2 (F2)	The frequency signals in <i>Operation mode 490</i> are evaluated as a reference value.
35 - Abs. Value MF11A + F2	Combination of operation modes 1 and 34.
40 - Abs. value Motorpoti (KP)	KP 500 is the reference value source, with keys ▲ for increasing the frequency and ▼ for reducing the frequency.
41 - Abs. value MF11A + KP	Combination of operation modes 40 and 1.
42 - Abs. Value EM-S11NA + KP	Combination of operation modes 40 and 2.
44 - Abs. Value MF11A + EM-S11NA + KP	Combination of operation modes 40, 1 and 2.
80 - Abs. value MF11A + FF + KP + F3 + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 40, 32 and 2. ¹⁾
81 - Abs. value MF11A + FF + KP + F1 + F3 + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 40, 30, 32 and 2. ¹⁾
82 - Abs. value MF11A + FF + KP + F3 + (F2) ²⁾ + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 40, 32, 34 ²⁾ and 2. ¹⁾
89 - Abs. value MF11A + FF + KP + F1 + F3 + (F2) ²⁾ + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 40, 30, 32, 34 ²⁾ and 2. ¹⁾
90 - Abs. value MF11A + FF + MP + F3 + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 20, 32 and 2. ¹⁾
91 - Abs. value MF11A + FF + MP + F1 + F3 + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 20, 30, 32 and 2. ¹⁾
92 - Abs. value MF11A + FF + MP + F3 + (F2) ²⁾ + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 20, 32, 34 ²⁾ and 2. ¹⁾
99 - Abs. value MF11A + FF + MP + F1 + F3 + (F2) ²⁾ + (EM-S11NA) ¹⁾	Combination of the operation modes 1, 10, 20, 30, 32, 34 ²⁾ and 2. ¹⁾
101 to 199	Operation modes with signs (+/-)

¹⁾ The reference value source is only available if an expansion module with analog input is connected. For information, refer to the expansion module operating instructions.


²⁾ The reference value source is only available if an expansion module with speed sensor input is connected. For information, refer to the expansion module operating instructions.

14.4.1 Block diagram

The following table describes the software switches shown in the circuit diagram as a function of the selected *Frequency reference value source* **475**.

Switch position on circuit diagram									
Operation mode	MF11A	FF	MP	F1	F3	KP	EM-S11NA	F2	Signal
1	1								Abs. value
10		1							Abs. value
11	1	1							Abs. value
12		1					1		Abs. value
14	1	1					1		Abs. value
20			1						Abs. value
21	1		1						Abs. value
22			1				1		Abs. value
24	1		1				1		Abs. value
30				1					Abs. value
31	1			1					Abs. value
32					1				Abs. value
33	1				1				Abs. value
34								1	Abs. value
35	1							1	Abs. value
40						1			Abs. value
41	1					1			Abs. value
42						1	1		Abs. value
44	1					1	1		Abs. value
80	1	1			1	1	1		Abs. value
81	1	1		1	1	1	1		Abs. value
82	1	1			1	1	1	1	Abs. value
89	1	1		1	1	1	1	1	Abs. value
90	1	1	1		1		1		Abs. value
91	1	1	1	1	1		1		Abs. value
92	1	1	1		1		1	1	Abs. value
99	1	1	1	1	1		1	1	Abs. value
101...199	Operation modes 1...99 with signs (+/-).								+/-

Circuit diagram of frequency reference value channel



14.5 Reference percentage channel

The reference percentage channel combines various signal sources for definition of the reference figures. The percentage scaling facilitates integration into the application, taking various process parameters into account.

The *Reference Percentage Source 476* determines the additive assignment of the available reference value sources depending on the hardware installed.

Reference Percentage Source 476		Function
1 -	Abs. value analog value MFI1A	Reference value source is the multifunctional input 1 in analog <i>Operation mode 452</i> .
2 -	Abs. Analog Value EM-S1INA ¹⁾	Reference value source is the Analog value of EM-S1INA.
4 -	Abs. Value MFI1A + EM-S1INA ¹⁾	Combination of the operation modes 1 and 2.
10 -	Abs. value fixed percentage value (FP)	The percentage according to <i>Fixed percent change-over 1 75</i> , <i>Fixed percent change-over 2 76</i> and the current data set.
11 -	Abs. value MFI1A + FP	Combination of the operation modes 1 and 10.
12 -	Abs. Value EM-S1INA + FP ¹⁾	Combination of the operation modes 2 and 10.
14 -	Abs. Value MFI1A + EM-S1INA + FP ¹⁾	Combination of the operation modes 1, 2 and 10.
20 -	Abs. value Motorpoti (MP)	Reference value source is the function <i>Percent Motorpoti Up 72</i> and <i>Percent Motorpoti Down 73</i> .
21 -	Abs. value MFI1A + MP	Combination of the operation modes 1 and 20.
22 -	Abs. Value EM-S1INA + MP ¹⁾	Combination of the operation modes 2 and 20.
24 -	Abs. Value MFI1A + EM-S1INA + MP ¹⁾	Combination of the operation modes 1,2 and 20.
32 -	Abs. Val. Rep. Freq./PWM Input (F3)	The frequency signal on the digital input according to <i>Operation mode 496</i> for the PWM-/repetition frequency input.
33 -	Abs. value MFI1A + F3	Combination of the operation modes 1 and 32.
90 -	Abs. value MFI1A + FP + MP + F3 (+ EM-S1INA) ¹⁾	Combination of the operation modes 1, 10, 20, 32(+ analog input of an expansion module). ¹⁾
95 -	Abs. Value Obj 0x6071 Target Torque	Reference value source is CANopen Object 0x6071.
96 -	Abs. Value Profibus OUT-PZD3	Reference value source is Profibus OUT-PZD3.
99 -	Abs. Val. FT-Output Percentage 1	Reference value source is the output of the function table FT-Output percentage 1.
101 to 199		Operation modes with signs (+/-).


¹⁾ The reference value source is only available if an optional expansion module with analog input is connected. For information, refer to the expansion module operating instructions.

14.5.1 Block diagram

The following table describes the software switches shown in the circuit diagram as a function of the selected *Reference percentage source 476*.

Switch position on circuit diagram						
Operation mode	MFI1A	FP	MP	F3	EM-S11NA	Sign
1	1					Abs. value
2					1	Abs. value
4	1				1	Abs. value
10		1				Abs. value
11	1	1				Abs. value
12		1			1	Abs. value
14	1	1			1	Abs. value
20			1			Abs. value
21	1		1			Abs. value
22			1		1	Abs. value
24	1		1		1	Abs. value
32				1		Abs. value
33	1			1		Abs. value
90	1	1	1	1		Abs. value
95	CANopen Object 0x6071					Abs. value
96	Profibus OUT-PZD3					Abs. value
99	Output of FT output Percentage 1					Abs. value
101...199	Operation modes 1...99 with signs (+/-)					+/-

Circuit diagram of percent reference value channel



14.6 Fixed reference values

The fixed reference values are to be parameterized as fixed frequencies or fixed percentages according to the configuration and function.

The signs of the fixed reference values determine the direction of rotation. A positive sign means a clockwise rotation; a negative sign means an anticlockwise rotation. The direction can only be changed via the sign if the *Reference frequency source 475* or *Reference percentage source 476* is parameterized to an operation mode with sign (+/-). The direction of rotation can also be stated with the digital signal sources assigned to the parameters *Start clockwise 68* and *Start anticlockwise 69*.

The fixed reference values are to be parameterized in four data sets and are assigned to further sources via the reference value channel. The use of the functions *Data set change-over 1 70* and *Data set change-over 2 71* thus enables the setting of 16 fixed reference values.

14.6.1 Fixed Frequencies

The four fixed frequencies define reference values which are selected via the *Fixed frequency change-over 1 66* and *Fixed frequency change-over 2 67*. The *Reference frequency source 475* defines the addition of the various sources in the reference frequency channel.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
480	Fixed frequency 1	-999.99 Hz	999.99 Hz	0.00 Hz
481	Fixed frequency 2	-999.99 Hz	999.99 Hz	10.00 Hz
482	Fixed frequency 3	-999.99 Hz	999.99 Hz	25.00 Hz
483	Fixed frequency 4	-999.99 Hz	999.99 Hz	50.00 Hz

By combining the logic states of the fixed frequency change-over modes 1 and 2, fixed frequencies 1 through 4 can be selected:

Selection of fixed frequencies		
<i>Fixed frequency change-over 1 66</i>	<i>Fixed frequency change-over 2 67</i>	Function / active fixed value
0	0	<i>Fixed frequency 1 480</i>
1	0	<i>Fixed frequency 2 481</i>
1	1	<i>Fixed frequency 3 482</i>
0	1	<i>Fixed frequency 4 483</i>

0 = contact open 1 = contact closed



If an optional expansion module with digital inputs is installed additional fixed frequencies can be selected. In this case refer to the instruction manual of the expansion module.

14.6.2 JOG frequency

The JOG function forms part of the functions for controlling the drive mechanism via the control unit. Use the arrow keys to change the JOG frequency within the function. The frequency of the output signal is set to the entered value if the FUN key is pressed. The drive starts and the machine turns at the set *JOG frequency* **489**. If the JOG frequency has been changed using the arrow keys, this value is stored.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
489	JOG frequency	-999.99 Hz	999.99 Hz	5.00 Hz

14.6.3 Fixed Percentages

The four percentage values define reference values which are selected via the *Fixed percent change-over 1* **75** and *Fixed percent change-over 2* **76**. The *Reference percentage source* **476** defines the addition of the various sources in the reference percentage channel.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
520	Fixed percentage 1	-300.00 %	300.00 %	0.00 %
521	Fixed percentage 2	-300.00 %	300.00 %	20.00 %
522	Fixed percentage 3	-300.00 %	300.00 %	50.00 %
523	Fixed percentage 4	-300.00 %	300.00 %	100.00 %

By combining the logic states of the fixed percentage change-over modes 1 and 2, fixed frequencies 1 through 4 can be selected:

Fixed Percentage Control		
<i>Fixed percentage change-over 1</i> 75	<i>Fixed percentage change-over 2</i> 76	Function / active fixed value
0	0	<i>Fixed Percentage 1</i> 520
1	0	<i>Fixed Percentage 2</i> 521
1	1	<i>Fixed Percentage 3</i> 522
0	1	<i>Fixed Percentage 4</i> 523

0 = contact open 1 = contact closed

14.7 Frequency ramps

The ramps determine how quickly the frequency value is changed if the reference value changes or after a start, stop or brake command. The maximum admissible ramp gradient can be selected according to the application and the current consumption of the motor.

If the settings of the frequency ramps are identical for both directions of rotation, the parameterization via the parameters *Acceleration (clockwise)* **420** and *Deceleration (clockwise)* **421** is sufficient. The values of the frequency ramps are taken over for *Acceleration anticlockwise* **422** and *Deceleration anticlockwise* **423** if these have been parameterized to the factory setting of -0.01 Hz/s.

The parameter value of 0.00 Hz/s for the acceleration blocks the corresponding direction of rotation.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
420	Acceleration (clockwise)	0.00 Hz/s	9999.99 Hz/s	5.00 Hz/s
421	Deceleration (clockwise)	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s
422	Acceleration anticlockwise	- 0.01 Hz/s ¹⁾	9999.99 Hz/s	- 0.01 Hz/s
423	Deceleration anticlockwise	- 0.01 Hz/s ²⁾	9999.99 Hz/s	- 0.01 Hz/s

¹⁾ Value -0.01 Hz/s means: *Acceleration (Clockwise)* **420** is applied.


²⁾ Value -0.01 Hz/s means: *Deceleration (Clockwise)* **421** is applied.



The setting 0.00 Hz/s won't accelerate or decelerate the drive due to the limitation of the ramp.

The ramps for the *Emergency stop clockwise* **424** and *Emergency stop anticlockwise* **425** of the drive mechanism to be activated via *Operation mode* **630** for the stopping behavior must be selected according to the application. The non-linear (S-shaped) course of the ramps is not active in the case of an emergency stop of the drive.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
424	Emergency stop clockwise	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s
425	Emergency stop anti-clockwise	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s



The parameter *Maximum leading* **426** limits the difference between the output of the ramp and the current actual value of the drive. The set maximum deviation is a dead time for the control system which should be kept as low as possible.

In case the drive is loaded heavily and high acceleration and deceleration values are selected it is possible, that a set controller limit is reached while the drive is accelerated or decelerated. In this case, the drive cannot follow the defined acceleration or deceleration ramps. With *Maximum leading* **426**, you can limit the max. leading of the ramp.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
426	Maximum leading	0.01 Hz	999.99 Hz	5.00 Hz


Example: Fixed value at ramp output = 20 Hz, current actual value of drive = 15 Hz, selected *Maximum leading* **426** = 5 Hz

The frequency at the ramp output is increased to 15 Hz only, it is not increased further. The difference (leading) between the frequency value at the ramp output and the current actual frequency of the drive is limited to 5 Hz in this way.

The load occurring in a linear acceleration of the drive is reduced by the adjustable modification speeds (S curve). The non-linear course of the frequency is defined as a ramp and states the time range in which the frequency is to be guided to the set ramp. The values set with parameters 420 to 423 are maintained regardless of the selected ramp times.

Setting the ramp time to 0 ms deactivates the function S curve and enables the use of the linear ramps. The data set change-over of the parameters within an acceleration phase of the drive mechanism demands the defined take-over of the values. The controller calculates the values required in order to reach the reference value from the ratio of the acceleration to the ramp time and uses it until the acceleration phase is complete. With this method, exceeding the reference values is avoided and a data set change-over between extremely deviating values becomes possible.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
430	Ramp rise time clockwise	0 ms	65000 ms	0 ms
431	Ramp fall time clockwise	0 ms	65000 ms	0 ms
432	Ramp rise time anticlockwise	0 ms	65000 ms	0 ms
433	Ramp rise time anticlockwise	0 ms	65000 ms	0 ms



Example: Calculation of the acceleration time in clockwise rotation at an acceleration from 20 Hz to 50 Hz (f_{max}) and an acceleration ramp of 2 Hz/s for parameter *Acceleration (clockwise)* **420**. The *Ramp rise time clockwise* **430** is set to 100 ms.

$$t_{aufr} = \frac{\Delta f}{a_r}$$

$$t_{aufr} = \frac{50 \text{ Hz} - 20 \text{ Hz}}{2 \text{ Hz/s}} = 15 \text{ s}$$

$$t_{auf} = t_{aufr} + t_{vr}$$

$$t_{auf} = 15 \text{ s} + 100 \text{ ms} = 15,1 \text{ s}$$

t_{aufr} = acceleration time clockwise rotary field
 Δf = change of frequency acceleration ramp
 a_r = Acceleration clockwise
 t_{vr} = Ramp rise time clockwise
 t_{auf} = acceleration time + ramp rise time

14.8 Percentage Value Ramps

The percentage value ramps scale the change of the reference value (in percent) for the corresponding input function. The acceleration and deceleration of the drive are parameterized via the frequency ramps.

The behavior *Gradient percentage ramp 477* corresponds to a function which takes the time behavior of the drive system into account. If the parameter is set to 0 %/s, this function is deactivated and a direct reference value modification for the following function is obtained.

The default value depends on the *Configuration 30*.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
477	Gradient percentage ramp	0 %/s	60000 %/s	x %/s


14.9 Block Frequencies

In certain applications, it is necessary to fade out reference frequencies. In this way, resonance points of the system as stationary operating points are avoided. The parameters *1st block frequency 447* and *2nd block frequency 448* with the parameter *Frequency hysteresis 449* define two resonance points.

A block frequency is active if the parameter values of the block frequency and the frequency hysteresis are not equal to 0.00 Hz.

The area faded out as a stationary working point by the hysteresis is passed through as quickly as possible according to the ramp set. If the output frequency is limited as a result of the selected control parameter settings, e.g. if the current limit is reached, the hysteresis is passed through with a delay. The behavior of the reference value can be determined from its direction of movement according to the following diagram.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
447	1. blocking frequency	0.00 Hz	999.99 Hz	0.00 Hz
448	2. blocking frequency	0.00 Hz	999.99 Hz	0.00 Hz
449	Frequency hysteresis	0.00 Hz	100.00 Hz	0.00 Hz



14.10 Motor Potentiometer

Via the motor potentiometer function, the motor speed is controlled via

- digital control signals (function Motorpoti MP) or via
- the keys of the control unit KP 500 (Function Motorpoti KP)

The control up/down commands are assigned the following functions:

Activation				
Motorpoti (MP)		Motorpoti (KP)		Function
Up	Down	Up	Down	
0	0	–	–	Output signal does not change.
1	0	▲	–	Output value rises at set ramp.
0	1	–	▼	Output value drops at set ramp.
1	1	▲ + ▼		Output value is reset to initial value.

0 = contact open 1 = contact closed

▲ ▼ = Arrow keys on control unit KP 500

The motor potentiometer function and its link to other reference value sources can be selected in the corresponding reference value channels with parameters *Reference frequency source 475* or *Reference percentage source 476*.

For a description of the possible links of the reference value sources, refer to chapters "Reference Values", "Frequency reference channel" and "Reference percentage channel".

Availability of functions „Motorpoti (MP)“ and „Motorpoti (KP)“ differs in the individual reference value channels:

Reference value channel		
	<i>Reference frequency source 475</i>	<i>Reference percentage source 476</i>
Motorpoti (MP)	X	X
Motorpoti (KP)	X	0

X = function available 0 = function not available

Depending on the active reference value channel, the function is assigned to a digital signal via parameters *Frequency motorpoti up 62*, *Frequency motorpoti down 63* or *Percent motorpoti up 72*, *Percent motorpoti down 73*.

For a summary of available digital signals, refer to chapter "Digital inputs".

The *Operation mode 474* of the motor potentiometer function defines the behavior of the function at various operating points of the frequency inverter.

<i>Operation mode 474</i>	<i>Function</i>
0 - non-storing	In the operation mode motor potentiometer non-storing (not Latching), the drive goes to the set minimum reference value at each start.
1 - latching	In the operation mode storing (latching) the motor goes to the reference value selected before the switch-off at the start. The reference value is also stored when the device is switched off.
2 - taking over	The operation mode Motorpoti taking over is to be used for the data set change-over of the reference value channel. The current reference value is used when the motorpoti function is activated.
3 - taking over and storing	This operation mode combines the behavior in operation mode 1 and 2.

14.10.1 Motorpoti (MP)

The Function "Motorpoti (MP)" is to be parameterized via the parameter *Reference frequency source 475* or *Reference percentage source 476*.

Frequency reference channel

Via the digital control inputs, the required functions *Frequency motorpoti up 62* and *Frequency motorpoti down 63* are triggered.

Limitation of the reference values is affected via parameters *Minimum frequency 418* and *Maximum frequency 419*.

Reference percentage channel

Via the digital control inputs, the required functions *Percentage motorpoti up 72* and *Percentage motorpoti down 73* are triggered. Limitation of the reference values is affected via parameters *Minimum percentage 518* and *Maximum percentage 519*.


14.10.2 Motorpoti (KP)

The function „Motorpoti (KP)“ is only available in the reference frequency channel. The function and its link to other reference value sources can be selected via parameter *Reference frequency source 475*.

Via the keys of the control unit KP 500, the required functions *Frequency motorpoti up 62* and *Frequency motorpoti down 63* are triggered.

Limitation of the reference values is affected via parameters *Minimum frequency 418* and *Maximum frequency 419*.

Control is performed as described in chapter „Control unit KP500, Controlling the Motor via the control unit“. If the function Motorpoti (KP) is activated, „inPF“ will be displayed for clockwise (forward) direction of rotation and „inPr“ for anticlockwise (reverse) direction of rotation.



The keys on the control unit have the following functions:

Key functions	
▲ / ▼	Increase / reduce frequency.
ENT	Reversal of the sense of rotation independent of the control signal on the terminals Clockwise S2IND or Anticlockwise S3IND.
ENT (1 sec)	Save the selected function as default value. The direction of rotation is not changed.
ESC	Cancel function and return to the menu structure.
FUN	Switch from internal reference value inP to JOG frequency; the drive will start. Release the key to switch to the sub-function and stop the drive.
RUN	Start drive; alternative to control signal S2IND or S3IND.
STOP	Stop drive; alternative to control signal S2IND or S3IND.

14.10.3 Controlling the Motor via the Control Unit

The function *Reference frequency source* **475** enables linking of the reference sources in the reference frequency channel. The operation modes can be set without the function "Motorpoti (KP)".

If an operation mode without "Motorpoti (KP)" is selected, a connected motor can be controlled via the keys of the control unit KP 500.

The function is activated as described in chapter „Control Unit KP500, Controlling the Motor via the Control Unit“.

The speed of the modification of the reference value is limited by the parameter *ramp Keypad-Motorpoti* **473**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
473	Ramp Keypad Motorpoti	0.00 Hz/s	999.99 Hz/s	2.00 Hz/s

14.11 PWM-/repetition frequency input

The use of a PWM (pulse-width modulated) frequency signal completes the various possibilities of the reference value specification. The signal at one of the available digital inputs is evaluated according to the selected *Operation mode 496*.

PWM frequencies in the range between 50 Hz and 150 kHz can be evaluated.

<i>Operation mode 496</i>	<i>Function</i>
0 - Off	The PWM signal or repetition frequency is zero.
2 - PWM S2IND, 0 - 100%	PWM signal capture on terminal X210A.4. 0 ... 100% of <i>Maximum reference percentage 519</i> or 0 ... 100% of <i>Maximum frequency 419</i> .
3 - PWM S3IND, 0 - 100%	PWM signal capture on terminal X210A.5. 0 ... 100% of <i>Maximum reference percentage 519</i> or 0 ... 100% of <i>Maximum frequency 419</i> .
6 - PWM S6IND, 0 - 100%	PWM signal capture on terminal X210B.1. 0 ... 100% of <i>Maximum reference percentage 519</i> or 0 ... 100% of <i>Maximum frequency 419</i> .
12 - PWM S2IND, -100 - 100%	PWM signal capture on terminal X210A.4. -100 ... 100% of <i>Maximum reference percentage 519</i> or -100 ... 100% of <i>Maximum frequency 419</i> .
13 - PWM S3IND, -100 - 100%	PWM signal capture on terminal X210A.5. -100 ... 100% of <i>Maximum reference percentage 519</i> or -100 ... 100% of <i>Maximum frequency 419</i> .
16 - PWM S6IND, -100 - 100%	PWM signal capture on terminal X210B.1. -100 ... 100% of <i>Maximum reference percentage 519</i> or -100 ... 100% of <i>Maximum frequency 419</i> .
21 - S2IND Single evaluation pos.	Repetition frequency input on terminal X210A.4. One edge of the frequency signal is evaluated with a positive sign.
22 - S2IND Double evaluation pos.	Repetition frequency input on terminal X210A.4. Both edges of the frequency signal are evaluated with a positive sign.
31 - S3IND Single evaluation pos.	Repetition frequency input on terminal X210A.5. One edge of the frequency signal is evaluated with a positive sign.
32 - S3IND Double evaluation pos.	Repetition frequency input on terminal X210A.5. Both edges of the frequency signal are evaluated with a positive sign.
61 - S6IND Single evaluation pos.	Repetition frequency input on terminal X210B.1. One edge of the frequency signal is evaluated with a positive sign.
62 - S6IND Double evaluation pos.	Repetition frequency input on terminal X210B.1. Both edges of the frequency signal are evaluated with a positive sign.
121 to 162	Repetition Frequency Input. Operation modes 21 to 62 with evaluation of the frequency signal, but with a negative sign.



If a digital input is configured as a PWM or repetition frequency input, this input cannot be used for other functions.

[Check the link of the digital inputs to other functions.](#)

The signal frequency at the selected repetition frequency input can be scaled via the parameter *Divider 497*. The parameter figure is comparable with the division marks of a speed sensor per rotation of the drive mechanism. The frequency limit of the parameterized digital input is to be taken into account for the frequency of the input signal.


Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
497	Divider	1	8192	1024



The reference value specification within the different functions enables the use of the repetition frequency signal as a percentage figure. A signal frequency of 100 Hz at the repetition frequency input corresponds to 100%, 1 Hz corresponds to 1%. The parameter *Divider 497* is to be used in a way comparable with the speed sensor simulation.

Via parameters *Offset 652* and *Amplification 653*, the PWM input signal can be adjusted for the application.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
652	Offset	-100.00%	100.00%	0.00%
653	Amplification	5.0%	1000.0%	100.0%



$$\text{PWM - Value} = \text{Offset } 652 + \left(\frac{T_{\text{on}}}{T_{\text{ges}}} [\%] \times \text{Amplification } 653 \right)$$

Set the reference value via one the following modes.

- For reference frequency values:
Reference Frequency Source 475 = "32 - Rep. Frequency Input (F3)". The PWM-value is related to *Maximum Frequency 419*.
- For reference percentage values:
Reference Percentage Source 476 = "32 - Rep. Frequency Input (F3)". The PWM-value is related to *Maximum Reference Percentage 519*.

Parameter *PWM-Input 258* shows the actual value of the PWM input.

15 Control Inputs and Outputs

The modular structure of the frequency inverters enables a wide spectrum of applications on the basis of the available hardware and software functionality. The control inputs and outputs of terminals X210A and X210B described in the following can be linked to software modules freely via the described parameters.

15.1 Multi-Function Input MFI1

Multifunction input MFI1 can be configured as a voltage, a current or a digital input. Depending on the selected *Operation mode* **452** for the multifunction input, a link to various functions of the software is possible. The unused operation modes are assigned the signal value 0 (LOW).

<i>Operation mode 452</i>	<i>Function</i>
1 - Voltage Input	voltage signal (MFI1A), 0 V ... 10 V
2 - Current Input	current signal (MFI1A), 0 mA ... 20 mA
3 - Digital Input	digital signal (MFI1D), 0 V ... 24 V



The sampling rate of multi-function input MFI1D is slower than that of digital signals S1IND/STOA, S2IND, etc. For this reason, this input should only be used for signals which are not time-critical.

15.1.1 Analog input MFI1A

Multifunction input MFI1 is configured by default for an analog reference value source with a voltage signal of 0 V to 10 V.

Alternatively, you can select the operation mode for an analog current signal of 0 mA to 20 mA. The current signal is continuously monitored and the fault message "F1407" displayed if the maximum figure is exceeded.

15.1.1.1 Characteristic

Mapping of the analog input signal onto a reference frequency value or a reference percentage value is possible for various requirements. Parameterization can be done via two points of the linear characteristic of the reference value channel.

Point 1 with coordinates X1 and Y1 and point 2 with coordinates X2 and Y2 can be set in four data sets.

<i>Parameter</i>		<i>Settings</i>		
No.	Description	Min.	Max.	Fact. sett.
454	Point X1	0.00 %	100.00 %	2.00 %
455	Point Y1	-100.00 %	100.00 %	0.00 %
456	Point X2	0.00 %	100.00 %	98.00 %
457	Point Y2	-100.00 %	100.00 %	100.00 %


The coordinates of the points relate, as a percentage, to the analog signal with 10 V or 20 mA and parameter *Maximum Frequency* **419** or parameter *Maximum percentage reference* **519**. The direction of rotation can be changed via the digital inputs and/or by selection of the points.



WARNING

The monitoring of the analog input signal via the parameter *Error/Warning behavior* **453** demands the examination of the parameter *Characteristic point X1* **454**.

The following characteristic is set by default and can be adapted to the application via the parameters mentioned.



Point 1:

$$X1 = 2.00\% \cdot 10 \text{ V} = 0.20 \text{ V}$$

$$Y1 = 0.00\% \cdot 50.00 \text{ Hz} = 0.00 \text{ Hz}$$


Point 2:

$$X2 = 98.00\% \cdot 10 \text{ V} = 9.80 \text{ V}$$

$$Y2 = 100.00\% \cdot 50.00 \text{ Hz} = 50.00 \text{ Hz}$$

The freely configurable characteristic enables setting a tolerance at the ends as well as a reversal of the direction of rotation.

The following example shows the inverse reference value specification with additional reversal of the direction of rotation. This is often used in pressure control systems.



Point 1:

$$X1 = 2.00\% \cdot 10 \text{ V} = 0.20 \text{ V}$$

$$Y1 = 100.00\% \cdot 50.00 \text{ Hz} = 50.00 \text{ Hz}$$

Point 2:

$$X2 = 98.00\% \cdot 10 \text{ V} = 9.80 \text{ V}$$

$$Y2 = -80.00\% \cdot 50.00 \text{ Hz} = -40.00 \text{ Hz}$$

The reversal of the direction of rotation is affected in this example at an analog input signal of 5.5V.

The definition of the analog input characteristic can be calculated via the two-point form of the line equation. The speed Y of the drive is controlled according to the analog control signal X.

$$Y = \frac{Y2 - Y1}{X2 - X1} \cdot (X - X1) + Y1$$

15.1.1.2 Scaling

The analog input signal is mapped to the freely configurable characteristic. The maximum admissible setting range of the drive can be set via the frequency limits or percentage limits according to the configuration selected. In the case of the parameterization of a bipolar characteristic, the set minimum and maximum limits for both directions of rotation are effective. The percentage values of the characteristic points are relative to the limits selected.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
418	Minimum Frequency	0.00 Hz	999.99 Hz	3.50 Hz ¹⁾
				0.00 Hz ²⁾
419	Maximum Frequency	0.00 Hz	999.99 Hz	50.00 Hz

The factory settings depend on the setup of parameter *Configuration 30*:

¹⁾ 3.50 Hz in configurations 1xx, 4xx

²⁾ 0.00 Hz in configurations 2xx, 5xx


The control system uses the maximum value of the output frequency, which is calculated from the *Maximum Frequency 419* and the compensated slip of the drive. The frequency limits define the speed range of the drive, and the percentage values supplement the scaling of the analog input characteristic in accordance with the functions configured.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
518	Minimum Reference Percentage	0.00 %	300.00 %	0.00 %
519	Maximum Reference Percentage	0.00 %	300.00 %	100.00 %


15.1.1.3 Tolerance Band and Hysteresis

The analog input characteristic with change of sign of the reference value can be adapted by the parameter *Tolerance band 450* of the application. The adjustable tolerance band extends the zero passage of the speed relative to the analog control signal. The parameter value (percent) is relative to the maximum current or voltage signal.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
450	Tolerance band	0.00 %	25.00 %	2.00 %



The default *Minimum Frequency 418* or *Minimum Percentage 518* extends the parameterized tolerance band to the hysteresis.



Tolerance band with set minimum frequency

For example, the output variable coming from positive input signals is kept on the positive minimum value until the input signal becomes lower than the value for the tolerance band in the negative direction. Then, the output variable follows the set characteristic.

15.1.1.4 Filter Time Constant

The time constant of the filter for the analog reference value can be set via the parameter *Filter Time Constant 451*.

The time constant indicates the time during which the input signal is averaged by means of a low pass filter, e.g. in order to eliminate fault effects.

The setting range is between 0 ms and 5000 ms in 15 steps.

<i>Filter Time Constant 451</i>	Function
0 - Time Constant 0 ms	Filter deactivated – analog reference value is forwarded unfiltered.
2 - Time Constant 2 ms	
4 - Time Constant 4 ms	
8 - Time Constant 8 ms	
16 - Time Constant 16 ms	
32 - Time Constant 32 ms	
64 - Time Constant 64 ms	
128 - Time Constant 128 ms	
256 - Time Constant 256 ms	
512 - Time Constant 512 ms	
1000 - Time Constant 1000 ms	
2000 - Time Constant 2000 ms	
3000 - Time Constant 3000 ms	
4000 - Time Constant 4000 ms	
5000 - Time Constant 5000 ms	

15.1.1.5 Error and warning behavior

For monitoring the analog input signal, an operation mode can be selected via parameter *Error/warning behavior 453*.

Error/Warning Behavior 453	Function
0 - Off	The input signal is not monitored.
1 - Warning < 1V/2mA	If the input signal is lower than 1 V or 2 mA, a warning message is issued.
2 - Shut Down < 1V/2mA	If the input signal is lower than 1 V or 2 mA, a warning message is issued; the drive is decelerated according to stopping behavior 2.
3 - Error Switch-Off < 1V/2mA	If the input signal is lower than 1 V or 2 mA, a warning and fault message is issued and the drive coasts to a standstill (stopping behavior 0).

Monitoring of the analog input signal is active regardless of the release of the frequency inverter according to the operation mode selected.

Operation mode **2** defines the shut-down and stopping of the drive, regardless of the setting of parameter *Operation mode 630* for the stopping behavior. The drive is stopped according to stopping behavior 2. If the set holding time has expired, an error message is issued. The drive can be started again by switching the start signal on and off.


Operation mode **3** defines the free coasting of the drive (like described for stopping behavior 0), regardless of the setting of parameter *Operation mode 630* for the stopping behavior.

WARNING

The monitoring of the analog input signal via the parameter *Error/Warning behavior 453* demands the examination of the parameter *Characteristic point X1 454*.



Example: *Error/Warning behavior 453* = "2 - Stop < 1V/2mA" or "3 – fault switch-off < 1V/2mA". In the factory settings of the parameter *Point X1 454* shutting down or fault switch-off are affected at an output frequency $\neq 0$ Hz. If shutting down or fault switch-off are to be affected at an output frequency of 0 Hz, the Point X1 must be adjusted (e.g. $X1=10\%$ / 1 V).



15.2 Multi-Function Output MFO1

Multifunction output MFO1 can either be configured as a digital, analog or a repetition frequency output. Depending on the selected *Operation mode 550* for the multifunction output, a link to various functions of the software is possible. The operation modes not used are deactivated internally.

<i>Operation mode 550</i>	Function
0 - Off	Output has the logic signal LOW.
1 - Digital	Digital output, 0...24 V.
2 - Analog	Analog output, 0...24 V.
3 - Repetition Frequency	Repetition frequency output, 0...24 V, $f_{\max} = 150 \text{ kHz}$.

15.2.1 Analog output MFO1A

By default, the multifunction output MFO1 is configured for the output of a pulse width modulated output signal with a maximum voltage of DC 24 V.

The selected configuration determines which actual values can be selected for parameter *Analog operation 553* of multifunction output 1.


<i>Analog operation 553</i>	Function
0 - Off	Analog operation MFO1 is switched off.
1 - Abs. Fs	Abs. value of the Stator Frequency 0.00 Hz ... <i>Maximum frequency 419</i> .
2 - Abs. Fs betw. f_{\min}/f_{\max}	Abs. value of the Stator Frequency <i>Minimum frequency 418...Maximum frequency 419</i> .
3 - Abs. Speed Sensor 1	Abs. value of speed sensor signal 1, 0.00 Hz ... <i>Maximum frequency 419</i> .
7 - Abs. Actual Frequency	Abs. value of act. frequency, 0.00 Hz ... <i>Maximum frequency 419</i> .
20 - Abs. I _{active}	Abs. value of current effective current I_{Active} , 0.0 A ... FU rated current.
21 - Abs. I _{sd}	Abs. value of flux-forming current component, 0.0 A ... FU rated current.
22 - Abs. I _{sq}	Abs. value of torque-forming current component, 0.0 A ... FU rated current.
30 - Abs. P _{active}	Abs. value of current active power P_{Active} , 0.0 kW ... <i>Rated mech. power 376</i> .
31 - Abs. M	Abs. value of calculated torque M, 0.0 Nm ... Rated torque.
32 - Abs. Inside Temperature	Abs. value of measured inside temperature, 0 °C ... 100 °C
33 - Abs. Heat Sink Temperature	Abs. value of measured heat sink temperature, 0 °C ... 100 °C
40 - Abs. Analog Input MFI1A	Abs. signal value on analog input 1, 0.0 V ... 10.0 V.
50 - Abs. I	Abs. current value of measured output currents, 0.0 A ... FU rated current.
51 - DC –Link Voltage	DC link voltage u_d , 0.0 V ... 1000.0 V.
52 - V	Output voltage U, 0.0 V ... 1000.0 V.
53 - Volume Flow	Abs. value of calculated volume flow 0.0 m ³ /h ... <i>Nominal volumetric flow 397</i> .
54 - Pressure	Abs. value of calculated pressure 0.0 kPa ... <i>Reference pressure 398</i> .
101 to 133	Operation modes in analog operation with signs.

15.2.1.1 Output Characteristic

The voltage range of the output signal at multifunction output 1 can be adjusted. The value range of the actual value selected via parameter *Analog operation 553* is assigned to the value range of the output signal which is adjusted via the parameters *Voltage 100% 551* and *Voltage 0% 552*.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
551	Voltage 100%	0.0 V	22.0 V	10.0 V
552	Voltage 0%	0.0 V	24.0 V	0.0 V

Analog Operation 553 with abs. act. *Analog operation 553* with signs:
value:



With the parameters *Voltage 100% 551* and *Voltage 0% 552*, the voltage range at 100% and 0% of the output parameter is set. If the output value exceeds the reference value, the output voltage also exceeds the value of the parameter *Voltage 100% 551* up to the maximum value of 24V.

15.2.2 Frequency Output MFO1F

The multifunctional output MFO1 can be used as a frequency output in the setting of *Operation Mode 550* = "3 - Repetition Frequency". The DC 24V output signal is assigned to the abs. value of the speed or frequency via the parameter *Repetition Freq. Operation 555*. The selection of the operation modes depends on the expansion modules installed as an option.

<i>Repetition Freq. Operation 555</i>	Function
0 - Off	Repetition frequency operation MFO1 switched off
1 - Actual Frequency	Abs. value of the <i>Actual frequency 241</i> .
2 - Stator Frequency	Abs. value of the <i>Stator frequency 210</i> .
3 - Frequency Speed Sensor 1	Abs. value of the <i>Encoder 1 Frequency 217</i> .
5 - Repetition Frequency Input	Abs. value of the <i>Repetition freq. input 252</i> .

15.2.2.1 Scaling

The repetition frequency mode for the multifunction output corresponds to the mapping of an incremental sensor. The parameter *Division marks 556* must be parameterized according to the frequency to be output. The minimum frequency of the repetition frequency operation is 30 Hz. Lower values are set as 0 Hz.

The pulse pause relation is not 1:1. The repetition frequency output should be evaluated therefore only with rising or falling edge in the evaluating device.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
556	Division Marks	30	8192	1024

The frequency limit of $f_{\max}=150$ kHz may not be exceeded in the calculation of the parameter *Division marks 556*.

$$S_{\max} = \frac{150000 \text{ Hz}}{\text{Frequency value}}$$

15.3 Digital Outputs

The *Operation mode Digital output 1 530* and the relay output with the parameter *Operation mode Digital output 3 532* link the digital outputs to various functions. The selection of the functions depends on the parameterized configuration. The use of the multifunctional output MFO1 as a digital output demands selection of an *Operation mode 550* and linking via parameter *Digital operation MFO1 554*.

Operation mode 530,532,554	Function
0 - Off	Digital output is switched off.
1 - Ready or Standby Signal	Frequency inverter is initialized and on stand-by or in operation.
2 - Run Signal	Signal enable STO (S1IND/STOA and S7IND/STOB) and a start command are present, output frequency available.
3 - Error Signal	Message is displayed via the parameter <i>Current error 259</i> or <i>Warnings 269</i> .
4 - Setting Frequency	The <i>Stator frequency 210</i> is higher than the parameterized <i>Setting frequency 510</i>
5 - Reference Frequency reached	The <i>Actual frequency 241</i> of the drive has reached the <i>Internal reference frequency 228</i> .
6 - Reference Percentage Reached	The <i>Actual percentage 230</i> has reached the <i>Reference percentage 229</i> .
7 - Ixt warning	The <i>Warning Limit Short-Term Ixt 405</i> or <i>Warning Limit Long-Term Ixt 406</i> has been reached.
8 - Warning Heat sink temperature	Max. heat sink temperature T_K of 80 °C minus the <i>Warning Limit Heat Sink Temp. 407</i> reached.
9 - Warning Inside temperature	Max. inside temperature T_i of 65 °C minus the <i>Warning Limit Inside Temp. 408</i> reached.
10 - Warning Motor Temperature	Warning behavior according to parameterized <i>Operation mode Motor temperature 570</i> at max. motor temperature T_{PTC} .
11 - Warning General	The message is displayed via parameter <i>Warnings 269</i> .
12 - Warning overtemperature	The selected limit values <i>Warning Limit Heat Sink Temp. 407</i> , <i>Warning limit Inside Temp. 408</i> or the maximum motor temperature has been exceeded.
13 - Mains Failure	Failure of the mains voltage and power regulation active according to <i>Operation Mode 670</i> for the voltage controller.
14 - Warning Motor Protect. Switch	Parameterized <i>Operation Mode 571</i> for the motor protection switch has triggered.
15 - Warning Current Limitation	A controller or the <i>Operation Mode 573</i> of the intelligent current limits limits the output current.
16 - Controller Current Limit. Long Term Ixt	The overload reserve for 60 s has been used up and the output current is being limited.
17 - Controller Current Limit. Short Term Ixt	The overload reserve for 1 s has been used up and the output current is being limited.
18 - Controller Current Limit. TK	Max. heat sink temperature T_K reached, intelligent current limits of <i>Operation mode 573</i> active.
19 - Controller Current Limit. Motor Temp.	Max. motor temperature reached, intelligent current limits of <i>Operation Mode 573</i> active.
20 - Comparator 1	The comparison according to the selected <i>Operation mode Comparator 1 540</i> is true.
21 - Comparator 2	The comparison according to the selected <i>Operation mode Comparator 2 543</i> is true.

Operation mode 530,532,554	Function
22 - Warning V-belt	Warning of <i>Operation Mode 581</i> of V-belt monitoring.
23 - Timer 1	The selected <i>Operation Mode Timer 1 790</i> generates an output signal of the function.
24 - Timer 2	The selected <i>Operation Mode Timer 2 793</i> generates an output signal of the function.
25 - Warning Mask	Message of the configurable parameter <i>Create Warning Mask 536</i> .
26 - Warning, Application	Warning application is signaled. Display of the actual value is affected via parameter <i>Warnings Application 273</i> .
27 - Warning Mask, Application	Message of the configurable parameter <i>Create Warning Mask Application 626</i> .
28 - Warning, gen + Warning, Application	Warning or warning application is signaled.
29 - Warn. Mask, gen + Warn. Mask, Appl.	Message of configurable parameters <i>Create Warning Mask 536</i> and <i>Create Warning Mask Application 626</i> .
30 - Flux-Forming finished	Magnetic field has been impressed.
41 - Brake release	Activation of a brake unit depending on the <i>Operation Mode 620</i> for the starting behavior, <i>Operation Mode 630</i> for the stopping behavior or the configured brake control system.
43 - External Fan	The <i>Switch-On Temperature 39</i> has been reached.
50 - Synchronization Fault ¹⁾	The phase error of the index control exceeded the <i>Warning limit 597</i> .
51 - Signal Fault ¹⁾	Index signal period too short during index control.
56 - Phasing Done ²⁾	Message of phasing function. For positioning in combination with the function of the electronic gear, the value <i>Phasing: Offset 1125</i> was reached.
57 - In Gear ^{1) 2)}	Synchronization of the electronic gear is reached. The slave drive is engaged and operates at a synchronous angle with the master.
58 - Position comparator ²⁾	The current actual value is in the range between <i>Switch-on position 1243</i> and <i>Switch-off position 1244</i> of the position comparator. The adjusted value of the parameter <i>Hysteresis 1245</i> is considered.
59 - Homing Done ²⁾	A reference travel operation was started and the reference position for positioning was set.
60 - Target Position Reached	<i>Reference orientation 469</i> of axle positioning was reached or <i>Target position / Distance 1202</i> of a positioning ²⁾ operation was reached (the current act. position is within the range set in parameter <i>Target window 1165</i> for a minimum period of <i>Target window time 1166</i>).
61 - Warning Deviation of Position ²⁾	The contouring error monitoring <i>Warning Threshold 1105</i> was exceeded.
62 - Motion-Block Digital Signal 1 ²⁾	Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 1 1218</i> were fulfilled. "Start", "Reference value reached" and "End" of a travel order were evaluated.

Operation mode 530,532,554	Function
63 - Motion-Block Digital Signal 2 ²⁾	Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 2</i> 1219 were fulfilled. "Start", "Reference value reached" and "End" of a travel order were evaluated.
64 - Motion-Block Digital Signal 3 ²⁾	Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 3</i> 1247 were fulfilled. "Start", "Reference value reached" and "End" of a travel order were evaluated.
65 - Motion-Block Digital Signal 4 ²⁾	Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 4</i> 1248 were fulfilled. "Start", "Reference value reached" and "End" of a travel order were evaluated.
80 - FT-Output Buffer 1 ³⁾	The output signal of a function table instruction. The output signal is the signal source „2401 - FT-Output buffer 1“. The signal source contains the value of the FT-instruction output, which is assigned to the signal source 2401. The assignment is done by parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
81 - FT-Output Buffer 2 ³⁾	The output signal of a function table instruction. The output signal is the signal source „2402 - FT-Output buffer 2“. The signal source contains the value of the FT-instruction output, which is assigned to the signal source 2402. The assignment is done by parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
82 - FT-Output Buffer 3 ³⁾	The output signal of a function table instruction. The output signal is the signal source „2403 - FT-Output buffer 3“. The signal source contains the value of the FT-instruction output, which is assigned to the signal source 2403. The assignment is done by parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
83 - FT-Output Buffer 4 ³⁾	The output signal of a function table instruction. The output signal is the signal source „2404 - FT-Output buffer 4“. The signal source contains the value of the FT-instruction output, which is assigned to the signal source 2404. The assignment is done by parameter <i>FT-target output 1</i> 1350 or <i>FT-target output 2</i> 1351 .
90 Obj 0x3003 DigOut 1 ⁴⁾ to to 94 Obj 0x3003 DigOut 5	Sources of CAN-objects. For communication module CM with CAN interface necessary.
100 to 194	Operation modes inverted (LOW active)

¹⁾ Refer to the application manual "Electronic gear" for further details.

²⁾ Refer to the application manual "Positioning" for further details.

³⁾ Refer to the application manual "Function table" for further details.

⁴⁾ Refer to the operating instructions of the expansion module with CAN interface.

15.3.1 Digital Signal

The signals selected for parameters *Op. Mode Digital Output 1* **530**, *Digital Operation* **554** and *Op. Mode Digital Output 3* **532** can be linked with inverter functions.

Signal at digital output 1

175 -	Digital Signal 1	The Signal which is selected via <i>Op. Mode Digital Output 1</i> 530 .
-------	------------------	--

Signal at multifunction output MFO1

176 -	Digital Signal 2	The Signal which is selected via <i>Digital Operation</i> 554 . Set <i>Operation Mode</i> 550 = 1 - Digital.
-------	------------------	--

Signal at digital output 3 (relay output)

177 -	Digital Signal 3	The Signal which is selected via <i>Op. Mode Digital Output 3</i> 532 .
-------	------------------	--

With expansion module:

Signal at digital output 1 of an expansion module

181 -	Digital Signal 4, EM-Module	The signal, which is selected via <i>Op. Mode EM-SIOUTD</i> 533 .
-------	-----------------------------	--

Signal at digital output 2 of an expansion module

182 -	Digital Signal 5, EM-Module	The signal, which is selected via <i>Op. Mode EM-S2OUTD</i> 534 .
-------	-----------------------------	--


15.3.2 Setting Frequency

If operation mode 4 - "Setting Frequency" is selected for a digital output, the corresponding output becomes active if the actual value *Stator Frequency 210* exceeds the value of *Setting Frequency 510*.

The relevant output is switched over again as soon as the *Stator Frequency 210* falls below the value of "*Setting Frequency 510* minus *Setting Frequency Off Delta 517*". If the output stage is switched off (in example via STO), the digital signal "Setting frequency" is set to zero independent of the actual frequency.

Signal source 164 - "Setting Frequency" can be linked with inverter functions.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
510	Setting Frequency	0.00 Hz	999.99 Hz	3.00 Hz
517	Setting Frequency Off Delta	0.00 Hz	999.99 Hz	2.00 Hz



If *Setting Frequency Switch Off Delta 517* > *Setting Frequency 510* the output is never reset after the first switching on. Set up fitting values during commissioning.

<i>Op. Mode Digital Output 1</i> 530	or	4 - Setting Frequency
<i>Op. Mode Digital Output 2</i> 531	or	
<i>Op. Mode Digital Output 3</i> 532		
With expansion module:		
<i>Op. Mode EM-S1OUTD</i> 533	or	
<i>Op. Mode EM-S1OUTD</i> 534		
<i>Setting Frequency</i> 510		Set value [Hz]
For linking with functions		164 - Setting Frequency

15.3.3 Reference value reached

In operation mode 5 - "Reference Frequency reached" for a digital output, a signal is generated via the corresponding output when the actual frequency has reached the reference value.

In operation mode 6 - "Reference Percentage reached" for a digital output, a signal is generated via the corresponding output when the actual percentage value has reached the reference value.

Signal source 163 - "Reference Frequency reached" or 178 - "Reference Percentage reached" can be linked with inverter functions.

The hysteresis can be defined as a percentage of the adjustable range (Max - Min) via parameter *Max. Control Deviation* **549**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
549	Max. Control Deviation	0.01 %	20.00 %	5.00 %

<i>Op.Mode Digital Output 1</i> 530	or	5 - Reference Frequency reached or 6 - Reference Percentage reached (<i>Configuration 30</i> = x11, x30)
<i>Op.Mode Digital Output 2</i> 531	or	
<i>Op.Mode Digital Output 3</i> 532		
With expansion module:		
<i>Op.Mode EM-SIOU</i> 533	or	
<i>Op.Mode EM-SIOU</i> 534		
<i>Max. Control Deviation</i> 549		Set value [%].

Reference frequency

Internal Reference Frequency **228**

or


Reference percentage

Reference Percentage Value **229**

Actual Frequency **241**

or

Actual Percentage Value **230**




Example:

$$\text{Max. Control Deviation [Hz]} = \Delta f \times \text{Max. Control Deviation } \mathbf{549} [\%]$$

$$= (\text{Maximum Frequency } \mathbf{419} - \text{Minimum Frequency } \mathbf{418}) \times \text{Max. Control Deviation } \mathbf{549} [\%]$$

$$= (50 \text{ Hz} - 3.5 \text{ Hz}) \times 5\% = 2.325 \text{ Hz}$$



15.3.4 Flux Forming finished

If operation mode **30** is selected for a digital output the corresponding output becomes active when the flux formation is ended. The time for the flux formation results from the operating state of the machine and the set parameters for magnetizing the machine. The magnetizing can be defined via the starting behavior and is influenced by the amount of the set starting current.

15.3.5 Brake release

The Open brake function in **operation mode 41** enables the activation of a corresponding unit via the digital control output. The function uses both the control commands via the contact inputs and the set starting and stopping behavior for controlling the digital output.

According to the configured starting behavior, the output is switched on when the magnetizing of the motor is finished. When the *Brake release time 625* has elapsed, the drive is accelerated.

The stopping behavior of the drive depends on the configuration of the parameters *Operation Mode 630*. This is described in chapter "Stopping Behavior".

If stopping behavior 2 or 5 with stop function is selected, the drive is controlled to zero speed and the digital output is not switched off. In the other operation modes of the stop behavior, the control of the brake is possible. At the start of a free coasting of the drive, the digital output is switched off.

This is similar to the behavior in the case of the stopping behavior with shutdown. The drive is decelerated and supplied with current for the set holding time. Within the set holding time, the control output is switched off and thus the brake activated.

Control of Brake	
Stopping Behavior 0	Operation mode "41-Open brake" switches off the digital output assigned to the function immediately. The mechanical brake is activated.
Stopping Behavior 1, 3, 4, 6, 7	Operation mode "41-Open brake" switches off the digital output assigned to the function when <i>Switch-Off Threshold 637</i> is reached. The mechanical brake is activated.
Stopping Behavior 2, 5	Operation mode "41-Open brake" leaves the digital output assigned to the function switched on. The mechanical brake remains open.

15.3.6 Current Limitation

Operation modes 15 to 19 link the digital outputs and the relay output to the functions of the intelligent current limits. The reduction of power by the set figure in percent of the rated current depends on the selected operation mode. Accordingly, the event for intervention of the current limitation can be output via the operation modes of the digital outputs. If the function of the intelligent current limits is deactivated within the sensorless control, **operation modes 16 to 19** are switched off in the same way.

15.3.7 External Fan

Operation mode 43 enables the control of an external fan. Via the digital output, the fan is switched on if the controller is released and Start clockwise or Start anti-clockwise are switched on, or if the *Switch-On Temperature 39* for the internal fan was reached.

15.3.8 Warning Mask

The Warning mask signals via a digital signal if an afore configured warning applies. The configuration of the Warning mask is carried out via *Create warning mask 536*. Warnings and controller status messages can be combined. This enables internal or external control using a common output signal. The display of *Warning 269* and *Controller Status 275* is not affected by the Warning mask.

Select a setting 1 ... 43 for message activation.

Select a setting 101 ... 143 for deactivation of a message.

<i>Create Warning Mask 536</i>	Function
0 - No Change	Configured warning mask is not modified.
1 - Activate everything	The warnings and controller status messages stated are linked in the warning mask.
2 - Activate all Warnings	The warnings reports stated are linked in the warning mask.
3 - Activate all Controller States	The controller status reports stated are linked in the warning mask.
10 - Warning Ixt	The frequency inverter is overloaded.
11 - Warning Short-Term Ixt	Overload reserve for 1 s less the <i>Warning limit short-term Ixt 405</i> has been reached.
12 - Warning Long-Term Ixt	Overload reserve for 60 s less the <i>Warning limit long-term Ixt 406</i> has been reached.
13 - Warning Heat Sink Temperature	Max. heat sink temperature T_K of 80 °C minus the <i>Warning Limit Heat Sink Temp. 407</i> has been reached.
14 - Warning Inside Temperature	Max. inside temperature T_I of 65 °C minus the <i>Warning Limit Inside Temp. 408</i> reached.
15 - Warning Limit	The controller stated in <i>Controller status 355</i> limits the reference value.
16 - Warning Init	Frequency inverter is being initialized.
17 - Warning Motor Temperature	Warning behavior according to parameterized <i>Operation mode Motor temperature 570</i> at max. motor temperature T_{PTC} .
18 - Warning Mains Failure	<i>Phase monitoring 576</i> reports a phase failure.
19 - Warning Motor Protective Switch	<i>Operation Mode 571</i> for the motor protective switch has triggered.
20 - Warning Fmax	The <i>Maximum frequency 419</i> has been exceeded. The frequency limitation is active.
21 - Warning Analog Input MF11A	The input signal is lower than 1 V/2 mA according to the operation mode <i>Error/Warning Behavior 453</i> .
22 - Warning Analog Input EM-S11NA	The input signal on the analog input of an expansion module is lower than 1V/2mA according to the operation mode <i>Error/Warning Behavior 453</i> .
23 - Warning System bus	A slave on the system bus reports a fault; warning is only relevant with the EM-SYS option.
24 - Warning Udc	The DC link voltage has reached the type-dependent minimum value.
25 - Application Warning	A warning application is signaled.
30 - Controller Udc Dynamic Operation	Controller is active according to the <i>Operation Mode 670</i> for the voltage controller.
31 - Controller Shutdown	The output frequency in the case of a power failure is below the <i>Shutdown threshold 675</i> .
32 - Controller Mains Failure	Failure of the mains voltage and power regulation active according to <i>Operation Mode 670</i> for the voltage controller.

<i>Create Warning Mask 536</i>		Function
33 -	Controller Udc Limitation	The DC link voltage has exceeded the <i>Reference UD limitation 680</i> .
34 -	Controller Voltage Pre-Control	The <i>Dyn. Voltage Pre-Control 605</i> accelerates the control characteristics.
35 -	Controller I abs	The output current is limited.
36 -	Controller Torque Limitation	The output power or the torque is limited by the speed controller.
37 -	Controller Torque Control	Switch-over of field-orientated control between speed and torque-controlled.
38 -	Ramp Stop	The <i>Operation mode 620</i> selected in starting behavior limits the output current.
39 -	Contr. Intel. Curr. Lim. LT-Ixt	Overload limit of the long-term Ixt (60s) reached, intelligent current limits active.
40 -	Contr. Intel. Curr. Lim. ST-Ixt	Overload limit of the short-term Ixt (1s) reached, intelligent current limits active.
41 -	Contr. Intel. Curr. Lim. Tc	Max. heat sink temperature T_K reached, <i>Operation Mode 573</i> for the intelligent current limits active.
42 -	Contr. Intel. Curr. Lim. Motor Temp.	Max. motor temperature T_{PTC} reached, <i>Operation Mode 573</i> for the intelligent current limits active.
43 -	Controller Freq. Limitation	The reference frequency has reached the <i>Maximum Frequency 419</i> . The frequency limitation is active.
101 to 143		Removal or deactivation of the operation mode within the warning mask.

The selected warning mask can be read out via the parameter *Actual Warning Mask 537*. The above operation modes of parameter *Create Warning Mask 536* are encoded in the *Actual Warning Mask 537*. The code results from hexadecimal addition of the individual operation modes and the matching abbreviation.

Warning code				Create Warning Mask 536
A	FFFF	FFFF	-	1 - Activate everything
A	0000	FFFF	-	2 - Activate all Warnings
A	FFFF	0000	-	3 - Activate all Controller States
A	0000	0001	Ixt	10 - Warning Ixt
A	0000	0002	IxtSt	11 - Warning Short-Term Ixt
A	0000	0004	IxtLt	12 - Warning Long-Term Ixt
A	0000	0008	Tc	13 - Warning Heat Sink Temperature
A	0000	0010	Ti	14 - Warning Inside Temperature
A	0000	0020	Lim	15 - Warning Limit
A	0000	0040	INIT	16 - Warning Init
A	0000	0080	MTemp	17 - Warning Motor Temperature
A	0000	0100	Mains	18 - Warning Mains Failure
A	0000	0200	PMS	19 - Warning Motor Protective Switch
A	0000	0400	Flim	20 - Warning Fmax
A	0000	0800	A1	21 - Warning Analog Input MF11A
A	0000	1000	A2	22 - Warning Analog Input MF12A
A	0000	2000	Sysbus	23 - Warning Systembus
A	0000	4000	UDC	24 - Warning Udc
A	0000	8000	WARN2	25 - Warning application
A	0001	0000	UDdyn	30 - Controller Udc Dynamic Operation
A	0002	0000	UDstop	31 - Controller Shutdown
A	0004	0000	UDctr	32 - Controller Mains Failure
A	0008	0000	UDlim	33 - Controller Udc Limitation
A	0010	0000	Boost	34 - Controller Voltage Pre-Control
A	0020	0000	Ilim	35 - Controller I abs
A	0040	0000	Tlim	36 - Controller Torque Limitation
A	0080	0000	Tctr	37 - Controller Torque Control
A	0100	0000	Rstp	38 - Ramp Stop
A	0200	0000	IxtLtlim	39 - Contr. Intel. Curr. Lim. LT-Ixt
A	0400	0000	IxtStlim	40 - Contr. Intel. Curr. Lim. ST-Ixt
A	0800	0000	Tclim	41 - Contr. Intel. Curr. Lim. Tc
A	1000	0000	MtempLim	42 - Contr. Intel. Curr. Lim. Motor Temp.
A	2000	0000	Flim	43 - Controller Freq. Limitation

The selected warning mask can be read out via parameter *Actual Warning Mask 537*. The above operation modes of parameter *Create Warning Mask 536* are encoded in the *Actual Warning Mask 537*. The code is calculated by hexadecimal addition of the individual operation modes and the corresponding abbreviation.

Output signals

The output of a warning message is signaled.

157 -	Warning Mask	1)	Output of a warning message which is activated in <i>Create Warning Mask 536</i> .
25 -		2)	

1) For linking with inverter functions

2) For digital output



Parameter *Warning 269* and *Warning 356* (error environment) show the warnings independent from the created Warning mask.

Parameter *Controller Status 275* and *Controller Status 355* (error environment) show the Controller Status independent from the created Warning mask.

15.3.9 Application warning mask

The Application Warning mask signals via a digital signal if an afore configured warning applies. The configuration of the Application Warning mask is carried out via *Create Appl. Warning Mask 626*.

As soon as limit switches are reached or contouring error limits are exceeded, a warning can be issued. The warnings refer to the parameter values set in error/warning behavior. Depending on the application, any number of warnings can be configured. This enables internal and/or external control using a common output signal. The display of *Warning Application 273* is not affected by the Warning mask.

<i>Create Appl. Warning Mask 626</i>	Function
0 - no change	The configured warning mask is not changed.
2 - Activate all Warnings	The warnings reports stated are linked in the warning mask.
10 - Warning V-belt	The <i>Operation mode 581</i> for V-belt monitoring signals no-load operation of the application.
11 - Warning pos. SW-Limit-Switch ¹⁾	Warning message indicating that the positive SW limit switch has been reached (parameter <i>Positive SW limit switch 1145</i>).
12 - Warning neg. SW-Limit-Switch ¹⁾	Warning message indicating that the negative SW limit switch has been reached (parameter <i>Negative SW limit switch 1146</i>).
13 - Warning pos. HW-Limit-Switch ¹⁾	Warning message indicating that the positive HW limit switch has been reached.
14 - Warning neg. HW-Limit-Switch ¹⁾	Warning message indicating that the negative HW limit switch has been reached.
15 - Warning Contouring Error ¹⁾	Warning message, indicating that the contouring error monitoring range adjusted with parameter <i>Warning Threshold 1105</i> has been left.
16 - Warning Encoder	An encoder with data track can trigger a warning. Selection is not effective with encoders without data track.
17 - Warning User 1	The signal set on digital input <i>User Warning 1 1363</i> is active.
18 - Warning User 2	The signal set on digital input <i>User Warning 2 1364</i> is active.
102 - Deactivate all Warnings	All warnings are deactivated.
110 - Deactivate Warning V-Belt	Warning 10 is deactivated.
111 - Deactivate Warning pos. SW-Limit-Switch	Warning 11 is deactivated.
112 - Deactivate Warning neg. SW-Limit-Switch	Warning 12 is deactivated.
113 - Deactivate Warning pos. HW-Limit-Switch	Warning 13 is deactivated.
114 - Deactivate Warning neg. HW-Limit-Switch	Warning 14 is deactivated.
115 - Deactivate Warning Contouring Error	Warning 15 is deactivated.
116 - Deactivate Warning Encoder	Warning 16 is deactivated.
117 - Deactivate Warning User 1	Warning 17 is deactivated.
118 - Deactivate Warning User 2	Warning 18 is deactivated.

¹⁾ Refer to the application manual "Positioning" for further details.

The selected warning mask application can be read out via the parameter *Actual Appl. Warning Mask 627*. The above operation modes of parameter *Create Appl. Warning Mask 626* are encoded in the *Actual Appl. Warning Mask 627*. The code results from hexadecimal addition of the individual operation modes and the matching abbreviation.

Warning code		Create Appl. Warning Mask 626
A 003F	-	2 - Activate all Warnings
A 0001	BELT	10 - Warning V-belt
A 0002	SW-LIM CW	11 - Warning pos. SW limit switch
A 0004	SW-LIM CCW	12 - Warning neg. SW limit switch
A 0008	HW-LIM CW	13 - Warning pos. HW limit switch
A 0010	HW-LIM CCW	14 - Warning neg. HW limit switch
A 0020	CONT	15 - Warning position controller
A 0040	Enc	16 - Warning Encoder
A 0080	User 1	17 - Warning User 1
A 0100	User 2	18 - Warning User 2

Output signals

The output of a warning message is signaled.

215 -	Warning Mask,	¹⁾	Output of a warning message which is activated in <i>Create Appl. Warning Mask 626</i> .
27 -	Application	²⁾	

¹⁾ For linking with inverter functions

²⁾ For digital output



Parameter *Warning Application 273* shows the Application Warnings independent from the created Warning mask.

In the error environment, *Application Warning Status 367* shows the current warnings of the positioning functions independent from the created Warning mask.

15.4 Digital inputs

The assignment of the control signals to the available software functions can be adapted to the application in question. Depending on the *Configuration 30* selected, the default assignment or the selection of the operation mode differ. In addition to the available digital control inputs, further internal logic signals are available as sources.

Each of the individual software functions is assigned to the various signal sources via parameterizable inputs. This enables a flexible use of the digital control signals.

Digital Inputs		Function
6 -	On	Signal input is switched on.
7 -	Off	Signal input is switched off.
13 -	Technology Controller Start	Start command technology controller (configuration 111, 211 or 411).
70 -	Inverter Release	¹ Signal on digital input S1IND/STOA (X210A.3) and S7IND/STOB (X210B.2); the safety function STO is linked permanently.
71 -	S2IND	Signal on digital input S2IND (X210A.4) or remote operation via communication interface.
72 -	S3IND	Signal on digital input S3IND (X210A.5) or remote operation via communication interface.
73 -	S4IND	Signal on digital input S4IND (X210A.6) or remote operation via communication interface.

¹ Refer to the application manual "Safe Torque Off" for further details.

Digital Inputs	Function
74 - S5IND	Signal on digital input S5IND (X210A.7) or remote operation via communication interface.
75 - S6IND	Signal on digital input S6IND (X210B.1) or remote operation via communication interface.
76 - MFI1D	Signal at multifunction input MFI1 (X210B.6) in <i>Operation Mode 452</i> = 3 - digital input or remote operation via communication interface.
157 - Warning Mask	The defined warning mask of parameter <i>Create Warning Mask 536</i> signals a critical operating point.
158 - Timer 1	Output signal of the time function according to the input connection <i>Timer 1 83</i> .
159 - Timer 2	Output signal of the time function according to the input connection <i>Timer 2 84</i> .
160 - Ready Signal	Frequency inverter is initialized and ready for operation.
161 - Run Signal	Signal enable STO (S1IND/STOA and S7IND/STOB) and a start command are present, output frequency available.
162 - Error Signal	Monitoring function signals an operational fault.
163 - Reference Frequency reached	Signal when the <i>Actual frequency 241</i> has reached the reference frequency.
164 - Setting Frequency	Signal when the actual value <i>Stator Frequency 210</i> exceeds the value of <i>Setting Frequency 510</i> .
165 - Warning Ixt	The monitoring functions report an overload of the frequency inverter.
166 - Warning Heat Sink Temperature	Max. heat sink temperature T_K of 80 °C less the <i>Warning Limit Heat Sink Temp. 407</i> reached.
167 - Warning Inside Temperature	Max. inside temperature T_i of 65 °C less the <i>Warning Limit Inside Temp 408</i> reached.
168 - Warning Motor Temperature	Warning behavior according to parameterized <i>Motor Temp. Operation mode 570</i> at max. motor temperature T_{PTC} .
169 - General Warning	Signal when <i>Warnings 269</i> are displayed with a critical operating point.
170 - Warning Overtemperature	The value – "80 °C minus <i>Warning Limit Heat Sink Temp. 407</i> " or – "65 °C minus <i>Warning Limit Inside Temp. 408</i> " is attained.
171 - Output Comparator 1	The comparison according to the selected <i>Operation mode Comparator 1 540</i> is true.
172 - Negated Output Comparator 1	Operation mode 171 with inverted logic (LOW active)
173 - Output Comparator 2	The comparison according to the selected <i>Operation mode Comparator 2 543</i> is true.
174 - Negated Output Comparator 2	Operation mode 173 with inverted logic (LOW active).
175 - Digital Signal 1	Signal according to parameter <i>Operation mode digital output 1 530</i> .
176 - Digital Signal 2	Signal according to parameter <i>Digital Operation 554</i> on multifunctional output MFO1.
177 - Digital Signal 3	Signal according to parameter <i>Operation mode digital output 3 532</i> .
178 - Reference Percentage reached	Signal when the <i>Actual percentage 230</i> has reached the <i>reference percentage 229</i> .

Digital Inputs	Function
179 - Mains Failure	Failure of the mains voltage and power regulation active according to <i>Operation Mode 670</i> for the voltage controller.
180 - Warning Motor Protection Switch	Parameterized <i>Operation Mode 571</i> of the motor protection switch has triggered.
181 - Digital Signal 4, EM-Module	Signal according to operation mode for the digital output of an expansion module.
182 - Digital Signal 5, EM-Module	Signal according to operation mode for the digital output of an expansion module.
215 - Warning Mask, Application	The defined warning mask of parameter <i>Create Appl. Warning Mask 626</i> signals a critical operating point.
216 - Application Warning	All warnings application are activated. Display is affected via parameter <i>Application Warnings 273</i> .
270 to 276	Operation modes 70 to 76 of the digital inputs inverted (LOW active).
282 - Target Position Reached	<i>Reference orientation 469</i> of axle positioning was reached or <i>Target position / Distance 1202</i> of a positioning operation ² was reached (the current act. position is within the range set in parameter <i>Target window 1165</i> for a minimum period of <i>Target window time 1166</i>).
284 - STOA inverted	Inverted signal status on digital input S1IND/STOA (first shutdown path STOA of safety function STO - „Safe Torque Off“). Inverted signal status on digital input S7IND/STOB (second shutdown path STOB of safety function STO - „Safe Torque Off“). Signal status on digital input S1IND/STOA (first shutdown path STOA of safety function STO - „Safe Torque Off“). Signal status on digital input S7IND/STOB (second shutdown path STOB of safety function STO - „Safe Torque Off“).
285 - STOB inverted	
292 - STOA	
293 - STOB	
320 - EM-S1IND	Signal on digital input 1 of an expansion module EM or remote operation via communication interface. Signal on digital input 2 of an expansion module EM or remote operation via communication interface. Signal on digital input 3 of an expansion module EM or remote operation via communication interface. Operation mode 320 inverted.
321 - EM-S2IND	
322 - EM-S3IND	
520 - EM-S1IND inverted	
521 - EM-S2IND inverted	Operation mode 321 inverted.
522 - EM-S3IND inverted	Operation mode 322 inverted.

² Refer to the application manual "Positioning" for further details.

³ Refer to the application manual "Safe Torque Off" for further details.

⁴ Refer to the operating instructions of the expansion modules with digital inputs.

Digital Inputs		Function
526 - S2IND (Hardware)		Digital input S2IND (X210A.4)
527 - S3IND (Hardware)		Digital input S3IND (X210A.5)
528 - S4IND (Hardware)		Digital input S4IND (X210A.6)
529 - S5IND (Hardware)		Digital input S5IND (X210A.7)
530 - S6IND (Hardware)		Digital input S6IND (X210B.1)
531 - MF11D (Hardware)	⁵	Multifunction input MF11 (X210B.6) in <i>Operation Mode 452</i> = 3 - digital input.
532 - EM-S1IND (Hardware)		Digital input 1 of an expansion module EM.
533 - EM-S2IND (Hardware)		Digital input 2 of an expansion module EM.
534 - EM-S3IND (Hardware)		Digital input 3 of an expansion module EM.
538 to 546		Operation modes 526 to 534 of the digital inputs inverted (LOW active).
604 - Warning Position Controller		Contouring error monitoring message. The contouring error monitoring range adjusted with parameter <i>Warning Threshold 1105</i> was left.
614 - Homing Done		A homing operation was started and the reference position for positioning was set.
615 - Homing Requested	⁶	A homing operation was started. The signal is reset at the end of the reference travel operation.
616 - Phasing Done		Message of phasing function. For positioning in combination with the function of the electronic gear, the value <i>Phasing: Offset 1125</i> was reached.
624 - In Gear	⁷	Synchronization of the electronic gear is reached. The slave drive is engaged and operates at a synchronous angle with the master.
640 Out-PZD3Boolean to 655 Out-PZD18Boolean	⁸	Process data for Profibus-communication. Module CM-PDP-V1 with Profibus interface is necessary.
691 - Index Contr.: Warn. Phase Error	⁹	The phase error of the index control exceeded the <i>Warning limit 597</i> .
692 - Index Contr.: Warning Period		Index signal period too short during index control.
700 - RxPDO1 Boolean1		Signal if an optional expansion module EM with system bus is used.
701 - RxPDO1 Boolean2		Signal if an optional expansion module EM with system bus is used.
702 - RxPDO1 Boolean3		Signal if an optional expansion module EM with system bus is used.
703 - RxPDO1 Boolean4	¹⁰	Signal if an optional expansion module EM with system bus is used.
710 to 713		Operation modes 700 to 703 for RxPDO2 with an expansion module EM with system bus.
720 to 723		Operation modes 700 to 703 for RxPDO3 with an expansion module EM with system bus.
730 - Sysbus Emergency		Signal if an optional expansion module EM with system bus is used.

⁵ The digital signal is independent of the configuration of the parameter *Local/Remote 412*.

⁶ Refer to the application manual "Positioning" for further details.

⁷ Refer to the application manuals "Positioning" and "Electronic gear" for further details.

⁸ Refer to the operating instructions of the expansion modules with Profibus interface.

⁹ Refer to the application manual "Electronic gear" for further details.

¹⁰ Refer to the operating instructions of the expansion modules with system bus.

Digital Inputs		Function
750 - OUT-PZD3 Boolean	11	Process data for Profibus-communication. Module CM-PDP with Profibus interface is necessary.
751 - OUT-PZD4 Boolean		Process data for Profibus-communication. Module CM-PDP with Profibus interface is necessary.
752 - OUT-PZD5 Boolean		Process data for Profibus-communication. Module CM-PDP with Profibus interface is necessary.
753 - OUT-PZD6 Boolean		Process data for Profibus-communication. Module CM-PDP with Profibus interface is necessary.
810 Obj 0x3003 DigOut 1 to 814 Obj 0x3003 DigOut 5	12	Source of CAN objects for CANopen-communication. Module CM with CAN interface necessary.
832 Obj 0x3005 Demux to 847 Demux Out 1 to Obj 0x3005 Demux Out 16		Source of the demultiplexer output for CANopen-communication. Module CM with CAN interface necessary.
876 - Position Comparator Out		The current actual value is in the range between <i>Switch-on position 1243</i> and <i>Switch-off position 1244</i> .
877 - Position Comparator Out inverted	13	Operation mode 876 inverted.
887 - MBC: Start Clockwise		Message clockwise operation of positioning controller.
888 - MBC: Start Anticlockwise		Message anticlockwise operation of positioning controller.
891 - Motion-Block Digital Signal 1		Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 1 1218</i> were fulfilled. „Start“, „Reference value reached“ and „End“ of a travel order were evaluated.
892 - Motion-Block Digital Signal 2		Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 2 1219</i> were fulfilled. „Start“, „Reference value reached“ and „End“ of a travel order were evaluated.
893 - Motion-Block Digital Signal 3		Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 3 1247</i> were fulfilled. „Start“, „Reference value reached“ and „End“ of a travel order were evaluated.
894 - Motion-Block Digital Signal 4		Message on status of a travel order during a positioning operation. The conditions set for parameter <i>Digital Signal 4 1248</i> were fulfilled. „Start“, „Reference value reached“ and „End“ of a travel order were evaluated.
895 to 898		Operation modes 891 to 894 inverted (LOW active).
910 Output DeMux Bit 0 to 925 Output DeMux Bit 15	14	Bit 0 to Bit 15 on output of de-multiplexer; de-multiplexed process data signal via system bus or Profibus on input of multiplexers (parameter <i>DeMux Input 1253</i>).
2401 FT-Output Buffer 1 to 2416 FT-Output Buffer 16	15	Output signals from FT-instructions of the function table.

¹¹ Refer to the operating instructions of the expansion modules with Profibus interface.

¹² Refer to the operating instructions of the expansion modules with CAN interface.

¹³ Refer to the application manual "Positioning" for further details.

¹⁴ Refer to the operating instructions of the expansion modules with system bus or Profibus interface.

¹⁵ Refer to the application manual "Function Table" for further details.

15.4.1 Start command


The parameters *Start Clockwise* **68** and *Start Anticlockwise* **69** can be linked to the available digital control inputs or the internal logic signals. The drive is only accelerated according to the control method after a start command.

The logic functions are used for the specification of the direction of rotation, but also for using the parameterized *Operation mode* **620** for the starting behavior and *Operation mode* **630** for the stopping behavior.

15.4.2 3-wire control

In the case of 3-wire control, the drive is controlled using digital pulses. The drive is prepared for starting via the logic state of the signal *Start 3-wire control* **87** and started by a Start clockwise pulse (Parameter *Start clockwise* **68**) or a Start anticlockwise pulse (Parameter *Start anticlockwise* **69**). By switching off the signal *Start 3-wire control* **87**, the drive is stopped.

The control signals for Start clockwise and Start anticlockwise are pulses. The functions Start clockwise and Start anticlockwise for the drive are latching-type functions when signal *Start 3-wire control* **87** is switched on. Latching is cancelled when the latching signal is switched off.



(R) Clockwise
(L) Anticlockwise

(1) Signals are ignored
(2) Time $t < 32$ ms

The drive is started according to the configured starting behavior if the signal *Start 3-wire control* **87** is switched on and a positive signal edge for Start clockwise or Start anticlockwise is detected.

Once the drive has started, new edges (1) on the start signals will be ignored. If the start signal is shorter than 32 ms (2) or if both start signals were switched on within 32 ms (2), the drive will be switched off according to the configured stopping behavior.

3-wire control is activated with parameter *Local/Remote* **412**:

<i>Local/Remote</i> 412	Function
Control 3-wire, 5 - sense of rot. via contacts	3-wire; control of direction of rotation and signal <i>3-wire control</i> 87 via contacts.
Control via 3-wire + KP, 46 - dir. of rot. via contacts + KP	3-wire and control unit; control of direction of rotation and signal <i>3-wire control</i> 87 via contacts or control unit.

For further operation modes of parameter *Local/Remote* **412**, refer to chapter „Bus Controller“.

15.4.3 Error Acknowledgment

The frequency inverters feature various monitoring functions which can be adapted via the error and warning behavior. Switching the frequency inverter off at the various operating points should be avoided by an application-related parameterization. If there is a fault switch-off, this report can be given via the parameter *Program(ming)* **34** or the logic signal can be acknowledged with parameter *Error acknowledgment* **103**.

15.4.4 Timer

The time functions can be selected via the parameters *Operation mode Timer 1* **790** and *Operation mode Timer 2* **793**. The sources of the logic signals are selected with the parameters *Timer 1* **83** and *Timer 2* **84** and processed according to the configured timer functions.

15.4.5 Thermo contact

The monitoring of the motor temperature is a part of the error and warning behavior which can be configured as required. The parameter *Thermocontact* **204** links the digital input signal to the defined *Operation mode Motor-PTC* **570** which is described in chapter "Motor Temperature". The temperature monitoring via a digital input checks the input signal for the threshold value. Accordingly, a thermocontact or an additional circuit must be used if a temperature-dependent resistor is used.

15.4.6 n-/M Control Change-Over

The field-orientated control procedures in configurations 230, 430, 530 and 630 contain the functions for speed or torque-dependent control of the drive. The change-over can be done in ongoing operation, as an additional functionality monitors the transition between the two control systems. The speed controller or the torque controller is active, depending on the *n-/M control change-over* **164**.

15.4.7 Data Set Change-Over


Parameter values can be stored in four different data sets. This enables the use of various parameter values depending on the current operation point of the frequency inverter. The change-over between the four data sets is done via the logic signals assigned with the parameters *Data set change-over 1* **70** and *Data set change-over 2* **71**.

The actual value parameter *active data set* **249** shows the selected data set.

Activation		
Data set change-over 1 70	Data set change-over 2 71	Function / active data set
0	0	Data set 1 (DS1)
1	0	Data set 2 (DS2)
1	1	Data set 3 (DS3)
0	1	Data set 4 (DS4)

0 = contact open 1 = contact closed

If *Configuration* **30** = 110, 111, 410, 411, 430, 510, 530, 610, 611 or 630 is selected, in the factory setting a timer function is interconnected between the digital input S4IND and the data set change-over 1.



The data set change-over 1 is linked with timer 1:

Data set change-over 1 **70** = 158 – Timer 1

Timer 1 is linked with the digital input S4IND (terminal X210A.6):

Timer 1 = 73 – S4IND

In the factory setting the data set change-over 1 is not affected by the Timer 1:

Signal delay *Time 1 Timer 1* **791** = 0.00 s/m/h

Signal duration *Time 2 Timer 1* **792** = 0.00 s/m/h

15.4.8 Fixed Value Change-Over

As a function of the selected configuration, the reference figures are specified via the assignment of the *Reference frequency source* **475** or *Reference percentage source* **476**. Accordingly, there can be a change between the fixed values by connection of the logic signals with the parameters *Fixed frequency change-over 1* **66**, *Fixed frequency change-over 2* **67** or the parameters *Fixed percent change-over 1* **75**, *Fixed percent change-over 2* **76**.

By combining the logic states of the fixed frequency change-over modes 1 and 2, fixed frequencies 1 through 4 can be selected:

Fixed Frequency Control		
<i>Fixed frequency change-over 1</i> 66	<i>Fixed frequency change-over 2</i> 67	Function / active fixed value
0	0	<i>Fixed Frequency 1</i> 480
1	0	<i>Fixed Frequency 2</i> 481
1	1	<i>Fixed Frequency 3</i> 482
0	1	<i>Fixed Frequency 4</i> 483

0 = contact open 1 = contact closed

By combining the logic states of the fixed percentage change-over modes 1 and 2, fixed frequencies 1 through 4 can be selected:

Fixed Percentage Control		
<i>Fixed percentage change-over 1</i> 75	<i>Fixed percentage change-over 2</i> 76	Function / active fixed value
0	0	<i>Fixed Percentage 1</i> 520
1	0	<i>Fixed Percentage 2</i> 521
1	1	<i>Fixed Percentage 3</i> 522
0	1	<i>Fixed Percentage 4</i> 523

0 = contact open 1 = contact closed

15.4.9 Motor Potentiometer

The parameters *Reference frequency source* **475**, and *Reference percentage source* **476** contain operation modes with motor potentiometer. The *Operation mode* **474** defines the behavior of the motor potentiometer function and the parameters *Frequency Motorpoti Up* **62**, *Frequency Motorpoti Down* **63** or *Percent Motorpoti Up* **72**, *Percent Motorpoti Down* **73** the connection with the available logic signals.

Motor Potentiometer Control		
Motorpoti Up	Motorpoti Down	Function
0	0	Output signal does not change.
1	0	Output value rises at set ramp.
0	1	Output value drops at set ramp.
1	1	Output value is reset to initial value.

0 = contact open 1 = contact closed

15.4.10 Handshake Traverse Function

Via parameter *Handshake Traverse Function* **49**, the signal source is selected for specification of the direction of rotation of the slave drive of the shot-effect function. The shot-effect function is switched on via parameter *Operation mode* **435**.

15.4.11 User warning

For setting up external warnings parameters *User Warning 1* **1363** and *User Warning 2* **1364** can be used. Parameterization of a user warning enables triggering a warning in the device via a digital signal if a critical state in the plant occurs. The warning is displayed in *Warnings Application* **273** and can be transmitted to a higher-level control like a PLC. Please check parameter *Create warning mask application* **626** and chapter 15.3.9 „Application warning mask“ for further explanations

15.4.12 External error

Parameterization of an external error enables switching off or shutting down several frequency inverters at a time if a fault occurs in the plant or the drive. If an error occurs in a frequency inverter, the error signal can be transmitted via a bus system and the required reaction can be triggered in another frequency inverter. Parameter *External error* **183** can be assigned the logic signal or digital input signal which is to trigger the external error.

Via parameter *Operation mode ext. error* **535**, the response to an external error can be configured.

Operation mode 535	Function
0 - Disabled	No response to external errors.
1 - Error-Switch-Off	The drive is switched off and the error message „F1454 External Error“ is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
2 - Shutdown, Error	The drive is stopped at the current deceleration ramp and the error message „F1454 External Error“ is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
3 - Emergency-Stop, Error	The drive is stopped at the current emergency stop ramp and the error message „F1454 External Error“ is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.

For setting up external warnings parameters *User Warning 1* **1363** and *User Warning 2* **1364** can be used. Check chapter 15.3.9 „Application warning mask“ for further details.

15.5 Function Modules


15.5.1 Timer

The timer function can be linked to various functions for time-control of digital signals.

The parameters *Operation Mode Timer 1 790* and *Operation Mode Timer 2 793* define the evaluation of the digital input signals and the unit of time of the time function.

Operation Mode 790, 793	Function
0 - Off	Signal output is switched off.
1 - Normal, Rising Edge, Sec.	Positive signal edge starts timer (trigger), time 1 delays the output signal, time 2 defines the signal period.
2 - Retrigger, Rising Edge, Sec.	Positive signal edge starts timer (trigger), next positive signal edge within time 1 starts the delay in time again (Retrigger), time 2 defines the signal period.
3 - AND-Connect., Rising Edge, Sec.	Positive signal edge starts timer (trigger), if no input signal is received within time 1 the delay starts again (Retrigger), if no input signal is received within time 2, the signal period is terminated.
11 to 13	Operation modes 1...3, negative signal edge starts timer.
101 to 113	Operation modes 1...3, [in minutes].
201 to 213	Operation modes 1...3, [in hours].

By default, the functions are linked according to the following illustration:



The sources of the digital signals (e.g. 73 - S4IND) are selected via the parameters *Timer 1 83* and *Timer 2 84*. In the factory setting Timer 1 is linked to digital input 4 and Timer 2 is switched off.

The output signal of the timer can be assigned to an inverter function or to a digital output. By default, *Data Set Change-Over 1* is linked to Timer 1 and Timer 2 is not linked.

Note: The factory setting is *Time 2 Timer 1 792* = 0. Signals at digital input S4IND are transmitted to the Data Set Change Over 1 without time delay.

Function	Parameter for input signal	Operation mode	Time constant	Function output signal	
Timer 1	<i>Timer 1 83</i>	<i>Operation Mode Timer 1 790</i>	<i>Time 1 Timer 1 791</i> <i>Time 2 Timer 1 792</i>	158 ¹⁾ -	Timer 1
				23 ²⁾ -	
Timer 2	<i>Timer 2 84</i>	<i>Operation Mode Timer 2 793</i>	<i>Time 1 Timer 2 794</i> <i>Time 2 Timer 2 795</i>	159 ¹⁾ -	Timer 2
				24 ²⁾ -	

¹⁾ For linking with inverter functions

²⁾ For digital output

15.5.1.1 Timer – Time Constant

The logic sequence of input and output signals is to be set separately for both timer functions via the time constants. The default parameter values result in a direct link of the input and output signal without a delay.



Before starting the timer, select the operation mode and set the time constants in order to avoid non-defined states.


Select operation mode for:	Set time constants in:
<i>Operation Mode Timer 1 790</i>	<i>Time 1 Timer 1 791</i> (signal delay) <i>Time 2 Timer 1 792</i> (signal duration)
<i>Operation Mode Timer 2 793</i>	<i>Time 1 Timer 2 794</i> (signal delay) <i>Time 2 Timer 2 795</i> (signal duration)

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
791	Time 1 Timer 1, signal delay	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h
792	Time 2 Timer 1, signal duration	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h
794	Time 1 Timer 2, signal delay	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h
795	Time 2 Timer 2, signal duration	0.00 s/m/h	650.00 s/m/h	0.00 s/m/h

Examples of the timer function depending on the selected operation mode and the input signal:

Normal, positive edge

Parameter *Operation Mode Timer 1 790* or *Operation Mode Timer 2 793* = 1




As soon as the positive signal edge is received at the input, time 1 (signal delay) starts. After the expiry of time 1 (signal delay), the output signal is switched on for time 2 (signal duration).

In the settings of signal duration (*Time 2 Timer 1 792* = 0 and *Time 2 Timer 2 795* = 0) the timer does not reset the output signal.

Retrigger, positive edge

Parameter *Operation Mode Timer 1 790* or *Operation Mode Timer 2 793* = 2




As soon as the positive signal edge is received at the input, time 1 (signal delay) is started. If a positive signal edge is detected within time 1 (signal delay), time 1 starts again. After the expiry of time 1 (signal delay), the output signal is switched on for time 2 (signal duration).

In the settings of signal duration (*Time 2 Timer 1 792* = 0 and *Time 2 Timer 2 795* = 0) the timer does not reset the output signal.

⏏: Time not run out completely
⏏: Time run out completely

AND connection, positive edge

Parameter *Operation Mode Timer 1 790* or *Operation Mode Timer 2 793* = 3




- 1) As soon as the positive signal edge is received at the input, time 1 (signal delay) is started.
- 2) If a positive signal edge is detected within time 1 (signal delay), time 1 starts again (retrigger).
- 3) After the expiry of time 1 (signal delay), the output signal is switched on for the time 2 (signal duration).
- 4) Within the time 2 (signal duration), the output is switched off by the input signal (AND-connection).
- 5) If the input signal is present during the whole time 2 (signal duration), the output signal remains on in this time.

◄-----: Time not run out completely

◄----->: Time run out completely

Factory settings: Time 1 = 0, Time 2 = 0



In the factory settings the output signal follows the input signal.

15.5.2 Comparator

With the help of software functions Comparator 1 and 2, various comparisons of actual values with percentage-adjustable fixed values can be done.

The actual values to be compared can be selected from the following table with the parameters *Op. Mode Comparator 1* **540** and *Op. Mode Comparator 2* **543**.

If an expansion module is connected, further operation modes are available.


Operation mode 540, 543	Function
0 - Off	Comparator is switched off.
1 - Absolute current	<i>R.m.s Current</i> 211 > <i>Rated Current</i> 371 .
2 - Abs. Active Current	<i>Active current</i> 214 > <i>Rated current</i> 371 .
3 - Abs. Stator Frequency	<i>Stator frequency</i> 210 > <i>Maximum frequency</i> 419 .
4 - Abs. Actual Speed 1	<i>Speed Sensor 2 Speed</i> 220 > maximum speed (calculated from <i>Maximum Frequency</i> 419 and <i>No. of Pole Pairs</i> 373).
5 - Abs. Actual Repetition Freq.	<i>Repetition frequency input</i> 252 > <i>Maximum frequency</i> 419 .
6 - Winding Temp., Temp. Follow-Up.	<i>Winding temperature</i> 226 > temperature 100 °C
7 - Abs. Actual Frequency	<i>Actual frequency</i> 241 > <i>Maximum frequency</i> 419 .
9 - DC –Link Voltage	<i>DC Link Voltage</i> 222 > Direct voltage 1000 V.
10 - Abs. Isq	<i>Isq</i> 216 > <i>Rated Current</i> 371 .
11 - Abs Filtered Active Current	<i>Active current</i> 214 > <i>Rated current</i> 371 .
12 - Abs. Internal Ref. Frequency	<i>Internal Reference Frequency</i> 228 > <i>Maximum Frequency</i> 419 .
13 - Abs. Ref. Percentage Value	<i>Reference Percentage Value</i> 229 > <i>Maximum Reference Percentage</i> 519 .
14 - Abs. Actual Percentage Value	<i>Actual Percentage Value</i> 230 > <i>Maximum Reference Percentage</i> 519 .
15 - Abs. Analog Input MF11A	<i>Analog Input MF11A</i> 251 > input signal 100 %
100 to 107, 111, 112	Operation modes with signs (+/-).

The switch-on and switch-off thresholds for comparactors 1 and 2 are set by the parameters *Comparator on above* **541**, **544** and *Comparator off below* **542**, **545**.

The percentage limits of the corresponding reference values are indicated.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
541	Comparator 1 On above	- 300.00 %	300.00 %	100.00 %
542	Comparator 1 Off below	- 300.00 %	300.00 %	50.00 %
544	Comparator 2 On above	- 300.00 %	300.00 %	100.00 %
545	Comparator 2 Off below	- 300.00 %	300.00 %	50.00 %

The setting of the percentage limits of the comparators enables the following logical links. The comparison with signs is possible in the corresponding operation modes of the comparators.



Example:

Op. Mode Comparator 1 **540** = 7- Abs. Actual Frequency

Comparator On above **541** = 80.00 % (of *Maximum Frequency* **419**)

Comparator Off below **542** = 50.00 % (of *Maximum Frequency* **419**)

Maximum Frequency **419**. = 50.00 Hz

➔ Comparator will switch on if *Actual Frequency* **241** > 40.00 Hz

➔ Comparator will switch off if *Actual Frequency* **241** < 25.00 Hz

Output signals

Digital signals indicate the result of the comparison.

Comparator 1

171 -	Output Comparator 1	¹⁾	The comparison – selected via <i>Op. Mode Comparator 1</i> 540 – is true.
20 -	Comparator 1	²⁾	
172 -	Negated Output Comparator 1	¹⁾	The comparison – selected via <i>Op. Mode Comparator 1</i> 540 – is true. The output level of the comparator is inverted.

Comparator 2

173 -	Output Comparator 2	¹⁾	The comparison – selected via <i>Op. Mode Comparator 2</i> 543 – is true.
21 -	Comparator 2	²⁾	
174 -	Negated Output Comparator 2	¹⁾	The comparison – selected via <i>Op. Mode Comparator 2</i> 543 – is true. The output level of the comparator is inverted.

¹⁾ For linking with inverter functions

²⁾ For digital output

15.5.3 Function table

The function table allows to link external digital signals and internal logic signals of the frequency inverter with each other. Besides standard AND, OR and XOR combinations, different more advanced logic functions like RS Flip Flop are available. The corresponding output value can be used for further logic instructions and digital outputs. The logic instructions can be linked with each other for any complex interconnections.

Up to 32 logic instructions allow flexible adoption of various input signals.

Example:

A drive should start when:

- the enable signal AND the S5IND signal are set
- OR
- the enable signal AND the S6IND signal are set.

Refer to the application manual "Function table" for a more detailed description.

15.5.4 Multiplexer/Demultiplexer

The multiplexer/demultiplexer enables the transfer of various digital signals between an overriding controller and frequency inverters via field bus or between frequency inverters via the system bus. For parameterization of the multiplexer and demultiplexer using the VTable application, the commissioning and diagnosis software VPlus, version 4.0.2 or higher is required.

Multiplexer:

The multiplexer features 16 inputs for logic signals or digital input signals. On the output, the logic signal 927 - Output MUX for the inputs of the TxPDO process data of the system bus or for PZDx-IN process data of the Profibus can be used.

Operation mode		Factory setting	
1252	Mux inputs	7 -	Off

The parameters *Mux input index (write)* **1250** and *Mux input index (read)* **1251** for the input signals of the multiplexer enable parameterization via the control unit KP500 or the application VTable in VPlus.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
1250	Mux input index (write) ¹⁾	0	33	1
1251	Mux input index (read)	0	33	1

¹⁾ Non-volatile (fixed parameterization):		Volatile:	
0:	All indices in EEPROM	17	All indices in RAM
1...16:	One Index of 1...16 in EEPROM	18...33:	One Index of 1...16 in RAM

NOTE

The setting "0" for *Mux input index (write)* **1250** changes all data in EEPROM and RAM.

In the case of non-volatile storage (0...16), the changed values are still available when power supply is switched on again.

In the case of volatile storage (17...33), the data is only stored in RAM. If the unit is switched off, this data is lost and the data required are loaded from EEPROM after restart.

Demultiplexer:


The demultiplexer features an input *DeMux Input* **1253** whose signal can be for the process data RxPDO of the system bus or OUT-PZDx of Profibus.

On the output of the demultiplexer, the logic signals "910 - Output DeMux Bit 0" to "925 - Output DeMux Bit15" are available, e.g. for control of FT-instructions.

Operation modes for <i>DeMux input</i> 1253	
9 -	Zero
704 ... 727 -	RxPDO Word
740, 741 -	Remote control word, remote state word
754 ... 757 -	OUT-PZD word
900 -	Controller status
927 -	Output MUX

Demultiplexer outputs	
910 ... 925 -	Output DeMux Bit 0 ... output DeMux Bit 15

Example: Transfer of a user-defined status word from a slave to a master via system bus or Profibus, parameterization of multiplexer and demultiplexer using PC application VTable in VPlus



Settings on transmitter:

- In VPlus, start application VTable via the button bar.
- In VTable assign the required signal sources for sending to parameter *Mux. inputs* 1252 index 1 to index 16. (a setting for index 0 results in this setting being taken over for all other indices.)
- Assign a TxPDO process data parameter of the system bus or a PZDx-IN process data parameter of Profibus to signal source "927 - Output MUX".

Settings on receiver:

- Assign the corresponding RxPDO signal sources of the system bus or OUT-PZD signal sources of Profibus to parameter *DeMux input* 1253.


The transmitted signals are available at the receiver as signal sources 910 to 925.

16 V/f-Characteristic

The sensorless control in configurations 110 and 111 is based on the proportional change of output voltage compared to the output frequency according to the configured characteristic.

By setting the V/f-characteristic, the voltage of the connected 3-phase motor is controlled according to the frequency. The torque to be applied by the motor at the corresponding operating point demands the control of the output voltage proportional to the frequency. At a constant output voltage / output frequency ratio of the frequency inverter, the magnetization is constant in the nominal operating range of the 3-phase motor. The rating point of the motor or end point of the V/f-characteristic is set via the guided commissioning with the parameter *Cut-off voltage* **603** and the parameter *Cut-off frequency* **604**.

The lower frequency range, where an increased voltage is necessary for the start of the drive, is critical. The voltage at output frequency = zero is set with the parameter *Starting voltage* **600**. An increase in voltage deviating from the linear course of the V/f-characteristic can be defined by the parameters *Voltage rise* **601** and *Rise frequency* **602**. The percentage parameter figure is calculated from the linear V/f-characteristic. Via the parameters *Minimum frequency* **418** and *Maximum frequency* **419**, the working range of the machine or the V/f-characteristic is defined.



(FMIN): *Minimum frequency* **418**, (FMAX): *Maximum frequency* **419**,

(US): *Starting voltage* **600**,

(UK): *Voltage rise* **601**, (FK): *Rise frequency* **602**

(UC): *Cut-off voltage* **603**, (FC): *Cut-off frequency* **604**

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
600	Starting voltage	0.0 V	100.0 V	5.0 V
601	Voltage rise	-100 %	200 %	10 %
602	Rise frequency	0 %	100 %	20 %
603	Cut-off voltage	60.0 V	560.0 V	400.0 V
604	Cut-off frequency	0.00 Hz	999.99 Hz	50.00 Hz



The guided commissioning takes the parameterized rated motor values and reference data of the frequency inverter into account when it comes to pre-setting the V/f-characteristic. In the case of three-phase machines, the speed can be increased at a constant torque if the motor winding can be switched over from star to delta connection. If the data for delta connection indicated on the rating plate of the three-phase motor were entered, the cut-off frequency is increased automatically by the square root of three.

The default *Cut-off voltage* **603 (UC)** and *Cut-off frequency* **604 (FC)** are derived from the motor data *Rated voltage* **370** and *Rated frequency* **375**. With the parameterized *Starting voltage* **600 (US)**, the linear equation of the V/f-characteristic results.

$$U = \left(\frac{UC - US}{FC - 0} \right) \cdot f + US = \left(\frac{400.0 \text{ V} - 5.0 \text{ V}}{50.00 \text{ Hz} - 0.00 \text{ Hz}} \right) \cdot f + 5.0 \text{ V}$$

The *Rise frequency* **602 (FK)** is entered as a percentage of the *Cut-off frequency* **604 (FC)**, the default value is $f=10 \text{ Hz}$. The output voltage for the default *Voltage rise* **601 (UK)** is calculated as $U=92.4 \text{ V}$.

$$U = \left[\left(\frac{UC - US}{FC - 0} \right) \cdot (FK \cdot FC) + US \right] \cdot (1 + UK) = \left[\left(\frac{400 \text{ V} - 5 \text{ V}}{50 \text{ Hz} - 0 \text{ Hz}} \right) \cdot (0.2 \cdot 50 \text{ Hz}) + 5 \text{ V} \right] \cdot 1.1 = \underline{\underline{92.4 \text{ V}}}$$

16.1 Dynamic Voltage Pre-Control

The *Dyn. voltage pre-control* **605** accelerates the control behavior of the current limit controller (parameter *Operation mode* **610**) and the voltage controller (parameter *Operation mode* **670**). The output voltage value resulting from the V/f characteristic is changed by addition of the calculated voltage pre-control.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
605	Dyn. voltage pre-control	0 %	200 %	100 %

17 Control Functions

The frequency inverters provide a selection of established control methods in *Configuration 30*. The selected control structure can be parameterized as required and optimized for the application by further functions.

17.1 Intelligent current limits

The current limits to be set according to the application avoid inadmissible loading of the connected load and prevent a fault switch-off of the frequency inverter. The function extends the current controller available in the control system. The overload reserve of the frequency inverter can be used optimally by means of the intelligent current limits, in particular in applications with dynamic load alternations. The criterion to be selected via the parameter *Operation Mode 573* defines the threshold to the activation of the intelligent current limit. The parameterized rated motor current or the reference current of the frequency inverter is synchronized as the limit value of the intelligent current limits.

<i>Operation Mode 573</i>	Function
0 - Off	The function is switched off.
1 - Ixt	Limitation to the overload of the frequency inverter (Ixt).
10 - T _c	Limitation to the maximum heat sink temperature (T _c).
11 - Ixt + T _c	Operation mode 1 and 10 (Ixt + T _c).
20 - Motor temp.	Limitation to the motor temperature (T _{Motor}).
21 - Motor temp. + Ixt	Operation mode 20 and 1 (T _{Motor} + Ixt).
30 - T _c + Motor temp.	Operation mode 10 and 20 (T _c + T _{Motor}).
31 - T _c + Motor temp. + Ixt	Operation mode 10, 20 and (T _c + T _{Motor} + Ixt).

The threshold value selected via the parameter *Operation Mode 573* is monitored by the intelligent current limits. In the operation modes with motor and heat sink temperature monitoring, the reduction of power selected with the parameter *Power limit 574* is done when the threshold value has been reached. This is achieved by a reduction of the output current and the speed in motor operation. The load behavior of the connected machine must be a function of the speed to ensure a sensible use of the intelligent current limits. The total time of the power reduction as a result of an increased motor or heat sink temperature contains not only the cooling time, but also the additionally defined *Limitation time 575*.

The definition of the power limit should be selected as small as possible in order to give the drive sufficient time to cool down. The reference value is the rated output of the frequency inverter or the set rated power of the motor.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
574	Power Limit	40.00 %	95.00 %	80.00 %
575	Limitation time	5 min	300 min	15 min

In the operation modes with overload reserve (Ixt) there is a reduction of the output current when the threshold value is exceeded, with a distinction being made between long and short-term overload reserve. After the short-term overload (1 s) has been used up, the output current is reduced to the long-term overload current matching the present switching frequency. After the long-term overload current has been used up (60 s), the output current is reduced to the rated current which also depends on the switching frequency.

If the output current has already been reduced due to the fact that the long-term overload has used up, the short-term overload is no longer available even if it has not been used up beforehand. The defined overload reserve (Ixt) of the frequency inverter is available again after a power reduction lasting 10 minutes.

Output signals

Digital outputs can signalize the achievement of a limit value – selected in *Operation Mode 573*.

15 -	Warning Current Limitation	Intelligent Current Limits active. Output current is limited.
16 -	Controller Current Limit. Long Term Ixt	The overload reserve for 60 s has been used up and the output current is being limited.
17 -	Controller Current Limit. Short Term Ixt	The overload reserve for 1 s has been used up and the output current is being limited.
18 -	Controller Current Limit. Tc	Intelligent Current Limits active. Maximum heat sink temperature Tc reached.
19 -	Controller Current Limit. Motor Temp.	Intelligent Current Limits active. Maximum motor temperature reached.

17.2 Voltage controller

The voltage controller contains the functions necessary for monitoring the DC link voltage.

- The DC link voltage which rises in generator operation or in the braking process of the 3-phase machine is controlled to the set limit value by the voltage controller.
- The power failure regulation uses the rotation energy of the drive to bridge short-term power failures.

The voltage controller is set with the parameter *Operation Mode 670* in accordance with the application.

<i>Operation Mode 670</i>	Function
0 - Off	The function is switched off. Brake and Motor chopper are active and switch with the parameterized thresholds of P506 and P507.
1 - Udc-Limitation active	DC link limitation active. Overvoltage controller switched on, the Brake and Motor chopper are active and switch with the parameterized thresholds of P506 and P507. Factory setting.
2 - Mains Support active	Power failure regulation switched on. Brake and Motor chopper are active and switch with the parameterized thresholds of P506 and P507. Suitable for quick shut-down.
3 - Udc-Limit. & Mains Supp. active	Overvoltage controller and power failure regulation switched on, with motor chopper.
12 - Mains Support active, Chopper not active	Power failure regulation switched on. During the Mains Support, motor and brake chopper are deactivated. In all other cases motor and brake chopper are active and switch with the parameterized thresholds of P506 and P507.
13 - Udc-Limit. & Mains Supp. active, Chopper not active	Overvoltage controller and power failure regulation switched on. During the Mains Support, motor and brake chopper are deactivated. In all other cases motor and brake chopper are active and switch with the parameterized thresholds of P506 and P507.

The function motor chopper is available in the field-oriented control methods (in configurations 210, 230, 410, 411 and 430).

When an operation mode with motor chopper is selected, set the *Trigger Threshold* **507** < (*Reference DC-Link Limitation* **680** - 10 V). See chapter 18.7.1 "Motor Chopper".



For synchronous motors (*Configuration* **30** = 5xx), the motor chopper function is deactivated to prevent damages to the motor. The other functions of the voltage controller are not affected by this.


For asynchronous motors in V/f control (*Configuration* **30** = 1xx), the motor chopper function is not operative. The other functions of the voltage controller are not affected by this.



The brake chopper is active dependent of the setting of *Reference DC-Link Limitation* **680**. See chapter 18.4 "Brake Chopper and Brake Resistance" for parameterizing the switching threshold.

Operation mode Overvoltage control,

Voltage controller: Parameter *Operation mode* **670** = 1




The overvoltage controller prevents a switch-off of the frequency inverter in generator operation. The reduction of the drive speed by a ramp gradient selected via the parameter *Deceleration Clockwise* **421** or *Deceleration Anticlockwise* **423** can lead to an overvoltage in the DC link. If the voltage exceeds the figure set by the parameter *Reference DC link limitation* **680**, the deceleration is reduced in such a way that the DC link voltage is regulated to the set value. If the DC link voltage cannot be regulated to the set reference value by the reduction of the deceleration, the deceleration is stopped and the output frequency raised. The output frequency is calculated by addition of the parameter value *Max. Frequency Rise* **681** to the frequency at the operating point of the controller intervention.

Parameter		Settings			
No.	Description	ACU	Min.	Max.	Fact. sett.
680	Reference DC link limitation	201	225	387.5	380 V
		401	425	775	760 V
681	Max. Frequency Rise	201/401	0.00 Hz	999.99 Hz	10.00 Hz

When an operation mode with motor chopper is selected, set the *Trigger Threshold* **507** < (*Reference DC-Link Limitation* **680** - 10 V). See chapter 18.7.1 "Motor Chopper".

Operation mode power failure regulation.

Voltage controller: Parameter *Operation mode* **670** = 2



With the power failure regulation, short-term power failures can be bridged. Mains failure is detected when the DC link voltage has dropped below the set value of parameter *Mains Failure Threshold* **671**. If a mains failure is detected, the controller tries to regulate the DC link voltage to the value set with parameter *Reference Mains Support Value* **672**. To that end, the output frequency is continuously reduced and the motor with its rotating masses is switched over to generator operation. Using field oriented Control (FOC, SERVO) the reduction of the output frequency is done according to the configuration with a maximum of the current set by the parameter *Gen. Ref. Current Limit* **683**.



Gen. Ref. Current Limit **683** is active in configurations 410 and 610 (FOC and SERVO).

The threshold values of the voltage controller are calculated starting with the current DC link voltage with the parameters *Mains failure threshold* **671** and *Reference mains support value* **672**.

Output signals

Digital signals indicate mains failure and power failure regulation.

179 - Mains failure	¹⁾	Mains failure and power failure regulation – selected via <i>Operation Mode</i> 670 of the voltage controller.
13 - Mains failure	²⁾	

¹⁾ For linking with inverter functions

²⁾ For digital output


If the mains voltage is restored before a switch-off is affected by the mains undervoltage detection system, the drive is accelerated to its reference frequency at the set acceleration or according to the parameter *Acceleration on mains resumption* **674**. If the value of parameter *Acceleration on mains resumption* **674** is set to the default value of 0.00 Hz/s, the drive is accelerated at the values set for the ramp parameters *Acceleration (clockwise)* **420** or *Acceleration (anticlockwise)* **422**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
671	Mains failure threshold	-200.0 V	-50.0 V	-100.0 V
672	Reference mains support value	-200.0 V	-10.0 V	-40.0 V



The frequency inverter reacts to the signals at the control inputs both when the power failure regulation is switched on and in normal operation. A control via externally supplied control signals is only possible in the case of a no-break supply. As an alternative, supply for the control signals through the frequency inverter is to be used.

Operation mode power failure regulation



The DC link voltage which is available in the case of a power failure is supplied by the motor. The output frequency is continuously reduced and the motor with its rotating masses is switched over to generator operation. The maximum reduction of the output frequency is done at the current set by the parameter *Gen. ref. current limit* **683** or the ramp *Mains support deceleration* **673** until the frequency limit *Shutdown threshold* **675** is reached. If the energy of the system for bridging the mains failure is not sufficient, the delay is affected at maximum ramp gradient as from the *Shutdown threshold* **675**.

The time required until the motor has come to a standstill results from the regenerative energy of the system which results in an increase in the DC link voltage. The DC link voltage set with the parameter *Reference shutdown value* **676** is used by the voltage controller as a control figure and kept constant. The voltage rise enables optimization of the braking behavior and the time until the drive has come to a standstill. The behavior of the controller can be compared to stopping behavior 2 (Shutdown + Stop), as the voltage controller brings the drive to a standstill at the maximum deceleration ramp and supplies it with the remaining DC link voltage.

If the DC-link voltage is restored before the shutdown of the drive, but after falling below *Shutdown Threshold* **675**, the drive is still decelerated to standstill.

If the mains voltage is restored after the shutdown of the drive but before the undervoltage switch-off has been reached, the frequency inverter signals a fault. The control unit displays the fault message "F0702".

If the mains failure without shutdown (*Shutdown threshold* **675** = 0 Hz) takes so long that the frequency has been reduced to 0 Hz, the drive is accelerated to the reference frequency when the mains supply is restored.

If the mains failure with or without shutdown takes so long that the frequency inverter shuts off completely (LED's = OFF), the frequency inverter will be in the "Standby" state when the mains supply is restored. If the inverter is released again, the drive will start. If the drive is to start automatically after restoration of the mains supply if the inverter is released permanently, *Operation mode 651* of Auto Start must be switched on.

Parameter		Settings			
No.	Description	ACU	Min.	Max.	Fact. sett.
675	Shutdown Threshold		0.00 Hz	999.99 Hz	0.00 Hz
676	Reference Shutdown Value	201	225	387.5	365
		401	425	775	730



Reference Shutdown Value 676 becomes effective below the frequency value *Shutdown Threshold 675*.

The voltage controller uses the limit values of the DC link voltage. The frequency change necessary for this is parameterized by the generator reference current value or the ramp. The *Gen. ref. current limit 683* or the ramp *Mains support deceleration 673* defines the maximum deceleration of the drive necessary in order to reach the voltage value *Reference mains support value 672*. The *Acceleration on mains resumption 674* replaces the set values of the ramp parameters *Acceleration (clockwise) 420* or *Acceleration anticlockwise 422* if the figure set in the factory is changed. The voltage control in a mains failure changes from the frequency limit *Shutdown threshold 675* from *Reference mains support value 672* to the *Reference shutdown value 676*.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
683	Gen. ref. current limit	0.0 A	$\ddot{u} \cdot I_{FUN}$	I_{FUN}
673	Mains support deceleration	0.01 Hz/s	9999.99 Hz/s	50.00 Hz/s
674	Acceleration on mains resumption	0.00 Hz/s	9999.99 Hz/s	0.00 Hz/s



Mains Support Deceleration 673 is active in configuration 1xx (V/f).

Gen. Ref. Current Limit 683 is active in configurations 2xx, 4xx and 5xx (FOC and SERVO).

The proportional and integrating part of the current controller can be set via parameters *Amplification 677* and *Integral time 678*. The control functions are deactivated by setting the parameters to 0. The controllers are P and I controllers in the corresponding settings.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
677	Amplification	0.00	30.00	1 ¹⁾
				2 ²⁾
678	Integral time	0 ms	10000 ms	8 ms ¹⁾
				23 ms ²⁾

The factory settings depend on the selected configuration and control procedure. According to the setup of parameter *Configuration 30* there is the following assignment.


¹⁾ Configurations 1xx

²⁾ Configurations 4xx, 2xx, 5xx, 6xx

17.3 Technology Controller

The technology controller, the behavior of which corresponds to a PID controller, is available as an additional function in configuration 111, 211, 411 and 611. The connection of reference and actual value of the application with the functions of the frequency inverter enables process control without further components. In this way, applications such as pressure, volume flow or speed control can be implemented easily. The configuration of the reference percentage source and the assignment of the actual percentage source are to be considered.

Structural image: Technology Controller



Comply with the following chapters of the manual:

Parameter	Chapter
Controller reference value: <i>Reference Percentage Source 476</i> Monitoring of the current controller reference value: <i>Reference Percentage Value 229</i>	14.5 „Reference percentage channel“ 19.1 „Actual Values of the Frequency Inverter“
Controller actual value: <i>Actual Percentage Source 478</i> is: - Analog signal at multifunction input: <i>Operation Mode 452</i> - Frequency signal at a digital input: <i>Operation Mode 496</i> Monitoring of the current controller actual value: <i>Actual Percentage Value 230</i>	17.3 „Technology Controller“ 15.1 „Multi-Function Input MF11“ 14.11 „PWM-/repetition frequency input“ 19.1 „Actual Values of the Frequency Inverter“

For the reference value, the technology controller also demands the assignment of an analog application figure with the parameter *Actual percentage source 478*. The difference between reference and actual value is used by the technology controller to control the drive system. The measured actual value is mapped via a signal converter onto the input signal of the reference percentage source.

<i>Actual percentage source 478</i>	Function
1 - Analog input MF11A	The analog signal on the multifunction input 1 in analog <i>Operation mode 452</i> .
32 - Repetition frequency input (F3)	The frequency signal on the digital input corresponding to the selected <i>Operation mode 496</i> .

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
58	Technology Controller Release	Selection		6- On

Via parameter *Technology Controller Release 58* the technology controller can be halted. The P and D part remain at the value before switching off. The output value and the I part resets with each switching off of the *Technology Controller Release 58*.




The default assignment of parameter *Start clockwise 68* to the logic signal of the technology controller must be observed:

Start Clockwise 68 = 13 - Technology Controller Start.

This assignment may not be changed. The technology controller becomes active with the controller release at digital input S1IND/STOA.

Structural image: Inputs for reference percentage source



The function selected via the parameter *Operation mode 440* defines the behavior of the technology controller.

<i>Operation mode 440</i>	Function
0 - off	The technology controller is switched off; the reference value specification is done via the reference percentage channel.
1 - Standard	For pressure and volume flow control with linear operating behavior and actual value monitoring.
2 - Liquid Level 1	Contents level control at defined motor speed with actual value missing.
3 - Liquid Level 2	Contents level control at defined motor speed with actual value missing or high control deviation.
4 - Speed Controller	Speed control with analog feedback of the actual speed.
5 - Indirect Volume Flow Control	Volume flow control with square rooted actual value.

The behavior of the technology controller corresponds to a PID controller with the components

- proportional component *Amplification* **444**
- integral component *Integral time* **445**
- differential component *Derivative time* **618**

The sign of the amplification determines the direction of control, i.e. with a rising actual value and pos. sign of the amplification, the output frequency is reduced (e.g. in pressure control). With a rising actual value and neg. sign of the amplification, the output frequency is increased (e.g. in temperature control systems, refrigerating machines, condensers).

The integral component can be used to reduce the steady-state control deviation (deviation between actual value and reference value) over a period of time. If the integral component is too dynamic¹⁾ the system will be unstable and oscillates. If the integral component is too passive²⁾ the steady-state control deviation will not be corrected adequately.

Therefore the integral component must be adjusted installation-dependent.

¹⁾ Dynamic behavior: fast correction of deviations.

²⁾ Passive behavior: slow correction of deviations.

In the factory setting *Derivative time* **618** = 0 ms the differential component is disabled.

If the control behavior of the PI controller (or P controller) is too slow the setting of the differential component (*Derivative time* **618**) allows a faster control. If the differential component is enabled the system tends to oscillate, so that the differential component should be enabled and set carefully.

BONFIGLIOLI VECTRON recommends setting the values of *Integral time* **445** and *Derivative time* **618** higher than the sample time, which is 2 ms at the ACU device.

Parameter *Max. P-Component* **442** limits the frequency change at the controller output. This prevents oscillations of the system at steep acceleration ramps.

Via Parameter *Hysteresis* **443** changes of the integral component outside a specified range (hysteresis band) can be suppressed. This causes more passive behavior of the technology controller. This can be helpful when the stator frequency cannot follow the reference frequency of the Technology controller. *Hysteresis* **443** is related to *Rated frequency* **375**, in most cases therefore 50 Hz.

The hysteresis acts as a limiter at the input of the integral part. Excessive differences between the stator current and the output of the controller technology are so limited and so prevent excessive integration of the integral value.


$\left \frac{f_{tech} - f_{stator}}{Rated\ frequency\ 375} \right \geq Hysteresis\ 443$	<p>The deviation Δ between Reference frequency of the Technology Controller (f_{tech}) and Stator frequency (f_{stator}) is too big. The Integrator is halted.</p>
$\left \frac{f_{tech} - f_{stator}}{Rated\ frequenz\ 375} \right < Hysteresis\ 443$	<p>The Stator frequency (f_{stator}) can follow the reference frequency of the technology controller sufficiently. The deviation Δ is small enough.</p>

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
441	Fixed Frequency	-999.99 Hz	+999.99 Hz	0.00 Hz
442	Max. P-Component	0.01 Hz	999.99 Hz	50.00 Hz
443	Hysteresis	0.01 %	100.00 %	10.00 %
444	Amplification	-15.00	+15.00	1.00
445	Integral Time	0 ms	32767 ms	200 ms
446	Ind. Volume Flow Control Factor	0.10	2.00	1.00
618	Derivative Time	0 ms	1000 ms	0 ms

In modes 1,2,3 and 5, the output frequency is shifted along the ordinate axis to the *Minimum Frequency 418*. The percentage of the technology controller output value corresponds to:

0 % = *Minimum Frequency 418*

100 % = *Maximum Frequency 419*



The parameterization of the technology controller in the individual data sets enables an adaptation to various operating points of the application with the data set change-over via control contacts.



The technology controller operates in motor clockwise operation. The direction of rotation can be changed via parameter *Change Sense of Rotation 1199*. Refer to chapter 10.2.8 „Change sense of rotation“.


Operation mode standard, parameter *Operation mode* 440 = 1

This operation mode can be used, for example, for pressure or volumetric flow control with linear operation behavior.

The minimum value monitoring prevents an acceleration of the drive if the actual value is missing.

If the actual value is missing (< 0.5%) the output frequency is guided to the *Minimum frequency* 418. This is done using the set *Deceleration (clockwise)* 421.

If the actual value is available again, the controller continues operation automatically.



Operation mode filling level 1, parameter *Operation mode* 440 = 2

This operation mode can be used, for example, for contents level control.


If the actual value is missing, the function brings the output frequency to an adjustable value.

The minimum value monitoring prevents an acceleration of the drive if the actual value is missing.

If the actual value is missing ($< 0.5\%$) the output frequency is guided to the *Fixed frequency* **441**. This is done using the set *Deceleration (clockwise)* **421**.

The *Fixed frequency* **441** must be in the range between *Minimum frequency* **418** and *Maximum frequency* **419**. If the *Fixed frequency* **441** is set to a value smaller than the *Minimum frequency* **418**, the output frequency is guided to *Minimum frequency* **418**. The frequency will not drop below *Minimum frequency* **418**.

If the actual value is available again, the controller continues operation automatically. The Integral value is reset when the Actual value returns.



Operation mode filling level 2, parameter *Operation mode* 440 = 3


This operation mode can be used, for example, for contents level control.

The minimum value monitoring prevents an acceleration of the drive if the actual value is missing.

If the actual value is missing ($< 0.5\%$) the output frequency is guided to the *Fixed frequency* 441. This is done using the set *Deceleration (clockwise)* 421.

If there is no control deviation (actual value = reference value) or if the control deviation is negative (actual value > reference value), the output frequency is guided to *Minimum frequency* 418. This is done using the set Controller settings. Additionally *Deceleration (clockwise)* 421 limits the ramp. If *Minimum frequency* 418 = 0 Hz, the power stage is switched off in this case.

The drive accelerates as soon as an actual value is present again or the control deviation exceeds the positive *Hysteresis* 443. The drive stops if Actual value \geq Reference value, the control output reached 0 Hz and *Minimum frequency* 418 = 0 Hz is set.




Operation mode speed controller, parameter *Operation mode 440 = 4*

This operation mode is suited for speed controls with an analog actual value transmitter (e.g. analog speedometer via analog input or HTL encoder via frequency input).

The motor is accelerated or decelerated according to the control deviation.

The output frequency is limited by the *Maximum frequency 419*.



NOTE

Minimum Frequency 418 is not limiting in mode "4-Speed". This can lead to a long time operation of the motor in the current injection (current frequency < 624 cutoff frequency) in configurations 411 and 611. Prevent an impermissible motor temperature rise through to long operation in the current injection. The operating mode "4-speed controller" can lead to a reversal of the drive.


Operation mode indirect volume flow control,
parameter *Operation mode* 440 = 5

This operation mode is suitable for volume flow control based on pressure measurement.


The square rooted actual value enables, for example, direct measurement of the active pressure in the system via the intake nozzle of the fan. The active pressure has a square proportion to the volume flow and thus forms the control figure for the volume flow control. The calculation corresponds to the "Law of Proportionality" which is generally valid for centrifugal machines.

Adaptation to the application in question and measurement are done via the *Ind. vol. flow control factor* 446. The actual values are calculated from the system data to be parameterized, reference pressure and volume flow, according to the bad point method, as described in chapter "Volume Flow and Pressure".

The output frequency is limited by the *Minimum frequency* 418 and *Maximum frequency* 419.



Structural image: Indirect volume flow control



17.4 Functions of Sensorless Control

The configurations of the sensorless control contain the following additional functions, which supplement the behavior according to the parameterized V/f characteristic.

17.4.1 Slip compensation

The load-dependent difference between the reference speed and the actual speed of the 3-phase motor is referred to as the slip. This dependency can be compensated by the current measurement in the output phases of the frequency inverter.

The activation of *Operation mode 660* for the slip compensation enables as speed control without feedback. The stator frequency and speed are corrected depending on the load.

The slip compensation is activated during the guided commissioning. The *Stator Resistance 377* is required to ensure a correct function and is measured during the guided commissioning.

If no guided commissioning is executed, the slip compensation can be activated manually. In these cases, enter the value for the *Stator Resistance 377* manually according to the motor data sheet.

<i>Operation mode 660</i>	Function
0 - Off	The slip compensation is deactivated.
1 - On	The load-dependent slip speed is compensated.

The control behavior of the slip compensation can only be optimized via the parameters in the case of specific applications. The parameter *Amplification 661* determines the correction of the speed and the effect of the slip compensation proportionally to the change of load. The *Max. Slip ramp 662* defines the max. frequency change per second in order to avoid an overload in the case of a load change.

The parameter *Minimum frequency 663* determines the frequency as from which the slip compensation becomes active.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
661	Amplification	0.0 %	300.0 %	100.0 %
662	Max. Slip Ramp	0.01 Hz/s	650.00 Hz/s	5.00 Hz/s
663	Minimum Frequency	0.01 Hz	999.99 Hz	0.01 Hz

17.4.2 Current limit value controller

Via a load-dependent speed control, the current limit value controller ensures that the drive system is not overloaded. This is extended by the intelligent current limits described in the previous chapter. The current limit value controller reduces the load on the drive, e.g. during acceleration, by stopping the acceleration ramp. The switch-off of the frequency inverter which happens when the acceleration ramps have been set at an excessive gradient is prevented in this way.

The current limit value controller is switched on and off via parameter *Operation mode 610*.

<i>Operation mode 610</i>	Function
0 - Off	The current limit value controller functions and the intelligent current limits have been deactivated.
1 - On	The current limit value controller is active.

Behavior in motor operation:

If the current set via parameter *Current limit 613* is exceeded, the activated current limit value controller will reduce the output frequency until the current limit is no longer exceeded. The output frequency is reduced as a maximum to the frequency set by the parameter *Frequency limit 614*. If the *Current limit 613* is fallen short of, the output frequency is raised back to the reference value.

Behavior in generator operation:

If the current set via parameter *Current limit 613* is exceeded, the activated current limit value controller will increase the output frequency until the current limit is no longer exceeded. The output frequency is increased, as a maximum, to the set *Maximum frequency 419*. If the current is below the *Current limit 613*, the output frequency is reduced to the required reference value again.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
613	I limit	0.0 A	$\ddot{U} \cdot I_{FUN}$	$\ddot{U} \cdot I_{FUN}$
614	Frequency Limit	0.00 Hz	999.99 Hz	0.00 Hz

The control behavior of the current limit value controller can be set via the proportional component, the parameter *Amplification 611*, and the integrating component, the parameter *Integral time 612*. If an optimization of the controller parameters is necessary in exceptional cases, a setting should be done by a jump alteration of the parameter *Current limit 613*.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
611	Amplification	0.01	30.00	1.00
612	Integral time	1 ms	10000 ms	24 ms



The dynamics of the current limit value controller and the voltage controller is influenced by the setting of the parameter *Dyn. voltage pre-control 605*.

17.5 Functions of Field-Orientated Control

The field-orientated control systems are based on a cascade control and the calculation of a complex machine model. In the course of the guided commissioning, a map of the connected machine is produced by the parameter identification and transferred to various parameters. Some of these parameters are visible and can be optimized for various operating points.

17.5.1 Current Controller

The inner control loop of the field-orientated control comprises two current controllers. The field-orientated control thus impresses the motor current into the machine via two components to be controlled.

This is done by:

- controlling the flux-forming current value I_{sd}
- controlling the torque-forming current value I_{sq}

By separate regulation of these two parameters, a decoupling of the system equivalent to an externally excited direct current machine is achieved.

The set-up of the two current controllers is identical and enables joint setting of amplification as well as the integral time for both controllers. For this, the parameters *Amplification 700* and *Integral time 701* are available. The proportional and integration component of the current controllers can be switched off by setting the parameters to zero.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
700	Amplification	0.00	8.00	0.13
701	Integral time	0.00 ms	10.00 ms	10.00 ms

The guided commissioning has selected the parameters of the current controller in such a way that they can be used without having to be changed in most applications. If, in exceptional cases, an optimization of the behavior of the current controller is to be done, the reference value jump during the flux-formation phase can be used for this. The reference value of the flux-forming current components leaps to the figure *Current during flux-formation 781* with suitable parameterization and then changes controlled to the magnetizing current after the expiry of the *Maximum flux-formation time 780*. The operating point necessary for the adjustment demands the setting of parameter *Minimum Frequency 418* to the value 0.00 Hz, as the drive is accelerated after magnetizing. The measurement of the step response, which is defined by the ratio of the currents mentioned, should be done in the motor supply line by means of a measuring current transformer of a sufficient bandwidth.



The internally calculated actual value for the flux-forming current component cannot be output via the analog output for this measurement as the time resolution of the measurement is not sufficient.

To set the parameters of the PI controller, the *Amplification 700* is increased first until the actual value overshoots distinctly during the control process. Now, the amplification is reduced to about fifty percent again and then the *Integral time 701* is synchronized until actual value overshoots slightly during the control process.

The settings of the current controllers should not be too dynamic in order to ensure a sufficient reserve range. The control tends to increased oscillations if the reverse range is reduced.

The dimensioning of the current controller parameters by calculation of the time constant is to be done for a switching frequency of 2 kHz. For other switching frequencies, the values are adapted internally so that the setting can remain unchanged for all switching frequencies. The dynamic properties of the current controller improve if the switching and scanning frequency increases.

The fixed time interval for the modulation results in the following scanning frequencies of the current controller via parameter *Switching frequency 400*.

Settings	
Switching frequency	Scanning frequency
2 kHz ¹⁾	2 kHz
4 kHz	4 kHz
8 kHz	8 kHz
12 kHz	8 kHz
16 kHz	8 kHz

¹⁾ This switching frequency can be set for parameter *Min. switching frequency 401*.

17.5.2 Extended Current Controller

For some machines it might be necessary, that for different current ranges different Amplification factors must be set up.

The following classification applies:

- Current < *Current below P. 777 is in effect 776*
→ *Amplification low Current 777*
- *Current above P. 700 is in effect 775* > Current
> *Current below P. 700 is in effect 757* → *Amplification 700*
- Current > *Current above P. 759 is in effect 758* → *Amplification high Current 759*

By default, the parameters are pre-assigned so that the parameters are not active and only the basic parameters are active.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
757	Current below P. 700 is in effect	0.00	$o * I_{FIN}$	$o * I_{FIN}$
758	Current above P. 759 is in effect	0.00	$o * I_{FIN}$	$o * I_{FIN}$
759	Amplification high Current	0.00	8.00	0.00
775	Current above P. 700 is in effect	0.00	$o * I_{FIN}$	0.00
776	Current below P. 777 is in effect	0.00	$o * I_{FIN}$	0.00
777	Amplification low Current	0.00	8.00	0.00

I_{FIN} = Nominal Output current of Frequency inverter

o: Overload capability of Frequency inverter

The motor autotuning changes the parameters.

17.5.3 Torque Controller

The torque-controlled configurations 230, 430, 530 and 630 can be used for sensorless torque control alternative to the speed control. The torque control is usable above the *Frequency Limit 624*. Below the *Frequency Limit 624* the current impression is active with the current reference frequency as reference value. In this case the torque is not controlled, but results depending on the load and the *Starting current 623*. To achieve a starting in torque control, the reference frequency should be set higher than *Frequency Limit 624*. This is guaranteed in example by setting *Minimum frequency 418* > *Frequency Limit 624*.

$f < \text{Frequency Limit 624}$: Current impression

$f \geq \text{Frequency Limit 624}$: Direct Torque Control

The *Frequency Limit 624* is set automatically during the motor setup.

17.5.3.1 Torque Reference

The reference torque can be specified as follows:

- Set parameter *n-/T-Control Change-Over* **164** to "6 - On" or link it to a digital signal and switch this on.
- Via parameter *Reference Percentage Source 1* **476** or *Reference Percentage Source 2* **494**, select a source for the reference torque.

For example:

- The reference torque can be set via the arrow keys of the operator panel if the following setting is selected: *Reference Percentage Source 2* **494** = "5 - keypad motorpoti (factory setting)".
- The reference torque can be set via multifunction input 1 (MFI1A) if the following setting is selected: *Reference Percentage Source 1* **476** = "1 - analog value MFI1A (factory setting)".
- 100 % Torque refer to the calculated Torque from *Rated Mech. Power* **376** (Motor power) and *Rated Speed* **372** (Motor nominal speed).

Parameter *Torque* **224** shows the actual torque.

Select an applicable operation mode for parameter *Operation Mode Flying Start* **645**. Refer to chapter 12.5 "Search Run".

17.5.3.2 Upper and lower limit of the frequency in Torque Control

In many cases limitation of the speed is required in the operating points with reduced or without load torque, because the speed regulates itself to the torque reference and the load behavior. To avoid an unintentional speed (mostly too high speeds, in some cases also too small speeds and avoidance of current impression), the frequency is limited by *Frequency upper limit* **767** and *Frequency lower limit* **768** by the speed controller.

As from the limit value the drive is controlled to maximum speed (*Frequency Upper Limit* **767** and *Frequency Lower Limit* **768**), which corresponds to the behavior of the speed controller. Additionally, the controller limits the speed to *Maximum Frequency* **419**. This limitation is set by the speed controller – changes in the speed controller affect the speed behavior in the limit area of the 3 mentioned parameters.

In the current impression, the speed is limited additional to *Minimum Frequency* **418** – in Direct Torque Control this limit is not active.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
767	Frequency upper limit	-999.99 Hz	999.99 Hz	999.99 Hz
768	Frequency lower limit	-999.99 Hz	999.99 Hz	-999.99 Hz



Positive values limit the speed in clockwise direction; negative values limit the speed in anticlockwise direction. In example, if both values are positive (> 0 Hz), anticlockwise movement is inhibited.



WARNING

If the torque control is activated while the actual frequency lies outside the defined range of *Frequency Upper Limit* **767** and *Frequency Lower Limit* **768** (in example when switching on a stopped machine or when the Flying start synchronizes), the allowed frequency is driven to without ramps. The torque is only limited by the limitations of the speed controller (current and torque). Therefore an unexpected dynamic behavior can occur.

17.5.3.3 Limit Value Sources

The limitation of the frequency can be done by setting fixed values and by linking to an analog input parameter. The analog value is limited via parameters *Minimum reference percentage* **518** and *Maximum reference percentage* **519**, but does not consider the *Gradient percentage ramp* **477** of the reference percentage value channel.

The assignment is done for the torque controller via parameters *Frequency upper limit source* **769** and *Frequency lower limit source* **770**.

Operation mode 769, 770	Function
101 - Analog input MF11A	The source is the multifunctional input 1 in analog <i>Operation mode</i> 452 .
110 - Fixed limit	The selected parameter values are taken into account to limit the speed controller.
201 - Inv. analog input MF11A	Operation mode 101, inverted.
210 - Inv. fixed limit value	Operation mode 110, inverted.

17.5.3.4 Switching over between speed control and torque control

Via the signal assigned to parameter *n-/T-Control Change-Over* **164**, you can switch between speed control and torque control. See chapter 15.4.6 "n-/M Control Change-Over".

17.5.4 Speed controller


The source of the actual speed value is selected via parameter *Actual Speed Source* **766**. By default, speed sensor 1 is used as the actual speed source. If speed sensor 2 of an expansion module is to deliver the actual value signal for the speed controller, speed sensor 2 must be selected as the source. Alternatively, the speed controller can derive the actual speed value from the machine model in configurations 4xx and 6xx (*Parameter Configuration* **30**).

Operation mode 766	Function
1 - Speed Sensor 1	The actual speed source is speed sensor 1 of the basic device (factory setting).
2 - Speed Sensor 2	The actual speed source is speed sensor 2 of an expansion module. ¹⁾
3 - Machine Model	The speed controller receives the calculated actual speed value from the machine model. Can be set in configurations 4xx and 6xx.
4 - Speedtracking EC 1	Speed synchronization by comparison between the calculated machine model and speed sensor 1 to increase speed accuracy. Can be set in configurations 4xx and 6xx. Adjustment for parameter <i>Integral Time Speedtracking</i> 515 is considered.
5 - Speedtracking EC 2	Speed synchronization by comparison between the calculated machine model and speed sensor 2 of an expansion module to increase speed accuracy. Can be set in configurations 4xx and 6xx. Adjustment for parameter <i>Integral Time Speedtracking</i> 515 is considered.

¹⁾ Only available if expansion module is installed

The control of the torque-forming current components is done in the outer control loop by the speed controller. Via parameter *Operation mode* **720**, you can select the operation mode for the speed controller. The operation mode defines the use of the parameterizable limits. These are referred to the direction of rotation and the direction of the torque and depend on the selected configuration.

Operation mode 720	Function
0 - Speed controller off	The controller is deactivated or the torque-forming component is zero.
1 - Limits motor / generator	The limitation of the speed controller assigns the upper limit to the motor operation of the drive. Independent of the direction of rotation, the same limit is used. The same applies in the case of regenerative operation with the lower limit.
2 - Limits pos. / neg. torque	The assignment of the limit is done by the sign of the value to be limited. Independent of the motor or generator operating points of the drive, the positive limitation is done by the upper limit. The lower limit is regarded as a negative limitation.



The properties of the speed controller can be adapted for adjustment and optimization of the controller. The amplification and integral time of the speed controller are to be set via the parameters *Amplification 1 721*, *Integral time 1 722*. For the second speed range, the parameters can be set via the parameters *Amplification 2 723*, *Integral time 2 724*. The distinction between the speed ranges is done by the parameter *Speed control switch-over limit 738*. The parameters *Amplification 1 721* and *Integral time 1 722* are taken into account with the parameter *Speed control switch-over limit*. If parameter *Speed control switch-over limit 738* is set to a value higher than 0.00 Hz, parameters *Amplification 1 721*, *Integral time 1 722* are active below the limit and parameters *Amplification 2 723*, *Integral time 2 724* are active above the limit.

The control deviation can be filtered with the *filter time constant 754* if necessary. Therefore the operation with static control deviation with occasional undesired deviations can be stabilized, while at the same time the dynamic behavior in load change operation (speed change or changing torque demand) suffers.

The parameterized amplification at the current operating point can additionally be assessed via the parameter *Backlash damping 748* depending on the control deviation. In particular the small signal behavior in applications with a gearbox can be improved by a value higher than zero percent.

Parameter *Backlash damping 748* is available depending on the type of unit.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
721	Amplification 1	0.00	200.00	- ¹⁾
722	Integral time 1	0 ms	60000 ms	- ¹⁾
723	Amplification 2	0.00	200.00	- ¹⁾
724	Integral time 2	0 ms	60000 ms	- ¹⁾
754	Filter time constant	0 ms	128 ms	0 ms
738	Speed control switch-over limit	0.00 Hz	999.99 Hz	55.00 Hz
748	Backlash damping	0 %	300 %	100 %

¹⁾ The default setting is relative to the recommended machine data for the amplification and integral time. This enables a first function test in a large number of applications. Switch-over between settings 1 and 2 for the current frequency range is done by the software according to the selected limit value.

The optimization of the speed controller can be done with the help of a reference value leap. The amount of the leap is defined by the set ramp or limitation. The optimization of the PI controller should be done at the maximum admissible reference figure change rate. First, the amplification is increased until the actual value overshoots distinctly during the control process. This is indicated by a strong oscillation of the speed and by the running noises. In the next step, reduce the amplification slightly (1/2 ...3/4 etc.). Then reduce the integral time (larger I component) until the actual value overshoots only slightly in the control process.


If necessary, check the speed control settings in the case of dynamic operations (acceleration, deceleration). The frequency at which a switch-over of the controller parameters is affected can be set via parameter *Speed control switch-over limit* **738**.

17.5.4.1 Limitation of Speed Controller

The output signal of the speed controller is the torque-forming current component I_{sq} . The output and the I component of the speed controller can be limited via parameters *Current limit* **728**, *Current limit generator operation* **729**, *Torque limit* **730**, *Torque limit generator operation* **731** or *Power limit* **739**, *Power limit generator operation* **740**. The limits of the proportional component are set via parameter *P component torque upper limit* **732** and parameter *P component torque lower limit* **733**.

- The output value of the controller is limited by an upper and a lower current limit, parameter *Current limit* **728** and parameter *Current limit generator operation* **729**. The limit figures are entered in Amperes. The current limits of the controller can be linked to the fixed limits and analog input parameters. The assignment is done via the parameters *Isq limit source motor operation* **734** and *Isq limit source generator operation* **735**.
- The output value of the controller is limited by an upper and a lower torque limit, parameter *Torque limit* **730** and parameter *Torque limit generator operation* **731**. The limit values are input as a percentage of the rated motor torque. The assignment of fixed values or analog limit values is done via the parameters *Torque limit source, motor op.* **736** and *Torque limit source, generator op.* **737**.
- The output value of the P component is limited with parameter *P comp. torque upper limit* **732** and *P comp. torque lower limit* **733**. The limit values are input as torque limits as a percentage of the rated motor torque.
- The power output by the motor is proportional to the product of speed and torque. This output power can be limited at the controller output with *Power limit* **739** and *Power limit generator operation* **740**. The power limits are entered in kW.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
728	I limit	0.0 A	$\ddot{u} \cdot I_{FUN}$	$\ddot{u} \cdot I_{FUN}$
729	Current limit generator operation	-0.1 A	$\ddot{u} \cdot I_{FUN}$	$\ddot{u} \cdot I_{FUN}$
730	Torque limit	0.00 %	650.00 %	650.00 %
731	Torque limit generator operation	0.00 %	650.00 %	650.00 %
732	P comp. torque upper limit	0.00 %	650.00 %	100.00 %
733	P comp. torque lower limit	0.00 %	650.00 %	100.00 %
739	Power Limit	0.00 kW	$2 \cdot \ddot{u} \cdot P_{FUN}$	$2 \cdot \ddot{u} \cdot P_{FUN}$
740	Power limit generator operation	0.00 kW	$2 \cdot \ddot{u} \cdot P_{FUN}$	$2 \cdot \ddot{u} \cdot P_{FUN}$



17.5.4.2 Limit Value Sources

As an alternative to limiting the output values by a fixed value, linking to an analog input value is also possible. The analog value is limited via parameters *Minimum reference percentage 518* and *Maximum reference percentage 519*, but does not consider the *Gradient percentage ramp 477* of the reference percentage value channel.

The assignment is done with the help of the parameters *Isq limit source motor operation 734* and *Isq limit source generator operation 735* for the torque-forming current component Isq.

The sources for the torque limits can be selected via the parameters *Torque limit source, motor op. 736* and *Torque limit source generator op. 737*.

Operation mode 736, 737	Function
101 - Analog input MF11A	The source is the multifunctional input 1 in analog <i>Operation mode 452</i> .
105 - Repetition frequency input (F3)	The frequency signal on the repetition frequency input corresponding to <i>Operation mode 496</i> .
110 - Fixed limit	The selected parameter figures for limiting the speed controller are taken into account.



The limit values and assignment to different limit value sources are data set related in the configurations. The use of the data record change-over demands an examination of the parameters in question.

17.5.4.3 Integral time speed synchronization

For speed synchronization and in order to increase the speed accuracy, the integrating portion of the speed control can be set via parameter *Integral time speed synchronization* **515**. The setup is effective in operation modes „4 – speed synchronization DG 1“ and „5 – speed synchronization DG 2“ for parameter *Actual speed source* **766**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
515	Integral time speed synch.	1 ms	60000 ms	5000 ms

17.5.5 Acceleration Pre-Control

The acceleration pre-control is active in the speed-controlled configurations and can be activated via parameter *Operation mode* **725**.

<i>Operation mode 725</i>	Function
0 - Off	The control system is not influenced.
1 - On	The acceleration pre-control is active according to the limit values.

The acceleration pre-control controlled parallel to the speed controller reduces the reaction time of the drive system to a change of reference values. The minimum acceleration time defines the modification speed of the reference speed value as from which a torque necessary for acceleration of the drive is pre-controlled. The acceleration of the mass is a function of the *Mech. time constant* **727** of the system. The value calculated from the increase of the reference value and the multiplication factor of the torque required is added to the output signal of the speed controller.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
726	Minimum acceleration	0.1 Hz/s	6500.0 Hz/s	1.0 Hz/s
727	Mech. time constant	1 ms	60000 ms	10 ms

For optimal setting, the acceleration pre-control is switched on and the mechanical time constant is set to the minimum value. The output value of the speed controller is compared to the minimum acceleration time during the acceleration processes. The frequency ramp is to be set to the highest value occurring in operation at which the output figure of the speed controller is not yet limited. Now, the value of the *Minimum acceleration* **726** is set to half the set acceleration ramp so that it is ensured that the acceleration pre-control is active. The acceleration pre-control is not raised by increasing the *Mech.time constant* **727** until the output figure corresponds to the time modification of the drive during the acceleration processes.

17.5.6 Field Controller

The flux-forming current component is controlled by the field controller. The guided commissioning optimizes the parameters of the field controller by measuring the time constant and magnetizing curve of the connected 3-phase machine. The parameters of the field controller are selected such that they can be used without changes in most applications. The proportional and the integrating part of the field controller are to be set via parameters *Amplification* **741** and *Integral time* **742**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
717	Reference Flux	0.01 %	300.00 %	100.00 %
741	Amplification	0.0	100.0	5.0
742	Integral time	0.0 ms	1000.0 ms	100.0 ms

Please note that changes within the Field controller parameters should only be done in the basic speed area.

When an optimization of the Field controller is necessary, set the *Integral Time* **742** = *Act. Rotor Time Constant* **227** / 2, meaning to the half of the rotor time constant. In most application cases, this change is sufficient.

When further optimizations are necessary, follow the step described in the following procedure.

- Set the output frequency in a way (i.e. via the frequency reference value), that the actual value *Modulation* **223** = 80...90 % *Reference Modulation* **750**.
- Now change the *Flux Reference Value* **717** from 100 % to 90 %. Oscillograph the actuating variable I_{sd} . The course of the signal of the flux-forming current I_{sd} should reach the stationary value after overshooting without oscillation.
- Change the parameters *Amplification* **741** and *Integral Time* **742** according to the application requirements.
- Change the *Flux Reference Value* **717** back to 100 % und repeat the flux reference step while you can analyze the changes with the oscillograph. Repeat these steps if necessary.

If a quick transition into field weakening is necessary for the application, the integral time should be reduced. Increase the *Amplification* **741** in order to achieve a good dynamism of the controller.

An increased overshoot is necessary for a good control behavior in controlling of a load with low-pass behavior, e.g. an asynchronous motor.

Parameter *Reduction Factor Flux* **778** reduces the standstill current if a stopping behavior with the function "R->0, Stop" is selected. This stopping behavior is selected if parameter *Operation Mode* **630** is set to 2x (20 ... 27 – „R->0, Stop, ... “) or x2 (2, 12, 22, 32, 42, 52, 62, 72 – „ ... , R->0, Stop“). The stopping behavior is described in chapter 12.2 "Stopping Behavior".

In these operation modes the setting of *Reduction Factor Flux* **778** becomes effective after the time of parameter *Holding Time* **638** is elapsed. The resulting standstill flux is calculated by multiplying *Reference Flux* **717** and *Reduction Factor Flux* **778**. After a start command the drive starts immediately and the flux is increased up to the reference value during the movement.

Because of the reduced flux the initially required torque-forming current component I_{sq} is increased. The time needed to achieve the reference flux can be influenced by parameter *Ref. Isd Upper Limit* **743** which is set to the motor rated current after setup.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
778	Reduction Factor Flux	20.00%	100.00%	100.00%

17.5.6.1 Limitation of field controller

The output signal of the field controller, the integrating and proportional components are limited via parameter *Ref. Isd upper limit* **743** and parameter *Ref. Isd lower limit* **744**. The guided commissioning has set the parameter *Ref. Isd upper limit* **743** according to the parameter *Rated current* **371**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
743	Ref. Isd upper limit	0	$\ddot{U} \cdot I_{FUN}$	I_{FUN}
744	Ref. Isd lower limit	$- I_{FUN}$	I_{FUN}	0.0

The limits of the field controller define not only the maximum current occurring, but also the dynamic properties of the controller. The upper and lower limits restrict the modification speed of the machine flux and the torque resulting from it. In particular the speed area above the nominal frequency should be observed for the modification of the flux-forming component. The upper limit is to be estimated from the product of the set magnetizing current and the correction factor *Reference flux* **717**, although the limit must not exceed the overload current of the drive.

17.5.7 Modulation Controller

The modulation controller, which is designed as an I regulator, automatically adapts the output value of the frequency inverter to the machine behavior in the basic speed area and in the field weakening area. If the modulation exceeds the figure set with parameter *Reference modulation* **750**, the field-forming current component and thus the flux in the machine are reduced.

In order to make the best possible use of the voltage available, the figure selected via parameter *Operation mode* **753** is put into proportion to the DC link voltage. That means that with a high mains voltage there is also a high output voltage available, the drive only reaches the field weakening area later and produces a higher torque.

<i>Operation mode</i> 753		Function
0 -	Usq-Control	The modulation is calculated from the ratio of torque-forming voltage component U_{sq} to the DC link voltage.
1 -	V-Absolute Value Control	The modulation is calculated from the abs. voltage value / DC link voltage ratio.

The integrating part of the modulation controller is to be set via parameter *Integral time* **752**.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
750	Reference modulator	3.00 %	105.00 %	102.00 %
752	Integral time	0.0 ms	1000.0 ms	10.0 ms

The percentage setting of the *Reference modulation* **750** is basically a function of the leakage inductivity of the machine. The default value was selected such that in most cases the remaining deviation of 5% is sufficient as a reserve range for the current controller. For the optimization of the controller parameters, the drive is accelerated with a flat ramp into the area of field weakening, so that the modulation controller intervenes. The limit is set via parameter *Reference modulation* **750**. Then, the control loop can be excited with a unit step function by modifying the reference modulation (change-over between 95% and 50%). By means of an oscillographed measurement of the flux-forming current component on the analog output of the frequency inverter, the controlling process of the modulation controller can be assessed. The course of the signal of the flux-forming current I_{sd} should reach the stationary value after overshooting without oscillation. An oscillating of the course of the current can be damped by increasing the integral time. The parameter *Integral time* **752** should roughly correspond to the actual value *Act. rotor time constant* **227**.

17.5.7.1 Limitation of Modulation Controller

The output signal of the modulation controller is the internal reference flux. The controller output and the integrating part are limited via the parameter *Reference Imr lower limit* **755** or the product of *Rated magnetizing current* **716** and *Reference flux* **717**. The magnetizing current parameter forming the upper limit is to be set to the rated figure of the machine. For the lower limit, select a value which also builds up an adequate flux in the machine in the field weakening area. The limitation of the control deviation at the output of the modulation controller prevents a possible oscillation of the control loop in the case of load surges. The parameter *Control deviation limitation* **756** is stated as an absolute value and acts both as a positive and a negative limit.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
755	Reference Imr lower limit	$0.01 \cdot I_{FUN}$	$\ddot{U} \cdot I_{FUN}$	$0.01 \cdot I_{FUN}$
756	Control deviation limitation	0.00 %	100.00 %	10.00 %

18 Special Functions

The configurable functions of the corresponding control methods enable another field of application of the frequency inverters. The integration in the application is made easier by special functions.

18.1 Pulse Width Modulation

The motor noises can be reduced by changing over the parameter *Switching frequency* **400**. A reduction of the switching frequency should be up to a maximum ratio of 1:10 to the frequency of the output signal for a sine-shaped output signal. The maximum possible switching frequency depends on the drive output and the ambient conditions. For the required technical data refer to the corresponding table and the device type diagrams.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
400	Switching frequency	2 kHz	16 kHz	2 kHz ¹⁾
				4 kHz ²⁾

The factory setting of parameter *Switching frequency* **400** depends on the setting of parameter *Configuration* **30**:

¹⁾ configurations 1xx

²⁾ configurations 2xx / 4xx/ 5xx

The heat losses increase proportionally to the load point of the frequency inverter and the switching frequency. The automatic reduction adjusts the switching frequency to the current operating state of the frequency inverter in order to provide the output performance required for the drive task at the greatest possible dynamics and a low noise level.

The switching frequency is adapted between the limits which can be set with the parameters *Switching frequency* **400** and *Min. switching frequency* **401**. If the *Min. switching frequency* **401** is larger than or equal to the *Switching frequency* **400**, the automatic reduction is deactivated.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
401	Min. switching frequency	2 kHz	16 kHz	2 kHz

The change of the switching frequency depends on the heat sink temperature switch-off limit and the output current. The temperature limit to be exceeded so that the switching frequency is reduced can be set via parameter *Reduction limit heat sink temp.* **580**. If the heat sink temperature falls below the threshold set via parameter *Reduction limit heat sink temp. Ti/Tk* **580** by 5 °C, the switching frequency is increased again step by step.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
580	Reduction limit Ti/Tk	-25 °C	0 °C	-4 °C



The limit for the switching frequency reduction is influenced by the intelligent current limits depending on the selected *Operation mode* **573** and the output current. If they have been switched off or provide the full overload current, the switching frequency is reduced when the output current exceeds the limit of 87.5% of the long-term overload current (60s). The switching frequency is increased if the output current drops below the reference current of the next highest switching frequency.

18.2 Fan

The switch-on temperature of the heat sink fan can be set with the parameter *Switch-on temperature 39*.

If mains voltage is applied to the frequency inverter, and the heat sink temperature exceeds the set temperature, the heat sink fan is switched on. Independent from parameter *Switch-on temperature 39*, the heat sink fan will be switched on, as soon as the frequency inverter is switched on and enabled and the start signal is received.



To protect the device a device fault is triggered when reaching an internal switching off temperature threshold.

If the heat sink temperature drops below the set temperature by 5 °C, or if the controller enable signal is inhibited, the heat sink fan is switched off when the minimum ON-time has elapsed.

The minimum ON-time of the heat sink fan is set internally to 1 minute. When the temperature drops below the *Switch-on temperature 39* during this time since starting, the fan will continue to operate until the running ON-time is reached.

Operation mode 43 for digital outputs additionally enables the control of an **external** fan. Via the digital output, the fan is switched on if the controller is released and Start clockwise or Start anticlockwise are switched on, or if the *Switch-on temperature 39* for the internal fan was reached.

Like in the case of the internal heat sink fan, the minimum ON-time of the external fan is 1 minute.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
39	Switch-on temperature	0 °C	60 °C	30 °C

18.3 Bus controller

DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.

Wait for 3 minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.



In order to be able to control the drive, the digital controller inputs S1IND/STOA and S7IND/STOB must be connected and set to "High-Signal" in order to enable the output stage.

The frequency inverters can be extended by different options for data communication and can be integrate in an automation and control system in this way. Parameterization and commissioning can be done via the optional communication card, the operating unit or the interface adapter.

The parameter *Local/Remote* **412** defines the operating behavior and enables a change between the control via contacts or the control unit and/or the interface.

<i>Local/Remote</i> 412	Function
0 - Control via Contacts	The Start and Stop commands as well as the direction of rotation are controlled via digital signals.
1 - Control via state machine	The Start and Stop commands as well as the direction of rotation are controlled via the DRIVECOM Statemachine of the communication interface.
2 - Control via remote contacts	The Start and Stop commands as well as the direction of rotation are controlled via logic signals through the communication protocol.
3 - Control via keypad, dir. of rot. via contacts	The Start and Stop commands are controlled from the control unit and the direction of rotation is controlled via digital signals.
4 - Control via KP or cont., dir. of rot. via contacts	The Start and Stop commands are controlled from the control unit or via digital signals. The statement of the direction of rotation only with the help of the digital signals.
5 - Control 3-wire, dir. of rot. via contacts	3-wire; control of direction of rotation and signal <i>3-wire control</i> 87 via contacts.
13 - Control via keypad, dir. of rot. via keypad	The Start and Stop commands as well as the direction of rotation are controlled via the control unit.
14 - Control via KP or cont., dir. of rot. via contacts	The Start and Stop commands are controlled from the control unit or via digital signals. The statement of the direction of rotation only with the help of the operating unit.
20 - Control via cont., clockwise only	The Start and Stop commands are controlled via digital signals. Fixed direction of rotation, clockwise rotation only.
23 - Control via keypad, clockwise only	The start and stop commands are controlled via keypad. Fixed direction of rotation, clockwise rotation only.
24 - Control via cont. + KP, clockwise rot. only	The Start and Stop commands are controlled from the control unit or via digital signals. Fixed direction of rotation, clockwise rotation only.
30 to 34	Operation mode 20 to 24, anticlockwise direction of rotation only.
43 - Control via KP, dir. of rot. via contacts	The start and stop commands are controlled via digital signals. The statement of the direction of rotation comes from the operating unit or via digital signals.
44 - Control via cont. + KP, sense of rot. via cont. + KP	The Start and Stop commands as well as the sense of rotation can be controlled from either the control unit or via digital signals.
46 - Control via 3-wire + KP, dir. of rot. via contacts + KP	3-wire and control unit; control of direction of rotation and signal <i>3-wire control</i> 87 via contacts or control unit.



If the operation mode is changed while the drive is running, the drive will not be stopped if no stop command is present in the new operation mode.

18.4 Brake Chopper and Brake Resistance

The frequency inverters feature a brake chopper transistor. The external brake resistor is connected to terminals Rb1 and Rb2. The parameter *Trigger threshold 506* defines the switch-on threshold of the brake chopper. The generator output of the drive, which leads to the increase in the DC link voltage, is converted to heat by the external brake resistor above the limit set via parameter *trigger threshold 506*.

Parameter		Settings			
No.	Description	ACU	Min.	Max.	Fact. sett..
506	Trigger threshold	201	225	1000.0 V	390
		401	425		780

The parameter *Trigger threshold 506* is to be set in such a way that it is between the maximum DC link voltage which the mains can generate and the maximum admissible DC link voltage of the frequency inverter.


$$U_{\text{Netz}} \cdot 1,1 \cdot \sqrt{2} < U_{d_{\text{BC}}} < U_{d_{\text{max}}}$$

If the parameter *Trigger threshold 506* is set larger than the maximum admissible DC link voltage, the brake chopper cannot become active; the brake chopper is switched off.

If the parameter *Trigger threshold 506* is set to a value below the DC link voltage generated by the mains, error message F0705 (chapter "Error Messages") is displayed if the start command is issued to the frequency inverter.

If the DC link voltage exceeds the maximum value of 400 V for the ACU 201 series of devices or 800 V for the ACU 401 series of devices the error message F0700 is displayed (chapter "Error Messages").

The sampling time of the function is 125 µs. The brake chopper remains on for at least 125 µs after the set trigger threshold was exceeded even if the value drops below the trigger threshold within this period again.



18.4.1 Dimensioning of Brake Resistor



⚠ WARNING

Connect a brake resistor following the instructions and safety information provided in chapter 6.4.4 "Connection of a Brake Resistor".

The following values must be known for dimensioning:

- Peak braking power $P_{b \text{ Peak}}$ in W
- Resistance R_b in Ω
- Operation Time OT in %

• Calculation of peak braking power $P_{b \text{ Peak}}$

$$P_{b \text{ Peak}} = \frac{J \cdot (n_1^2 - n_2^2)}{182 \cdot t_b}$$

$P_{b \text{ Peak}}$	=	Peak braking power in W
J	=	Moment of inertia of drive system kgm^2
n_1	=	Speed of drive system before the braking operation in min^{-1}
n_2	=	Speed of drive system after the braking operation in min^{-1}
t_b	=	Braking time in s

• Calculation of resistance R_b

$$R_b = \frac{U_{d \text{ BC}}^2}{P_{b \text{ Peak}}}$$

R_b	=	Resistance in Ω
$U_{d \text{ BC}}$	=	Switch-on threshold in V
$P_{b \text{ Peak}}$	=	Peak braking power in W

The switch-on threshold $U_{d \text{ BC}}$ is the DC link voltage at which the brake resistor is switched on. The switch-on threshold can be set, as described above, via parameter *Trigger threshold* **506**.



⚠ CAUTION


The resistance of the brake resistor must not be less than the minimum value $R_{b \text{ min}}$ - 10%. The values for $R_{b \text{ min}}$ are listed in chapter 4 "Technical Data".

If the calculated resistance R_b of the brake resistor is between two standard series values, the lower resistance is to be selected.

• Calculation of operation time OT

$$DC = \frac{t_b}{t_{\text{cycle}}}$$

OT	=	Operation time
t_b	=	Braking time
t_{cycle}	=	Cycle time



Example:

$$t_b = 48 \text{ s}, t_{\text{cycle}} = 120 \text{ s}$$

$$DC = \frac{t_b}{t_{\text{cycle}}} = 0.4 = 40\%$$

In the case of infrequent short braking operations, typical values of the operation time OT are at 10 %, for long braking operations ($\geq 120 \text{ s}$) typical values are at 100%. In the case of frequent deceleration and acceleration operations, it is recommended that the operating time OT be calculated according to the above formula.

The calculated values for $P_{b \text{ Peak}}$, R_b and OT can be used by the resistor manufacturers for determining the resistor-specific permanent power.

18.5 Motor Protection

The protection of the motor against impermissible temperature rise requires monitoring mechanisms for recognizing a thermal overload to prevent a possible damage to the motor.

The thermal state of a motor can be evaluated by different ways.

1.) Direct monitoring by temperature sensors inside the motor winding (see chapter 18.5.1).

- PTC
- KTY
- PT100
- Thermal contact

2.) Indirect monitoring of the motor temperature

- Monitoring of the motor current based on the K characteristic of an integrated motor circuit breaker
- Emulation of the motor heating by using a temperature-relevant mathematical model I^2t

The choice of thermal control is mainly determined by type and operating conditions of the motor.

For safe motor protection it is generally sufficient using one of the available possibilities.

A combination of the two groups and their simultaneous operation is possible.

18.5.1 Motor Protection Switch


Motor protection switches are used for protecting a motor and its supply cable against overheating by overload. Depending on the overload level, they disconnect the motor from power supply immediately in the case of a short-circuit or they disconnect the motor if an overload has occurred for some time.

Conventional motor protection switches are commercially available for various applications with different trigger characteristics (L, G/U, R and K), as shown in the diagram on the right. As frequency inverters in most cases are used for supplying motors which are classified as operating equipment with very high starting currents, exclusively the K characteristic was realized in this function.

Unlike the operation of a conventional motor protection switch which disconnects the equipment to be protected immediately if the trigger threshold is reached, this function provides the possibility of issuing a warning instead of disconnecting the equipment immediately.

The rated current of the motor protection switch refers to the rated motor current stated via parameter *Rated current* **371** of the corresponding data set.

The rated values of the frequency inverter are to be considered accordingly when it comes to dimensioning the application.



The function of the motor protection switch can be linked to different data sets. In this way, it is possible to operate different motors via one frequency inverter. Thus, each motor can be equipped with its own motor protection switch.

In case a motor is operated via the frequency inverter for which some setting values, e.g. minimum and maximum frequency, are changed via the data set switch-over, only one motor protection switch may be installed. This functionality can be differentiated by selecting the parameter *Operation mode 571* for single motor operation or multiple motor operation.

<i>Operation Mode 571</i>	<i>Function</i>
0 - Off	The function is deactivated.
1 - K-Char.,Mul.Motor Op.,Err.Sw.Off	In each of the four data sets, the rated values are monitored. Overloading the drive is prevented by the fault switch-off "F0401".
2 - K-Char., Sing.Motor,Err.Sw.-Off	The rated values in the first data set are used independently of the active data set. Overloading the drive is prevented by the fault switch-off "F0401".
11 - K-Char.,Multi-Motor Op.,Warning	In each of the four data sets, the rated values are monitored. Overloading the drive mechanism is signaled by a warning message "A0200".
22 - K-Char.,Single- Motor,Warning	The rated values in the first data set are used independently of the active data set. Overloading the drive mechanism is signaled by a warning message "A0200".
42 - I ² t, Single-Motor, Error Switch Off	See chapter 18.5.2.
51 - I ² t, Multi-Motor Opera- tion, Warning	See chapter 18.5.2.
52 - I ² t, Single-Motor, Warning	See chapter 18.5.2.
61 - I ² t, Multi-Motor Opera- tion, Warning and Er- ror Switch Off	See chapter 18.5.2.
62 - I ² t, Single-Motor, Warning and Error Switch Off	See chapter 18.5.2.
101 - K-Char.,Mul.Motor Op.,Err.Sw.Off, Latching	Like Operation modes 1,2 11, or 22. Additionally the integrated current over the time is stored when the device is switched off and set to the stored value when switched on again.
102 - K-Char., Sing.Motor,Err.Sw.-Off, Latching	
111 - K-Char.,Multi-Motor Op.,Warning, Latching	
122 - K-Char.,Single- Motor,Warning, Latching	

Multiple motor operation

Parameter *Operation Mode* **571** = **1, 11, 101** or **111**

In multiple motor operation, it is assumed that each data set is assigned to a corresponding motor. For this, one motor and one motor protection switch are assigned to each data set. In this operation mode, the rated values of the active data set are monitored. The current output current of the frequency inverter is only taken into account in the motor protection switch activated by the data set. In the motor protection switches of the other data sets, zero current is expected, with the result that the thermal decay functions are taken into account. In combination with the data set change-over, the function of the motor protection switch is similar to that of motors connected alternately to the mains with their own protection switches.

In operation modes **101** and **111** additionally the integrated current over the time is stored when the device is switched off and set to the stored value when switched on again.

Single motor operation

Parameter *Operation Mode* **571** = **2, 22, 102** or **122**

In single motor operation, only one motor protection switch, which monitors the output current of the frequency inverter, is active. In the case of a data set change-over, only the switch-off limits derived from the rated machine parameters are changed over. Accumulated thermal values are used after the change-over as well. In the case of the data set change-over, please ensure that the machine data are stated identically for all data sets. In combination with the data set change-over, the function of the motor protection switch is similar to that of motors connected alternately to the mains with one common protection switch.

In operation modes **102** and **122** additionally the integrated current over the time is stored when the device is switched off and set to the stored value when switched on again.

Reset stable

Parameter *Operation Mode* **571** = **101, 102, 111** or **122**.

The internal state of the motor protection switch is latched reset stable. These settings are to be used when regularly short mains interruptions occur. This way the motor protection is considered correctly for short mains failures or short shut downs of the application.



In settings 101, 102, 111 and 112 of *Operation Mode* **571** the same values should be set in all data sets.

Motor protection, in particular self-ventilation motors, is improved via the *Frequency limit* **572** which can be set as a percentage of the rated frequency. The measured output current in operating points below the frequency limit is assessed by a factor of 2 higher in the calculation of the trigger characteristic.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
572	Frequency Limit	0 %	300 %	0 %

Output signals

Digital signals indicate the triggering of the function "Motor Protection Switch".

180 -	Warning Motor Protection Switch	1)	Triggering of the function "Motor Protection Switch" according to <i>Operation Mode</i> 571 is signaled.
14 -		2)	

¹⁾ For linking with inverter functions

²⁾ For digital output

In calculation the tripping time the measured output current in operating points below the frequency limit is evaluated by a factor between 1 and 2. The determination of this factor is a function of the stator frequency. The increased thermal load of self-ventilated motors in the lower speed range is therefore considered.

The table shows in extracts factors for motor rated frequency 50Hz.

← Frequency limit 572 →									
	300%	200%	150%	100%	80%	60%	40%	20%	10%
Stator frequency [Hz]	0	200%	200%	200%	200%	200%	200%	200%	200%
	5	188%	182%	177%	168%	162%	153%	139%	114%
	10	177%	168%	160%	147%	139%	129%	114%	100%
	20	160%	147%	137%	122%	114%	106%	100%	100%
	30	147%	132%	122%	109%	103%	100%	100%	100%
	50	129%	114%	106%	100%	100%	100%	100%	100%
	100	106%	100%	100%	100%	100%	100%	100%	100%
	150	100%	100%	100%	100%	100%	100%	100%	100%

18.5.2 Motor Protection by I²t- Monitoring

To protect the motor against overload the I²t monitoring provides a further possibility for the user.

This kind of motor protection is mainly used in servo technology. When using servo motors the I²t- monitoring is a proven alternative to motor protection switch. By integrating temperature-dependent parameters, measurable or known, the heating of a mathematical model is simulated.

The kind of the I²t monitoring mode can be selected by *Operation Mode 571*.


This parameter is switchable via data set.

The I²t monitoring works by function $(I_{act}/I_n)^2$ as shown in the figure.

The monitored value is evaluated via a PT1 element with the thermal time constant of the stator.

If the output of PT1 element is bigger than 120%, then an error message is generated and the drive switches off. The threshold of 120% prevents, that an overshoot leads to an immediate shutdown.

In the application should be avoided exceeding 100% capacity of the stator winding permanently.



The output of the first PT1 element is linked to the input of the second PT1 element which includes the thermal motor time constant. This output may be permanently 100%. This corresponds to the complete thermal capacity of the motor. If 102% is reached, the drive switches off with an error message. Both outputs are connected to the adjustable alarm limit.

Operation Mode 571	Function
42 - I ² t, Single-Motor, Error Switch Off	The I ² t capacity of the motor is monitored with rated values from the active dataset. If the fixed threshold values exceed 100% _{motor} (120% _{stator}), the drive switches off with fault "F0401" in the active dataset.
51 - I ² t, Multi-Motor Operation, Warning	The I ² t capacity of the motors regarding their related ratings is monitored in each of the four data sets. If the <i>Warning Limit Motor I²t 615</i> is reached, the warning message "A0200" is signaled from the active data set.
52 - I ² t, Single-Motor, Warning	The I ² t capacity of the motor is monitored with rated values from the active dataset. If the <i>Warning Limit Motor I²t 615</i> is reached, the warning message "A0200" is signaled from the active data set.
61 - I ² t, Multi-Motor Operation, Warning and Error Switch Off	The I ² t capacity of the motors regarding their related ratings is monitored in each of the four data sets. If the <i>Warning Limit Motor I²t 615</i> is reached, the warning message "A0200" is signaled from the active data set. If the fixed threshold values exceed 100% _{motor} (120% _{stator}), the drive switches off with fault "F0401" in the active dataset. Both incidences are triggered from the active dataset.
62 - I ² t, Single-Motor, Warning and Error Switch Off	The I ² t capacity of the motor is monitored with rated values from the active dataset. If the <i>Warning Limit Motor I²t 615</i> is reached, the warning message "A0200" is signaled from the active data set. If the fixed threshold values exceed 100% _{motor} (120% _{stator}), the drive switches off with fault "F0401" in the active dataset. Both incidences are triggered from the active dataset.

The thermal time constant of the motor is in the range from few minutes to a couple of hours. This motor-specific parameter is set via *Thermal time constant motor 608*. Substantially smaller is the thermal stator time constant. To protect the stator winding additional monitoring is required which is determined by *Thermal time constant stator 609*.

These values can be taken from the corresponding motor data sheets. When estimated time constants are used because the required data are not available then an optimal thermal motor protection cannot be guaranteed.

A warning limit allows the user to prevent an imminent I^2t -fault trip through appropriate measures.

Warning limit motor I^2t 615 is used to set the warning signal between 6% and 100% of thermal capacity.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
608	Thermal time constant Motor	1 min	240 min	30 min
609	Thermal time constant Stator	1 s	600 s	15 s
615	Warning Limit Motor I^2t	6%	100%	80%

Output signals

Digital signals indicate the triggering of the function "Motor Protection Switch".

180 -	Warning Motor Protection	1)	Triggering of the function "Motor Protection Switch" according to <i>Operation Mode 571</i> is signaled.
14 -		2)	

1) For linking with inverter functions

2) For digital output

18.6 V-belt Monitoring

Continuous monitoring of the load behavior and thus of the connection between the 3-phase machine and the load is the task of the V-belt monitoring system. Parameter *Operation Mode 581* defines the functional behavior if the *Active Current 214* or the torque-forming current component *Isq 216* (field -orientated control method) drops below the set *Trigger Limit Iactive 582* for a time longer than the set *Delay Time 583*.

<i>Operation mode 581</i>	Function
0 - Off	The function is deactivated.
1 - Warning	If the active current drops below the threshold value, the warning "A8000" is displayed.
2 - Error	The unloaded drive is switched off and fault message "F0402" is displayed.

The error and warning messages can be read out by means of the digital outputs (signal 22 - "Warning V-Belt") or reported to an overriding control system. The *Trigger limit Iactive 582* is to be parameterized as a percentage of the *Rated current 371* for the application and the possible operating points.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
582	Trigger limit Iactive	0.1 %	100.0 %	10.0 %
583	Delay time	0.1 s	600.0 s	10.0 s

18.7 Functions of Field-Orientated Control

The field-orientated control systems are based on a cascade control and the calculation of a complex machine model. The various control functions can be supplemented by special functions specific to the application.

18.7.1 Motor Chopper

The field-orientated control systems contain the function for adapted implementation of the generator energy into heat in the connected three-phase machine. This enables the realization of dynamic speed changes at minimum system costs. The torque and speed behavior of the drive system is not influenced by the parameterized braking behavior. The parameter *Trigger threshold 507* of the DC link voltage defines the switch-on threshold of the motor chopper function.

Parameter		Settings			
No.	Description	ACU	Min.	Max.	Fact. sett..
507	Trigger threshold	201	225	1000.0 V	400
		401	425		800

The parameter *Trigger threshold 507* is to be set in such a way that it is between the maximum DC link voltage which the mains can generate and the maximum admissible DC link voltage of the frequency inverter.

$$U_{\text{Netz}} \cdot 1,1 \cdot \sqrt{2} < U_{\text{dMC}} < U_{\text{dmax}}$$

If the parameter *Trigger threshold 507* is set larger than the maximum admissible DC link voltage, the motor chopper cannot become active; the motor chopper is switched off.

If the set *Trigger threshold 507* is smaller than the maximum DC link voltage the mains can generate, error message F0706 (chapter "Error Messages") is displayed when the frequency inverter is switched on.



The motor chopper function only works if activated via voltage Controller *Operation Mode 670*. See chapter 17.2 "Voltage controller".



For synchronous motors (*Configuration 30* = 5xx), the motor chopper function is deactivated to prevent damages to the motor. The other functions of the voltage controller are not affected by this.



Please note that by default the Motor chopper *Trigger Threshold 507* and the *Trigger Threshold 506* are set up with different values. Check, that the two thresholds are set up fittingly for your application.

18.7.2 Temperature Adjustment

The field-orientated control systems are based on the most precise calculation of the machine model possible. The rotor time constant is an important machine variable for the calculation. The figure to be read out via the parameter *Current rotor time constant* **227** is calculated from the inductivity of the rotor circuit and the rotor resistance. The dependence of the rotor time constant on the motor temperature can be taken into account in the case of particularly high precision requirements via a suitable measurement. Via *Operation mode* **465** for the temperature adjustment, you can select different methods and actual value sources for temperature measurement.

<i>Operation mode 465</i>	<i>Function</i>
0 - Off	The function is deactivated.
1 - Temp. meas. on MF11A	Temperature synchronization (0 ... 200 °C => 0 ... 10 V / 0 ... 20 mA), actual temperature value at multifunctional input 1
4 - Temp. Meas. at Start	Determination of temperature by frequency inverter via measurement of the winding resistance without external temperature measurement
11 - Vectron temp. meas. on MF11A	Temperature synchronization; act. temperature value across analog multi-function input. (-26.0 °C ... 207.8 °C => 0 ... 10 V / 0 ... 20 mA)

Operation mode 1 requires an external temperature measurement system which evaluates the temperature sensor and maps the temperature range from 0...200 °C to an analog voltage or current signal. The *Operation mode* **452** of multifunction input MF11 must be selected accordingly.

Operation mode 4 is available in configurations 210, 211 and 230. When the signals Controller release and Start clockwise or Start anticlockwise are present, the motor temperature and the rotor time constant are synchronized by means of the measured winding resistance.

For operation mode 11, an optional temperature measurement board by BONFIGLIOLI VECTRON is required. This board can be connected to the 20 V power supply on the frequency inverter. This board converts the temperature to an analog voltage or current signal in a range from -26.0 °C to 207.8 °C. The resistance of the measuring resistor KTY84/130 to be used is 1000 Ω at a temperature of 100 °C.

The material used for the rotor winding of the motor is taken into account via the parameter *Temperature coefficient* **466**. This value defines the change of the rotor resistance as a function of the temperature for a certain material of the rotor winding. Typical temperature coefficients are 39%/100 °C for copper and 36%/100 °C for aluminum at a temperature of 20 °C.

The temperature characteristic within the software is calculated via the aforementioned temperature coefficient and the parameter *Temperature adjustment* **467**. The adjustment temperature enables an additional optimization of the rotor time constant alongside the parameter *Rated slip correction factor* **718**.

<i>Parameter</i>		<i>Settings</i>		
No.	Description	Min.	Max.	Fact. sett.
466	Temperature coefficient	0.00%/100 °C	300.00%/100 °C	39.00%/100 °C
467	Adjusting temperature	-50 °C	300 °C	35 °C

The synchronization of the rotor time constant as a function of the winding temperature can be adjusted. The default values should normally be sufficiently precise so that neither an adjustment of the rotor time constants via the parameter *Rated slip correction factor* **718** nor an adjustment of the temperature synchronization via the parameter *Temperature coefficient* **466** is necessary. If an adjustment is necessary, please remember that the rotor time constant is calculated by the guided commissioning via the machine data. The *Adjusting temperature* **467** is to be set to the temperature at which the optimization of the extended machine data was carried out. The temperature can be read out via the actual value parameter *Winding temperature* **226** and can be used in the optimization for the parameter.

18.7.3 Speed Sensor Monitoring

Failures of the speed sensor lead to a faulty behavior of the drive, as the measured speed forms the foundation of the control system. By default, the speed sensor monitoring system continuously monitors the speed sensor signal, the track signals. If an expansion module EM is connected, the number of division marks is monitored additionally. If, while the frequency inverter is released, a faulty signal is recognized for longer than the timeout, a fault switch-off is affected. If the parameter *Operation mode* **760** is set to zero, the monitoring function is deactivated.

<i>Operation Mode</i> 760	Function
0 - Off	The function is deactivated
2 - Error	A fault message is displayed according to the timeouts set.

The speed sensor monitoring is to be parameterized in the part functions according to the application. The monitoring function becomes active with the release of the frequency inverter and the start command. The timeout defines a monitoring time in which the condition for the fault switch-off must be fulfilled without interruption. If one of the timeouts is set to zero, this monitoring function is deactivated.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
761	Timeout: Signal fault	0 ms	65000 ms	1000 ms
762	Timeout: Track fault	0 ms	65000 ms	1000 ms
763	Timeout: Direction of rotation fault	0 ms	65000 ms	1000 ms

Timeout: Signal fault

The actual speed measured is compared with the output value of the speed controller. If the actual speed value is exactly zero for the time selected with the parameter *Timeout: Signal fault* **761**, although a reference value is available, the fault is displayed with the message "F1430".

Timeout: Track fault


The actual speed measurement monitors the sequence in time of the signals in the quadruple evaluation of the speed sensor operation mode. If the speed sensor signal is faulty for the time selected with the parameter *Timeout: Channel fault* **762**, the fault is displayed with the message "F1431".

Timeout: Direction of rotation fault

The actual speed measured is compared with the reference speed. If the sign between reference value and actual value differs for the time selected with the parameter *Timeout: Direction fault* **763**, the fault is displayed with the message "F1432". The monitoring function is reset when the drive mechanism has moved in the reference value direction by a quarter of a revolution.


18.8 Traverse function

With the traverse function, a triangle-shaped frequency signal with the acceleration and deceleration times to be set is superimposed on the output frequency. The resulting signal courses of the reference frequency of master drive and slave drive are shown in the following diagrams. The function can be used, for example, for drives which wind up thread on coils in textile machines. To avoid winding errors at the turning point of the thread guide, a proportional jump is performed which causes a quick speed change.



In the case of the master drive, the superimposed traverse frequency proceeds linearly to the limit *Traverse Amplitude 438* and then reverses its direction. When the direction is reversed, a proportional step is affected. Via a handshake signal, the master drive informs the slave drive that the traverse output has changed its direction. The traverse function of the slave drive has the same gradient as the traverse function of the master drive, but with opposite sign. When the slave drive reaches the limit *Traverse Amplitude 438* before switch-over of the handshake signal, the frequency is maintained until switch-over is affected. If the handshake signal is received before the frequency limit is reached, the direction is reversed immediately.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
436	Acceleration Time	0.01 s	320.00 s	5 s
437	Deceleration Time	0.01 s	320.00 s	5 s
438	Traverse Amplitude	0.01 %	50.00 %	10 %
439	Proportional Step	0.01 %	50.00 %	0.01%



Signal "14 – Traverse Output" is added to the reference frequency value.

Via parameter *Operation mode* **435**, the drive is configured as a master drive or slave drive.

<i>Operation mode 435</i>	<i>Function</i>
0 - Off	The traverse function is deactivated.
1 - Master Drive	Operation as master drive.
2 - Slave Drive	Operation as slave drive.

For traverse mode, the reference value source is selected via parameter *Reference frequency* **48**.

Traverse mode becomes active as soon as the *Reference frequency* **48** is reached for the first time. This frequency is reached via the values for *Acceleration (clockwise)* **420** and *Acceleration Anticlockwise* **422** and *Deceleration (clockwise)* **421** and *Deceleration anticlockwise* **423**. In shot-effect mode, the values for *Acceleration Time* **436** and *Deceleration Time* **437** are active.

The frequency range for shot-effect mode is limited by the *Minimum frequency* **418** and the *Maximum frequency* **419**.

During traverse operation, the configured traverse parameter values cannot be changed.

The source of the handshake signal is selected via *Handshake Traverse Function* **49**.

18.9 Converter Profibus from/to Internal Notation

The Converter Profibus/Internal notation can convert a 16 bit Word into an internal 32 Bit frequency value and vice versa. This is useful in example, when several devices are linked together via Systembus and for commercial reasons only one device is equipped with a Profibus Option. Through the routing of the Profibus Word via the Systembus ("Tunneling") the necessary bandwidth can be reduced and the parameterization of the "Gateway" (Systembus Master with Profibus Slave communication) be simplified. The converter is used in this case in a device without Profibus module to convert the Profibus Notation into an internal reference value.

Parameter		Settings		
No.	Description	Min.	Max.	Fact. sett.
1370	In-F-PDP-word 1	Selection		
1371	In-F-PDP-word 2	Selection		
1372	In-F-intern long 1	Selection		
1373	In-F-intern long 2	Selection		
1374	In-F-Convert Reference	0.01 Hz	999.99 Hz	50.00 Hz

A similar procedure can be used to convert in example the Actual Frequency into a value according to Profibus notation.

The converter can also be used for other purposes, in example when using the internal PLC programming.

In-F-PDP-word 1 1370 and *In-F-PDP-word 2 1371* convert the Profibus Notation into the internal Frequency. 0x4000 in Profibus-Notation (=100 %) refers to *In-F-Convert Reference 1374* in Hz.

In-F-intern-long 1 1372 and *In-F-intern-long 2 1373* convert an internal frequency value into Profibus Notation. 0x4000 in Profibus-Notation (=100 %) refers to *In-F-Convert Reference 1374* in Hz.

The Profibus Notation is limited to values from -200 % (0x8000) to +200 % (0x7FFF).

0x4000	= 100 %	= <i>In-F-Convert Reference 1374</i>
0x7FFF	= 200 %	= <i>2x In-F-Convert Reference 1374</i>
0x8000	= -200 %	= <i>-2x In-F-Convert Reference 1374</i>
0xC000	= -100 %	= <i>-In-F-Convert Reference 1374</i>

The values converted this way can be used as internal source.

774 – Out-F-PDP-Conv1-long1 as output of

In-F-PDP-word 1 1370 (Profibus-Not. → Frequency)

775 – Out-F-PDP-Conv1-long2 as output of

In-F-PDP-word 2 1371 (Profibus-Not. → Frequency)

776 – Out-F-PDP-Conv1-word1 as output of

In-F-PDP-long 1 1372 (Frequency → Profibus-Not.)

777 – Out-F-PDP-Conv2-word2 as output of

In-F-PDP-long 2 1373 (Frequency → Profibus-Not.)

19 Actual Values

The various control functions and methods include electrical control variables and various calculated actual values of the machine or system. The different actual values can be read out for operational and error diagnosis via a communication interface or in the VAL menu branch of the operating unit.

19.1 Actual Values of the Frequency Inverter

The modular hardware of the frequency inverter enables application-specific adaptation. Further actual value parameters can be displayed as a function of the selection configuration and the installed expansion cards.

Actual Values of the Frequency Inverter		
No.	Description	Function
222	DC –Link Voltage	Direct voltage in the DC link.
223	Modulation	Output voltage of the frequency inverter relative to the mains voltage (100% = U_{FUN}).
228	Internal ref. frequency	Sum of the <i>Frequency reference value sources 475</i> as a reference value from the frequency reference value channel.
229	Reference percentage	Sum of the <i>Reference percentage sources 476</i> as a reference value from the reference percentage channel.
230	Actual percentage value	Actual value signal on the <i>Actual percentage source 478</i> .
243	Digital Inputs (Hardware)	Decimally coded status of the six digital inputs and of multifunctional input 1 in <i>Operation Mode 452</i> - digital input. Displays the status of the physical inputs (See also <i>Digital Inputs 250</i>).
244	Working hours counter	Operating hours in which the output stage of the inverter is active.
245	Operation hours counter	Operating hours of the frequency inverter in which supply voltage is available.
249	Active data set	The data set actively in use according to <i>Data set change-over 1 70</i> and <i>Data set change-over 2 71</i> .
250	Digital Inputs	Decimally coded status of the six digital inputs and of multifunctional input 1 in <i>Operation Mode 452</i> - digital input. Depending of the setting of parameter <i>Local/Remote 412</i> the hardware signals or Fieldbus/Systembus signals are displayed (See also <i>Digital Inputs(Hardware) 243</i>)
251	Analog input MF11A	Input signal on multifunctional input 1 in analog <i>Operation mode 452</i> .
252	Repetition Frequency Input	Signal on repetition frequency input according to <i>Operation mode 496</i> .
254	Digital Outputs	Decimally coded status of the two digital outputs and of multifunctional output 1 in <i>Operation mode 550</i> – digital.
255	Heat sink temperature	Measured heat sink temperature.
256	Inside temperature	Measured inside temperature.
257	Analog output MFO1A	Output signal on multifunctional input 1 in <i>Operation mode 550</i> – analog.
258	PWM-Input	Pulse-width modulated signal at PWM input according to <i>Operation mode 496</i> .
259	Current error	Error message with error code and abbreviation.

Actual Values of the Frequency Inverter		
269	Warnings	Warning message with error code and abbreviation.
273	Application Warnings	Application Warning message with error code and abbreviation.
275	Controller Status	The reference value signal is limited by the controller coded in the controller status.
277	STO Status	Signal state of the shutdown paths STOA (digital input S1IND/STOA) and STOB (S7IND/STOB) of the safety function "STO – Safe Torque Off".
278	Frequency MFO1F	Output signal on multifunctional input 1 in <i>Operation mode 550</i> – repetition frequency.



Additional to the described Actual values further Actual values are available for Fieldbus access. These are notable parameters *Current error 260*, *Warnings 270* and *Application Warnings 274*, in which the respective feedback can be readout as a hexadecimal code (and without text). Please refer to the Communication manuals.



The actual values can be read out and monitored in the VAL menu branch of the operating unit. The parameter *Operation level 28* in the PARA menu branch defines the selection of the actual value parameters.



The digital inputs may seem deactivated in the actual value display **243**, **250** (constant "0"). This can be caused by the used configuration or used functions (in example encoder or frequency input).

Input	Deactivation mechanism for Actual value display	
S2IND	PWM / Rep. freq. input	
S4IND	Track B (Encoder 1)	
S5IND	Track A (Encoder 1)	
S6IND	Track Z (Encoder 1) or	PWM / Rep. freq. input
MF11	Analog input	

Settings:

For Encoder 1, check Parameter *Operation mode 490*.

For PWM / Rep. Freq. input, check Parameter *Operation mode 496*.

For MF11 check Parameter *Operation mode 452*.

Actual value:

Encoder 1: Frequency is displayed in **217**, speed in **218**.

PWM / Rep. freq. input: PWM is displayed in **258**, frequency in **252**.

19.1.1 STO Status

Parameter *STO Status* **277** can be used for an extended diagnosis of the two digital inputs STOA and STOB. The states of the inputs are bit coded displayed.

Bit	Significance	Function
0	1	Input STOA is missing.
1	2	Input STOB is missing.
2	4	Switch off input STOA.
3	8	Switch off input STOB.
4	16	Timeout STOA.
5	32	Timeout STOB.
6	64	Diagnosis error.
7	128	Frequency inverter error (Fault)

The signal statuses at the digital inputs STOA and STOB can be linked with inverter functions.

292 -	STOA	Signal status at digital input STOA
284 -	STOA inverted	Inverted signal status at digital input STOA
293 -	STOB	Signal status at digital input STOB
285 -	STOB inverted	Inverted signal status at digital input STOB

For further instructions refer to the application manual „STO – Safe torque off“.

19.2 Actual Values of the Machine

The frequency inverter controls the behavior of the machine in the various operating points. As a function of the configuration selected and the expansion cards installed, control variables and further actual value parameters of the machine can be displayed.

Actual Values of the Machine		
No.	Description	Function
210	Stator Frequency	The output voltage (motor voltage) of the frequency inverter.
211	R.m.s current	Calculated effective output current (motor current) of the frequency inverter.
212	Output voltage	Calculated R.m.s. figure of the phase-to-phase voltage (motor voltage) of the frequency inverter.
213	Active power	Active power calculated from the voltage, the current and the control variables.
214	Active current	Active current calculated from the rated motor parameters, the control variables and the current.
215	Isd	Current component of the field-orientated control forming the magnetic flux.
216	Isq	Torque-forming current component of field-orientated control.
217	Frequency Speed Sensor 1	Calculated from the data on speed sensor 1, the <i>No. of pole pairs</i> 373 and the speed sensor signal.
218	Speed sensor 1 speed	Calculation from speed sensor 1 frequency.
221	Slip frequency	Difference from the synchronous frequency calculated from the rated motor parameters, the control variables and the current.
224	Torque	Torque at the current output frequency calculated from the voltage, the current and the control variables.
225	Rotor flux	Current magnetic flux relative to the rated motor parameters.
226	Winding temperature	Measured temperature of the motor winding according to <i>Operation mode</i> 465 for temperature adjustment.
227	Act. rotor time constant	Time constant calculated for the operating point of the machine from the rated motor parameters, the rated and control variables.
235	Flux-forming voltage	Voltage component of the field-orientated control forming the magnetic flux.
236	Torque-forming voltage	Voltage component of the field-orientated control forming the torque.
238	Flux value	Magnetic flux calculated according to the rated values and the operating point of the motor.
239	Reactive current	Reactive current calculated from the rated motor parameters, the control variables and the current.
240	Actual speed	Measured or calculated speed of drive.
241	Actual frequency	Measured or calculated frequency of drive.



The actual values can be read out and monitored in the VAL menu branch of the operating unit. The parameter *Operation level* **28** in the PARA menu branch defines the selection of the actual value parameters to be selected.

19.3 Actual value memory

The assessment of the operating behavior and the maintenance of the frequency inverter in the application are facilitated by storing various actual values. The actual value memory guarantees monitoring of the individual variables for a definable period. The parameters of the actual value memory can be read out via a communication interface and displayed via the operating unit. In addition, the operating unit provides monitoring of the peak and mean values in the VAL menu branch.

Actual value memory		
No.	Description	Function
231	Peak Value Long Term Ixt	Utilization of the device-dependent overload of 60 seconds.
232	Peak Value Short Term Ixt	Utilization of the device-dependent overload of 1 second.
287	Peak value Vdc	The maximum DC link voltage measured.
288	Average value Vdc	The mean DC link voltage calculated in the period of observation.
289	Peak value heat sink temp.	The highest measured heat sink temperature of the frequency inverter.
290	Average value heat sink temp.	The mean heat sink temperature calculated in the period of observation.
291	Peak value inside temp.	The maximum measured inside temperature in the frequency inverter.
292	Average value inside temp.	The mean inside temperature calculated in the period of observation.
293	Peak value Iabs.	The highest abs. current calculated from the measured motor phases.
294	Average value Iabs	The mean abs. current calculated in the period of observation.
295	Peak value active power pos.	The largest calculated active power in motor operation.
296	Peak value active power neg.	Maximum generator active power calculated from the voltage, the current and the control variables.
297	Average value active power	The mean active power calculated in the period of observation.
301	Energy positive	The calculated energy to the motor in motor operation.
302	Energy negative	The calculated energy from the motor in generator operation.



The actual values can be read out and monitored in the VAL menu branch of the operating unit. The parameter *Operation level 28* in the PARA menu branch defines the selection of the actual value parameters to be selected.

The *Reset memory 237* parameter to be selected in the PARA menu branch of the operating unit enables purposeful resetting of the individual mean and peak values. The peak value and the mean value with the values stored in the period are overwritten with the parameter value zero.

<i>Reset memory 237</i>	Function
0 - No Reset	Values of actual value memory remain unchanged.
1 - Peak Value Long Term Ixt	Reset <i>Peak value long-term Ixt 231</i> .
2 - Peak Value Short Term Ixt	Reset <i>Peak value short-term Ixt 232</i> .
3 - Peak Value Vdc	Reset <i>Peak value Vdc 287</i> .
4 - Average Value Vdc	Delete <i>Average value Vdc. 288</i> .
5 - Peak Value Tc	Reset <i>Peak value Vdc 289</i> .
6 - Average Value Tc	Delete <i>Average value Vdc. 290</i> .
7 - Peak Value Ti	Reset <i>Peak value Ti 291</i> .
8 - Average Value Ti	Delete <i>Average value Ti. 292</i> .
9 - Peak Value Iabs.	Reset <i>Peak value Iabs. 293</i> .
10 - Average Value Iabs	Delete <i>Average Iabs 294</i> .
11 - Peak Value Pactive pos.	Reset <i>Peak value active power pos. 295</i> .
12 - Peak Value Pactive neg.	Reset <i>Peak value active power neg. 296</i> .
13 - Average Value Pactive	Delete <i>Average value active power 297</i> .
16 - Energy, positive	Reset parameter <i>Energy positive 301</i> .
17 - Energy, negative	Reset parameter <i>Energy negative 302</i> .
100 - All Peak Values	Reset all peak values stored.
101 - All Average Values	Delete average values and stored values.
102 - All Values	Delete the entire actual value memory.

19.4 Actual Values of the System

The calculation of the actual figures of the system is based on the parameterized system data. Specific to the application, the parameters are calculated from the factors, electrical variables and the controls. The correct display of the actual figures is a function of the data of the system to be parameterized.

19.4.1 Actual System Value

The drive can be monitored via the actual value *Actual System Value 242*.

The *Actual frequency 241* to be monitored is multiplied by the *Actual system value factor 389* and can be read out via the parameter *Actual system value 242*, i.e. *Actual frequency 241* x *Actual system value factor 389* = *Actual system value 242*.

Actual System Value		
No.	Description	Function
242	Actual System Value	Calculated frequency of drive.

19.4.2 Volume Flow and Pressure

The parameterization of the factors *Nominal Volumetric Flow* **397** and *Nominal Pressure* **398** is necessary if the matching actual values *Volumetric Flow* **285** and *Pressure* **286** are used to monitor the drive. The conversion is done using the electrical control parameters. *Volume flow* **285** and *Pressure* **286** are referred to the *Effective current* **214** in the case of the sensorless control methods. In the case of the field-oriented control methods, they are referred to the torque-forming current component *Isq* **216**.

Volume Flow and Pressure		
No.	Description	Function
285	Volumetric flow	Calculated volume flow with the unit m ³ /h.
286	Pressure	Pressure calculated according to the characteristic with the unit kPa.

20 Error Protocol

The various control methods and the hardware of the frequency inverter include functions which continuously monitor the application. The operational and error diagnosis is facilitated by the information stored in the error protocol.

20.1 Error List

The last 16 fault messages are stored in chronological order and the *No. of errors* **362** shows the number of errors which have occurred since initial commissioning of the frequency inverter. In the VAL menu branch of the control unit, the error code FXXXX is displayed. The meaning of the error key is described in the following chapter "Error Messages". Via the PC program, the number of operation hours (h), operation minutes (m) and the fault message can additionally be read out. The current operating hours can be read off via the *Operation hours counter* **245**. The fault report can be acknowledged via the keys of the operating unit and according to the assignment *Error acknowledgment* **103**.

Error List		
No.	Description	Function
310	Last error	hhhhh:mm ; FXXXX fault message.
311	Last error but one	hhhhh:mm ; FXXXX fault message.
312 to 325		Error 3 to error 16.
362	No. of errors	Number of errors occurred after the initial commissioning of the frequency inverter.

The error and warning behavior of the frequency inverter can be set in various ways. The automatic error acknowledgment enables acknowledgment of the faults Overcurrent F0500, Overcurrent F0507 and Overvoltage F0700 without intervention by an overriding control system or the user. The *No. of self acknowledged errors* **363** shows the total number of automatic error acknowledgments.

Error List		
No.	Description	Function
363	No. of self acknowledged errors	Total number of automatic error acknowledgment with synchronization.

20.1.1 Error Messages

The error code stored following a fault comprises the error group FXX and the following code number XX.

Error Messages		
Code		Meaning
F00	00	No fault has occurred.
Overload		
F01	00	Frequency inverter overloaded.
F01	02	Frequency inverter overloaded (60 s), check load behavior.
	03	Short-term overload (1 s), check motor and application parameters.

Table "Fault Messages" continued on next page.

Heat Sink		
Code		Meaning
F02	00	Heat sink temperature too high, check cooling and fan.
	01	Temperature sensor defective or ambient temperature too low.
Inside		
F03	00	Inside temperature too high, check cooling and fan.
	01	Inside temperature too low, check electrical cabinet heating.
Motor Connection		
F04	00	Motor temperature too high or sensor defective, check connection S6IND.
	01	Motor protection switch tripped, check drive.
	02	V-belt monitoring reports no load on the drive.
	03	Phase failure, check motor and wiring.
	04	Deviation Position Controller. Please check Application manual Positioning.
	05	Start monitoring. Check brake & limiting parameters at start, like in example <i>Current limit 728</i> , Intelligent currents, etc.
Output current		
F05	00	Overloaded, check load situation and ramps.
	01	Instantaneous output current value too high. Check load.
	02	Dynamic Phase current limitation. Check load.
	03	Short circuit or earth fault, check motor and wiring.
	04	Overloaded, check load situation and current value limit controller.
	05	Asymmetric motor current, check current and wiring.
	06	Motor phase current too high, check motor and wiring.
	07	Message from phase monitoring, check motor and wiring.
DC –Link Voltage		
F07	00	DC link voltage too high, check deceleration ramps and connected brake resistor.
	01	DC link voltage too low, check mains voltage.
	02	Power failure, check mains voltage and circuit.
	03	Phase failure, check mains fuses and circuit.
	04	<i>Reference DC link limitation 680</i> too small, check mains voltage.
	05	Brake chopper <i>Trigger threshold 506</i> too small, check mains voltage.
	06	Motor chopper <i>Trigger threshold 507</i> too small, check mains voltage.
Electronics voltage		
F08	01	Electronics voltage DC 24 V too low, check control terminal.
	04	Electronics voltage too high, check wiring of control terminals.
Brake chopper		
F10	10	Brake Chopper Overcurrent; refer to chapter 18.4 "Brake Chopper and Brake Resistance".
Output frequency		
F11	00	Output frequency too high, check control signals and settings.
	01	Max. frequency reached by control, check deceleration ramps and connected brake resistor.
	10	Overspeed. Check Application manual "Crane drives".

Table "Fault Messages" continued on next page.

Safety function STO		
Code		Meaning
F12	01	Diagnosis error of function STO; at least one of the shut-down paths STOA and STOB is defective. Check units connected to shut-down paths; check cabling and EMC.
	04	Software self-diagnosis has detected an internal error. Consult BONFIGLIOLI customer service.
	05	Fault message of 5-second monitoring. Shut-down paths STOA and STOB were not actuated at the same time, but with an offset of more than 5 seconds. Check addressing of shut-down paths or control of protective circuitry.
Motor Connection		
F13	00	Earth fault on output, check motor and wiring.
	01	Set <i>IDC compensation limit 415</i> reached, check motor and cabling, increase limit, if necessary.
	10	Minimum current monitoring, check motor and wiring.
Control Connection		
F14	01	Reference value on multifunctional input 1 faulty, check signal.
	02	Reference value EM-S1INA faulty, check signal.
	07	Overcurrent on multifunctional input 1, check signal.
	21	Resolver fault. Check resolver connection and speed.
	22	Resolver counting fault. Check resolver connection.
	23	Resolver pole pair number incorrect. Check parameter of pole pairs.
	24	Resolver connection fault. Check resolver connection.
	30	Encoder signal defective, check connections S4IND and S5IND.
	31	One track of the speed sensor signal is missing, check connections.
	32	Direction of rotation of speed sensor wrong, check connections.
	33	Encoder 2: Division Marks Fault. Check encoder settings.
	34	Too less Division Marks Fault. Check encoder settings.
	35	Too many Division Marks Fault. Check encoder settings.
	36	Encoder 1: Division Marks Fault. Correct <i>Division Marks 491</i> of encoder 1; refer to chapter 10.4.2 "Division marks, speed sensor 1".
37	The encoder is disabled. In configurations 210, 211 and 230 an encoder must be activated. Set parameter <i>Operation Mode 490</i> to an evaluation mode (not to "0 – off). If an expansion module is installed and parameter <i>Actual Speed source 766</i> is set to "2 – Speed Sensor 2", parameter <i>Operation Mode 493</i> (speed sensor 2) must be set to an evaluation mode.	
50	KTY Temperature Measurement Failure. Check KTY connection.	
54	External error; drive responded according to parameter setting for <i>Operation mode ext. error 535</i> . Error was triggered via the logic signal or digital input signal assigned to parameter <i>External error 183</i> .	
Positioning		
F14	4n	Positioning function fault. Please check Application manual Positioning.
	5n	
	6n	
	7n	
EM-ABS-01 Module		
F14	8n	Fault with Absolute encoder evaluation. Please check EM-ABS-01 manual.
	9n	

Table "Fault Messages" continued on next page.

Positioning		
Code	Meaning	
F15	nn	Positioning function fault. Please check Application manual Positioning.
Absolute encoder: Absolute value interface		
F17	nn	Fault with Absolute encoder evaluation. Please check EM-ABS-01 manual.
Modbus and VABus		
F20	10	Communication error according to parameter <i>CM: VABus Watchdog Timer 413</i> .
CANopen		
F20	21	CAN Bus OFF
	22	CAN Guarding
	23	Error state
	24	SYNC error (SYNC timing)
	25	CAN error state
	26	RxPDO1 length error
	27	RxPDO2 length error
	28	RxPDO3 length error
	2A	CAN RxPDO1 Timeout
	2B	CAN RxPDO2 Timeout
	2C	CAN RxPDO3 Timeout
Number of received bytes differs from mapping.		
DeviceNet		
F20	5x	DeviceNet Fault. Please check DeviceNet manual.
PROFIBUS		
F20	6x	PROFIBUS Fault. Please check PROFIBUS manual.
System bus		
F21	nn	Fault message on system bus master when a fault at system bus slave occurs, nn = node-ID of slave (hex)
F22	00	Communication fault, system bus, timeout sync-telegram
	01	Communication fault, system bus, timeout RxPDO1
	02	Communication fault, system bus, timeout RxPDO2
	03	Communication fault, system bus, timeout RxPDO3
	10	Communication fault, system bus, bus-off
CANopen		
F23	nn	Heartbeat error, nn = triggering node.
CM module recognition		
F24	nn	Unknown CM module. Check compatibility firmware and CM module.
EM module recognition		
F25	nn	Unknown CM module. Check compatibility firmware and EM module.
Industrial Ethernet		
F27	nn	Industrial Ethernet Fault. Please check manual of used Ethernet Module.
EtherCAT		
F28	nn	EtherCAT fault.

Table "Fault Messages" continued on next page.

User Error VPLC		
Code		Meaning
F30	3n	User triggered Error of Internal PLC. Please check the application manual VPLC.
Optional Components		
F0A	10	Data transmission from control unit KP 500 to the frequency inverter not possible. At least one file must be stored in the control unit.
F0B	13	The communication module was fitted to slot B without disconnection of the mains voltage, switch mains voltage off.
Internal monitoring		
F0C	40	After 6 warm starts in less than 3 minutes this fault is triggered, due to the expectation that a faulty programming of the PLC or the function table is at hand. Additionally the PLC / Function table is stopped (P. 1399 = 0 only in RAM).

In error occurrence the signal 162 - "Error Signal" is set. The signal can be linked with inverter functions.

Output signals in error occurrence

Errors are indicated by digital signals.

162 -	Error Signal	¹⁾	Monitoring function signals an error which is displayed in parameter <i>Current Error</i> 259 .
3 -		²⁾	

¹⁾ For linking with inverter functions

²⁾ For digital output

In addition to fault messages mentioned, there are further fault messages. However these messages are only used for internal purposes and are not listed here. If you receive fault messages which are not listed here, please contact the BONFIGLIOLI customer service.

Please store the parameter file on your PC before contacting BONFIGLIOLI.

20.2 Error Environment

The parameters of the error environment help troubleshooting both in the settings of the frequency inverter and also in the complete application. The error environment documents the operational behavior of the frequency inverter at the time of the last four faults.

Error Environment		
No.	Description	Function
330	DC –Link Voltage	Direct voltage in the DC link.
331	Output voltage	Calculated output voltage (motor voltage) of the frequency inverter.
332	Stator frequency	The output voltage (motor voltage) of the frequency inverter.
333	Frequency Speed Sensor 1	Calculated from the data on speed sensor 1, the <i>No. of pole pairs 373</i> and the speed sensor signal.
335	Phase current Ia	Measured current in motor phase U.
336	Phase current Ib	Measured current in motor phase V.
337	Phase current Ic	Measured current in motor phase W.
338	R.m.s current	Calculated effective output current (motor current) of the frequency inverter.
339	Isd / reactive current	Current component forming the magnetic flux or the calculated reactive current.
340	Isq / active current	Current component forming the torque or the calculated active current.
341	Rotor magnetizing current	Magnetizing current relative to the rated motor parameters and the operating point.
342	Torque	Torque calculated from the voltage, the current and the control variables.
343	Analog input MF11A	Input signal on multifunctional input 1 in analog <i>Operation mode 452</i> .
346	Analog output MFO1A	Output signal on multifunctional input 1 in <i>Operation mode 550</i> – analog.
349	Repetition frequency output	Signal at repetition frequency output according to <i>Operation mode 550</i> – repetition frequency.
350	Status of digital inputs	Decimally coded status of the six digital inputs and of multifunctional input 1 in <i>Operation mode 452</i> - digital input.
351	Status of digital outputs	Decimally coded status of the two digital outputs and of multifunctional output 1 in <i>Operation mode 550</i> – digital.
352	Time since release	The time of the error in hours (h), minutes (m) and seconds (s) after the release signal: hhhhh:mm:ss . ^{sec} /10 ^{sec} /100 ^{sec} /1000.
353	Heat sink temperature	Measured heat sink temperature.
354	Inside temperature	Measured inside temperature.
355	Controller Status	The reference value signal is limited by the controller coded in the controller status.
356	Warning Status	The warning messages coded in warning status.
357	Int. value 1	Software service parameter.
358	Int. value 2	Software service parameter.
359	Long value 1	Software service parameter.
360	Long value 2	Software service parameter.
367	Warning status application	The application warnings coded in warning status.

The *Checksum 361* parameter shows whether the storage of the error environment was free of errors (OK) or incomplete (NOK).


Error Environment		
No.	Description	Function
361	Checksum	Check protocol of the error environment.

21 Operational and Error Diagnosis

Operation of the frequency inverter and the connected load are monitored continuously. Various functions document the operational behavior and facilitate the operational and error diagnosis.

21.1 Status Display

The green and red light-emitting diodes give information about the operating point of the frequency inverter. If the control unit is connected, the status messages are additionally displayed by the display elements RUN, WARN and FAULT.




Status Display			
green LED	red LED	Display	Description
off	off	-	No supply voltage.
on	on	-	Initialization and self-test.
flashes	off	RUN flashes	Ready for operation, no output signal.
on	off	RUN	Operating message.
on	flashes	RUN + WARN	Operational message, current <i>warning 269</i> .
flashes	flashes	RUN + WARN	Ready for operation, current <i>warning 269</i> .
off	flashes	FAULT flashes	<i>Last error 310</i> of frequency inverter.
off	on	FAULT	<i>Last error 310</i> , acknowledge fault.

21.2 Status of Digital Signals

The status display of the digital input and output signals enables checking of the various control signals and their assignment to the corresponding software functions, in particular during commissioning.

Coding of the status of the digital signals

Assignment:



A decimal value is displayed, indicating the status of the digital signals in bits after conversion into a binary figure.

Example: Decimal figure 33 is displayed. Converted into the binary system, the number reads **00100001**. Thus, the following contact inputs or outputs are active:

- Control signal at digital input or output 1
- Control signal at digital input or output 6

21.3 Controller Status

The controller status can be used to establish which of the control functions are active. If a several controllers are active at the time, a controller code composed of the sum total of the individual codes is displayed. The display of the controller status by the control unit and the light-emitting diodes can be parameterized via the *Controller status message 409*.

Coding of the controller status	
CXXXX	ABCDE
Controller code	Controller abbreviation
Code	Controller Status
C 00 00 -	No controller active.
C 00 01 UDdyn	Voltage controller is in the rise phase according to <i>Operation mode 670</i> .
C 00 02 UDstop	The output frequency in the case of a power failure is below the <i>Shutdown threshold 675</i> .
C 00 04 UDctr	Failure of the mains voltage and power regulation active according to <i>Operation mode 670</i> of the voltage controller.
C 00 08 UDlim	The DC link voltage has exceeded the <i>Reference UD limitation 680</i> .
C 00 10 Boost	The <i>Dyn. voltage pre-control 605</i> accelerates the control system.
C 00 20 Ilim	The output current is limited by the current limit value controller or the speed controller.
C 00 40 Tlim	The output power or the torque is limited by the speed controller.
C 00 80 Tctr	Switch-over of field-orientated control between speed and torque-controlled control method.
C 01 00 Rstp	The <i>Operation mode 620</i> selected in starting behavior limits the output current.
C 02 00 IxtLtLim	Overload limit of the long-term Ixt (60s) reached, intelligent current limits active.
C 04 00 IxtStLim	Overload limit of the short-term Ixt (1s) reached, intelligent current limits active.
C 08 00 Tclim	Max. heat sink temperature TK reached, intelligent current limits of <i>Operation mode 573</i> active.
C 10 00 PTclim	Max. motor temperature reached, intelligent current limits of <i>Operation mode 573</i> active.
C 20 00 Flim	The reference frequency has reached the <i>Maximum frequency 419</i> . The frequency limitation is active.

Example: The controller status is displayed

C0024 UDctr Ilim

The controller status results from the hexadecimal sum of the controller codes (0004+0020 = 0024). At the same, the power failure regulation and also the current limitation of the speed controller are active.

21.4 Warning Status and Warning Status Application

The current warning is displayed by a message in the warning status and can be used for an early message of a critical operational condition. If a warning is present, this is indicated by the flashing red LED and the display field WARN of the control unit. If several warnings are present, the warning status is displayed as the sum of the individual warning codes.

The warning masks created through parameters *Create warning mask* **536** and *Create warning mask application* **626** have no influence on the warnings displayed. Via the actual value parameters *Warning* **269**, *Application Warnings* **273**, *Warning status* **356** (in error environment) and *Warning status application* **367** (in error environment), all warnings present at the time of the error are always displayed.

Coding of the warning status

A XXXX	A B C D E
Warning code	Abbreviation for the warning

Meaning of code displayed by parameter *Warning status* **356**:

Code	Warning Status
A 00 00 -	No warning message present.
A 00 01 lxt	Frequency inverter overloaded (A0002 or A0004).
A 00 02 lxtSt	Overload for 60 s relative to the nominal output of the frequency inverter.
A 00 04 lxtLt	Short-time overload for 1 s relative to the nominal output of the frequency inverter.
A 00 08 Tc	Max. heat sink temperature T_K of 80 °C less the <i>Warning Limit Heat Sink Temp.</i> 407 reached.
A 00 10 Ti	Max. inside temperature T_i of 65 °C less the <i>Warning Limit Inside Temp.</i> 408 reached.
A 00 20 Lim	The controller stated in <i>Controller status</i> 275 limits the reference value.
A 00 40 INIT	Frequency inverter is being initialized.
A 00 80 PTC	Warning behavior according to parameterized <i>Operation mode Motor temp.</i> 570 at max. motor temperature T_{Motor} .
A 01 00 Mains	<i>Phase monitoring</i> 576 reports a phase failure.
A 02 00 PMS	Motor protection switch parameterized in <i>Operation mode</i> 571 tripped.
A 04 00 Flim	The <i>Maximum frequency</i> 419 was exceeded. The frequency limitation is active.
A 08 00 A1	The input signal MF11A is lower than 1 V / 2 mA according to the operation mode for the <i>Error/warning behavior</i> 453 .
A 10 00 A2	The input signal is lower than 1 V / 2 mA according to the operation mode for the <i>Error/warning behavior</i> 453 .
A 20 00 SYS	A slave on the system bus reports a fault; warning is only relevant with the EM-SYS option.
A 40 00 UDC	The DC link voltage has reached the type-dependent minimum value.
A 80 00 WARN2	In <i>Warning status application</i> 367 , a warning is present.

Example: The following warning status is displayed:

A008D Ixt IxtLt Tc PTC

The warning status results from the hexadecimal sum of the warning codes ($0001+0004+0008+0080 = 008D$).

The short-term overload (1 s), warning limit heat sink temperature and warning limit motor temperature warnings are present.

Output signals

The output of a warning message is signaled.

169 -	General Warning	¹⁾	The output of a warning message in <i>Warnings 269</i> is signaled.
11 -	Warning, General	²⁾	

¹⁾ For linking with inverter functions

²⁾ For digital output

Meaning of code displayed by parameter *Application Warning Status 367*:

Code	Warning Status
A 00 00 NO WARNING	No warning message present.
A 00 01 BELT	Warning V-belt by <i>Operation mode 581</i> .
A 00 02 SW-LIM CW	The positive SW limit switch was reached (parameter <i>Positive SW limit switch 1145</i>).
A 00 04 SW-LIM CCW	The negative SW limit switch was reached (parameter <i>Negative SW limit switch 1146</i>).
A 00 08 HW-LIM CW	The positive HW limit switch was reached.
A 00 10 HW-LIM CCW	The negative HW limit switch was reached.
A 00 20 CONT	The contouring error monitoring range adjusted with parameter <i>Warning Threshold 1105</i> was left.
A 00 40 Enc	A connected encoder with data track triggered a warning.
A 00 80 User 1	The signal set on digital input <i>User Warning 1 1363</i> is active.
A 01 00 User 2	The signal set on digital input <i>User Warning 2 1364</i> is active.

Output signals

The output of an application warning message is signaled.




216 -	Application Warning	¹⁾	The output of a warning message in <i>Application Warnings 273</i> is signaled.
26 -	Warning, Application	²⁾	

¹⁾ For linking with inverter functions

²⁾ For digital output

22 Parameter List

The parameter list is structured according to the menu branches of the control unit. The parameters are listed in ascending numerical order. A headline (shaded) can appear several times, i.e. a subject area may be listed at different places in the table. For better clarity, the parameters have been marked with pictograms:

-  The parameter is available in the four data sets.
-  The parameter value is set by the SETUP routine.
-  This parameter cannot be written when the frequency inverter is in operation.

I_{FIN} , U_{FIN} , P_{FIN} : rated values of the frequency inverter, o : overload capacity of frequency inverter

(201) value for ACU201 devices

(401) value for ACU401 devices

ACU201 devices: $U_{dmax}=387,5$ V, ACU401 devices: $U_{dmax}=770$ V



At the control unit KP500 parameter numbers > 999 are displayed hexadecimal at the leading digit (999, A00 ... B5 ... C66).




























22.1 Actual Value Menu (VAL)

Actual Values of the Machine				
No.	Description	Unit	Display range	Chapter
210	Stator Frequency	Hz	0.00 ... 999.99	19.2
211	R.m.s Current	A	0.0 ... I_{max}	19.2
212	Output Voltage	V	0.0 ... U_{FIN}	19.2
213	Active Power	kW	0.0 ... P_{max}	19.2
214	Active Current	A	0.0 ... I_{max}	19.2
215	Isd	A	0.0 ... I_{max}	19.2
216	Isq	A	0.0 ... I_{max}	19.2
217	Encoder 1 Frequency	Hz	0.00 ... 999.99	19.2
218	Encoder 1 Speed	1/min	0 ... 60000	19.2
221	Slip Frequency	Hz	0.0 ... 999.99	19.2
Actual Values of the Frequency Inverter				
222	DC-Link Voltage	V	0.0 ... $U_{dmax}-25$	19.1
223	Modulation	%	0 ... 100	19.1
Actual Values of the Machine				
224	Torque	Nm	± 9999.9	19.2
225	Rotor Flux	%	0 ... 100	19.2
226	Winding Temperature	deg.C	0 ... 999	19.2
227	Act. Rotor Time Constant	ms	0 ... τ_{max}	19.2
Actual Values of the Frequency Inverter				
228	Internal ref. frequency	Hz	0.00 ... f_{max}	19.1
229	Reference percentage	%	± 300.00	19.1
230	Actual percentage value	%	± 300.00	19.1
Actual value memory				
231	Peak value long-term Ixt	%	0.00 ... 100.00	19.3
232	Peak value short-term Ixt	%	0.00 ... 100.00	19.3


Actual Values of the Machine				
No.	Description	Unit	Display range	Chapter
235	Flux-forming voltage	V	0.0 ... U_{FIN}	19.2
236	Torque-forming voltage	V	0.0 ... U_{FIN}	19.2
238	Flux value	%	0.0 ... 100.0	19.2
239	Reactive current	A	0.0 ... I_{max}	19.2
240	Actual speed	1/min	0 ... 60000	19.2
241	Actual frequency	Hz	0.0 ... 999.99	19.2
Actual Values of the System				
242	Actual System Value	Hz	0.0 ... 999.99	19.4.1
Actual Values of the Frequency Inverter				
243	Digital inputs (Hardware)	-	00 ... 255	19.1
244	Working hours counter	h	99999	19.1
245	Operation hours counter	h	99999	19.1
249	Active data set	-	1 ... 4	19.1
250	Digital inputs	-	00 ... 255	19.1
251	Analog input MF11A	%	± 100.00	19.1
252	Repetition Frequency Input	Hz	0.0 ... 999.99	19.1
254	Digital Outputs	-	00 ... 255	19.1
255	Heat sink temperature	deg.C	0 ... T_{kmax}	19.1
256	Inside temperature	deg.C	0 ... T_{imax}	19.1
257	Analog output MFO1A	V	0.0 ... 24.0	19.1
258	PWM-Input	%	0.00 ... 100.00	19.1
259	Current error	-	FXXXX	19.1
269	Warnings	-	AXXXX	19.1
273	Application Warnings	-	AXXXX	19.1
275	Controller Status	-	CXXXX	19.1
277	STO Status	-	XXXX	19.1
278	Frequency MFO1F	Hz	0.00 ... f_{max}	19.1
Actual Values of the System				
285	Volumetric flow	m ³ /h	0 ... 99999	19.4.2
286	Pressure	kPa	0.0 ... 999.9	19.4.2
Actual value memory				
287	Peak value Vdc	V	0.0 ... U_{dmax}	19.3
288	Average value Vdc	V	0.0 ... U_{dmax}	19.3
289	Peak value heat sink temp.	deg.C	0 ... T_{kmax}	19.3
290	Average value heat sink temp.	deg.C	0 ... T_{kmax}	19.3
291	Peak Value Inside Temperature	deg.C	0 ... T_{imax}	19.3
292	Average Value Inside Temperature	deg.C	0 ... T_{imax}	19.3
293	Peak Value Irms	A	0.0 ... $0 \cdot I_{FIN}$	19.3
294	Average Value Irms	A	0.0 ... $0 \cdot I_{FIN}$	19.3
295	Peak value active power pos.	kW	0.0 ... $0 \cdot P_{FIN}$	19.3
296	Peak value active power neg.	kW	0.0 ... $0 \cdot P_{FIN}$	19.3
297	Average value active power	kW	0.0 ... $0 \cdot P_{FIN}$	19.3
301	Energy positive	kWh	0 ... 99999	19.3
302	Energy negative	kWh	0 ... 99999	19.3

Error List				
No.	Description	Unit	Display range	Chapter
310	Last error	h:m; F	00000:00; FXXXX	20.1
311	Last error but one	h:m; F	00000:00; FXXXX	20.1
312	Error 3	h:m; F	00000:00; FXXXX	20.1
313	Error 4	h:m; F	00000:00; FXXXX	20.1
314	Error 5	h:m; F	00000:00; FXXXX	20.1
315	Error 6	h:m; F	00000:00; FXXXX	20.1
316	Error 7	h:m; F	00000:00; FXXXX	20.1
317	Error 8	h:m; F	00000:00; FXXXX	20.1
318	Error 9	h:m; F	00000:00; FXXXX	20.1
319	Error 10	h:m; F	00000:00; FXXXX	20.1
320	Error 11	h:m; F	00000:00; FXXXX	20.1
321	Error 12	h:m; F	00000:00; FXXXX	20.1




Error List				
322	Error 13	h:m; F	00000:00; FXXXX	20.1
323	Error 14	h:m; F	00000:00; FXXXX	20.1
324	Error 15	h:m; F	00000:00; FXXXX	20.1
325	Error 16	h:m; F	00000:00; FXXXX	20.1



























Error Environment					
	330	DC –Link Voltage	V	0.0 ... U _{dmax}	20.2
	331	Output voltage	V	0.0 ... U _{FUN}	20.2
	332	Stator frequency	Hz	0.00 ... 999.99	20.2
	333	Encoder 1 Frequency	Hz	0.00 ... 999.99	20.2
	335	Phase current Ia	A	0.0 ... I _{max}	20.2
	336	Phase current Ib	A	0.0 ... I _{max}	20.2
	337	Phase current Ic	A	0.0 ... I _{max}	20.2
	338	R.m.s current	A	0.0 ... I _{max}	20.2
	339	Isd / reactive current	A	0.0 ... I _{max}	20.2
	340	Isq / active current	A	0.0 ... I _{max}	20.2
	341	Rotor magnetizing current	A	0.0 ... I _{max}	20.2
	342	Torque	Nm	± 9999.9	20.2
	343	Analog input MF11A	%	± 100.00	20.2
	346	Analog output MFO1A	V	0.0 ... 24.0	20.2
	349	Repetition frequency output	Hz	0.00 ... 999.99	20.2
	350	Status of digital inputs	-	00 ... 255	21.2
	351	Status of digital outputs	-	00 ... 255	21.2
	352	Time since release	h:m:s.ms	00000:00:00.000	20.2
	353	Heat sink temperature	deg.C	0 ... T _{kmax}	20.2
	354	Inside temperature	deg.C	0 ... T _{imax}	20.2
	355	Controller Status	-	C0000 ... CFFFF	21.3
	356	Warning Status	-	A0000 ... AFFFF	21.4
	357	Int. value 1	-	± 32768	20.2
	358	Int. value 2	-	± 32768	20.2
	359	Long value 1	-	± 2147483647	20.2
	360	Long value 2	-	± 2147483647	20.2
	361	Checksum	-	OK / NOK	20.2

Error List				
362	No. of errors	-	0 ... 32767	20.1
363	No. of self acknowledged errors	-	0 ... 32767	20.1





















Error Environment				
No.	Description	Unit	Display range	Chapter
 367	Application Warning Status	-	A0000 ... AFFFF	21.4
Positioning				
470	Rotations	U	0.000 ... 1·10 ⁶	12.6
Digital Outputs				
537	Actual warning mask	-	AXXXXXXXXX	15.3.8
627	Actual Appl. Warning Mask	-	AXXXX	15.3.9
Self-configuration				
797	SET-UP Status	-	OK / NOK	8.5





























22.2 Parameter Menu (PARA)








































Inverter Data				
No.	Description	Unit	Setting range	Chapter
0	Serial Number	-	Characters	9.1
1	Optional Modules	-	Characters	9.2
12	Inverter Software Version	-	Characters	9.3
15	Copyright	-	Characters	9.3
27	Set password	-	0 ... 999	9.4
28	Control level	-	1 ... 3	9.5
29	User Name	-	32 characters	9.6
 30	Configuration	-	Selection	9.7
33	Language	-	Selection	9.8
 34	Program(ming)	-	0 ... 9999	9.9
37	Start Positioning of Axle	-	Selection	12.6.2
Fan				
39	Switch-on temperature	deg.C	0 ... 60	18.2
Shot effect function				
 48	Reference frequency	-	Selection	18.8
Digital inputs				
49	Handshake Traverse Function	-	Selection	15.4.10
58	Technology Controller Release	-	Selection	17.3
62	Frequency Motorpoti Up	-	Selection	15.4.9
63	Frequency Motorpoti Down	-	Selection	15.4.9
66	Fixed frequency change-over 1	-	Selection	15.4.8
67	Fixed frequency change-over 2	-	Selection	15.4.8
68	Start clockwise	-	Selection	15.4.1
69	Start anticlockwise	-	Selection	15.4.1
70	Data set change-over 1	-	Selection	15.4.7
71	Data set change-over 2	-	Selection	15.4.7
72	Percent Motorpoti Up	-	Selection	15.4.9
73	Percent Motorpoti Down	-	Selection	15.4.9
75	Fixed perc. value change-over 1	-	Selection	15.4.8
76	Fixed perc. value change-over 2	-	Selection	15.4.8
83	Timer 1	-	Selection	15.4.4
84	Timer 2	-	Selection	15.4.4
87	Start 3-wire control	-	Selection	15.4.2
103	Error Acknowledgment	-	Selection	15.4.3
164	n-/M Control Change-Over	-	Selection	15.4.6
183	External error	-	Selection	15.4.12
Digital inputs				
204	Therm. Contact	-	Selection	15.4.5






































Actual value memory					
No.	Description	Unit	Setting range	Chapter	
237	Reset memory	-	Selection	19.3	
Controlled commissioning					
369	Motor Type	-	Selection	8.2.3	
Rated Motor Parameters					
	370	Rated voltage	V	$0.17 \cdot U_{FIN} \dots 2 \cdot U_{FIN}$	10.1
	371	Rated current	A	$0.01 \cdot I_{FIN} \dots 10 \cdot I_{FIN}$	10.1
	372	Rated speed	U/min	96 ... 60000	10.1
✓ 	373	No. of pole pairs	-	1 ... 24	10.1
	374	Rated cosine Phi	-	0.01 ... 1.00	10.1
	375	Rated frequency	Hz	10.00 ... 1000.00	10.1
	376	Rated mech. power	kW	$0.1 \cdot P_{FIN} \dots 10 \cdot P_{FIN}$	10.1
Further motor parameters					
✓ 	377	Stator Resistance	mOhm	0 ... 65535	10.2.1
✓ 	378	Leakage Coefficient	%	1.0 ... 20.0	10.2.2
	383	Voltage constant	mVmin	0.0 ... 850.0	10.2.5
	384	Stator Inductance	mH	0.1 ... 500.0	10.2.6
System Data					
	389	Factor Actual Value System	-	-100.000 ... 100.000	11.1
	397	Nominal volumetric flow	m3/h	1 ... 99999	11.2
	398	Nominal pressure	kPa	0.1 ... 999.9	11.2
Pulse Width Modulation					
	400	Switching frequency	-	Selection	18.1
	401	Min. switching frequency	-	Selection	18.1
Error/warning behavior					
	405	Warning limit, short-term Ixt	%	6 ... 100	13.1
	406	Warning limit long-term Ixt	%	6 ... 100	13.1
	407	Warning Limit Heat Sink Temp	deg.C	-25 ... 0	13.2
	408	Warning Limit Inside Temp.	deg.C	-25 ... 0	13.2
	409	Controller status message	-	Selection	13.3
Bus controller					
	412	Local/Remote	-	Selection	18.3
Error/warning behavior					
	415	IDC Compensation Limit	V	0.0 ... 1.5	13.4
	417	Frequency Switch-Off Limit	Hz	0.00 ... 999.99	13.5
Frequency Limits					
 	418	Minimum Frequency	Hz	0.00 ... 999.99	14.1
 	419	Maximum Frequency	Hz	0.00 ... 999.99	14.1
Frequency ramps					
	420	Acceleration (clockwise)	Hz/s	0.00 ... 9999.99	14.7
	421	Deceleration (clockwise)	Hz/s	0.01 ... 9999.99	14.7
	422	Acceleration anticlockwise	Hz/s	-0.01 ... 9999.99	14.7
	423	Deceleration anticlockwise	Hz/s	-0.01 ... 9999.99	14.7
	424	Emergency stop clockwise	Hz/s	0.01 ... 9999.99	14.7
	425	Emergency stop anti-clockwise	Hz/s	0.01 ... 9999.99	14.7
	426	Maximum leading	Hz	0.01 ... 999.99	14.7
	430	Ramp rise time clockwise	ms	0 ... 65000	14.7
	431	Ramp fall time clockwise	ms	0 ... 65000	14.7
	432	Ramp rise time anticlockwise	ms	0 ... 65000	14.7
	433	Ramp rise time anticlockwise	ms	0 ... 65000	14.7


































Traverse function				
No.	Description	Unit	Setting range	Chapter
⊗ 435	Operation mode	-	Selection	18.8
⊗ 436	Acceleration Time	s	0.01 ... 320.00	18.8
⊗ 437	Deceleration Time	s	0.01 ... 320.00	18.8
⊗ 438	Traverse Amplitude	%	0.01 ... 50.00	18.8
⊗ 439	Proportional Step	%	0.01 ... 50.00	18.8
Technology Controller				
📄 440	Operation mode	-	Selection	17.3
📄 441	Fixed frequency	Hz	-999.99 ... 999.99	17.3
📄 442	max. P component	Hz	0.01 ... 999.99	17.3
📄 443	Hysteresis	%	0.01 ... 100.00	17.3
📄 444	Amplification	-	-15.00 ... 15.00	17.3
📄 445	Integral time	ms	0 ... 32767	17.3
📄 446	Ind. volume flow control factor	-	0.10 ... 2.00	17.3
Block Frequencies				
📄 447	1. blocking frequency	Hz	0.00 ... 999.99	14.9
📄 448	2. blocking frequency	Hz	0.00 ... 999.99	14.9
📄 449	Frequency hysteresis	Hz	0.00 ... 100.00	14.9
Multifunctional input 1				
📄 450	Tolerance band	%	0.00 ... 25.00	15.1.1.3
451	Filter Time Constant	ms	Selection	15.1.1.4
452	Operation mode	-	Selection	15.1
453	Error/warning behavior	-	Selection	15.1.1.5
📄 454	Point X1	%	0.00 ... 100.00	15.1.1.1
📄 455	Point Y1	%	-100.00 ... 100.00	15.1.1.1
📄 456	Point X2	%	0.00 ... 100.00	15.1.1.1
📄 457	Point Y2	%	-100.00 ... 100.00	15.1.1.1
Positioning				
📄 458	Operation mode	-	Selection	12.6
459	Signal source	-	Selection	12.6.1
📄 460	Positioning distance	U	0.000 ... 1 10 ⁶	12.6.1
📄 461	Signal correction	ms	-327.68 ... 327.67	12.6.1
📄 462	Load correction	-	-32768 ... 32767	12.6.1
📄 463	Activity after positioning	-	Selection	12.6.1
📄 464	Waiting time	ms	0 ... 3.6 10 ⁶	12.6.1
Temperature Adjustment				
📄 465	Operation mode	-	Selection	18.7.2
📄 466	Temperature coefficient	%/100	0.00 ... 300.00	18.7.2
📄 467	Adjusting temperature	deg.C	-50.0 ... 300.0	18.7.2
Positioning				
📄 469	Reference orientation	°	0.0 ... 359.9	12.6.2
📄 471	Positioning frequency	Hz	1.00 ... 50.00	12.6.2
📄 472	Max. positional error	°	0.1 ... 90.0	12.6.2
Motor Potentiometer				
473	Ramp Keypad Motorpoti	Hz/s	0.01 ... 999.99	14.10.3
474	Operation mode	-	Selection	14.10
Frequency reference channel				
📄 475	Reference frequency source	-	Selection	14.4
Reference percentage channel				
📄 476	Reference percentage source	-	Selection	14.5

Percentage ramp				
No.	Description	Unit	Setting range	Chapter
 477	Gradient percentage ramp	%/s	0 ... 60000	14.8
Technology Controller				
 478	Actual percentage source	-	Selection	17.3
Positioning				
 479	time constant positioning contr.	ms	1.00 ... 9999.99	12.6.2
Fixed Frequencies				
 480	Fixed frequency 1	Hz	-999.99 ... 999.99	14.6.1
 481	Fixed frequency 2	Hz	-999.99 ... 999.99	14.6.1
 482	Fixed frequency 3	Hz	-999.99 ... 999.99	14.6.1
 483	Fixed frequency 4	Hz	-999.99 ... 999.99	14.6.1
489	JOG frequency	Hz	-999.99 ... 999.99	14.6.2
Speed Sensor 1				
 490	Operation mode	-	Selection	10.4.1
 491	Division Marks	-	1 ... 8192	10.4.2
PWM-/repetition frequency input				
 496	Operation mode	-	Selection	14.11
 497	Divider	-	1 ... 8192	14.11
Brake Chopper				
506	Trigger threshold	V	225 ... 1000.0 (201) 425 ... 1000.0 (401)	18.4
Motor Chopper				
 507	Trigger threshold	V	225 ... 1000.0 (201) 425 ... 1000.0 (401)	18.7.1
Digital Outputs				
 510	Setting Frequency	Hz	0.00 ... 999.99	15.3.2
Speed Sensor 1				
511	EC1 Gear Factor Numerator	-	-300.00 ... 300.00	10.4.3
512	EC1 Gear Factor Denominator	-	0.01 ... 300.00	10.4.3
Speed controller				
515	Integral Time Speedtracking	ms	1 ... 60 000	17.5.4.3
Digital Outputs				
 517	Setting Frequency Off Delta	Hz	0.00 ... 999.99	15.3.2
Percentage Value Limits				
 518	Minimum Reference Percentage	%	0.00 ... 300.00	14.3
 519	Maximum Reference Percentage	%	0.00 ... 300.00	14.3
Fixed Percentages				
 520	Fixed percentage 1	%	-300.00 ... 300.00	14.6.3
 521	Fixed percentage 2	%	-300.00 ... 300.00	14.6.3
 522	Fixed percentage 3	%	-300.00 ... 300.00	14.6.3
 523	Fixed percentage 4	%	-300.00 ... 300.00	14.6.3
Digital Outputs				
530	Operation mode digital output 1	-	Selection	15.3
532	Operation mode digital output 3	-	Selection	15.3
535	Op. Mode ext. Error	-	Selection	15.4.12
536	Create Warning Mask	-	Selection	15.3.8
540	Operation mode comparator 1	-	Selection	15.5.2
541	Comparator On above	%	-300.00 ... 300.00	15.5.2

Digital Outputs				
No.	Description	Unit	Setting range	Chapter
542	Comparator Off below	%	-300.00 ... 300.00	15.5.2
543	Operation mode comparator 2	-	Selection	15.5.2
544	Comparator On above	%	-300.00 ... 300.00	15.5.2
545	Comparator Off below	%	-300.00 ... 300.00	15.5.2
549	Max. Control Deviation	%	0.01 ... 20.00	15.3.3
Multifunctional output 1				
550	Operation mode	-	Selection	15.2
551	Voltage 100%	V	0.0 ... 22.0	15.2.1.1
552	Voltage 0%	V	0.0 ... 24.0	15.2.1.1
553	Analog operation	-	Selection	15.2.1
554	Digital operation	-	Selection	15.3
Multifunctional output 1				
 555	Repetition frequency operation	-	Selection	15.2.2
 556	Division Marks	-	30 ... 8192	15.2.2.1
Error/warning behavior				
570	Motor Temp. Operation Mode	-	Selection	13.6
Motor protection switch				
 571	Operation mode	-	Selection	18.5
 572	Frequency Limit	%	0 ... 300	18.5
Intelligent current limits				
 573	Operation mode	-	Selection	17.1
 574	Power Limit	%	40.00 ... 95.00	17.1
 575	Limitation time	min	5 ... 300	17.1
Error/warning behavior				
 576	Phase supervision	-	Selection	13.7
578	Allowed no. of auto-acknowl.	-	0 ... 20	13.8
579	Restart delay	ms	0 ... 1000	13.8
Pulse Width Modulation				
580	Reduction Limit Ti/Tc	deg.C	-25 ... 0	18.1
V-belt Monitoring				
 581	Operation mode	-	Selection	18.5.2
 582	Trigger limit lactive	%	0.1 ... 100.0	18.5.2
 583	Delay time	s	0.1 ... 600.0	18.5.2
V/f characteristic				
  600	Starting voltage	V	0.0 ... 100.0	16
  601	Voltage rise	%	-100 ... 200	16
  602	Rise frequency	%	0 ... 100	16
  603	Cut-off voltage	V	60.0 ... 560.0	16
  604	Cut-off frequency	Hz	0.00 ... 999.99	16
 605	Dyn. voltage pre-control	%	0 ... 200	16.1
Current limit value controller				
 610	Operation mode	-	Selection	17.4.2
 611	Amplification	-	0.01 ... 30.00	17.4.2
 612	Integral time	ms	1 10000	17.4.2
 613	Current Limit	A	0.0 ... 0 · I _{FIN}	17.4.2
  614	Frequency Limit	Hz	0.00 ... 999.99	17.4.2
Error/Warning Behaviour				
617	Max Temp. Windings	°C	0 ... 200	13.6
Technology Controller				
618	Derivative Time	ms	0 ... 1000	17.3

Starting Behavior				
No.	Description	Unit	Setting range	Chapter
✓ 	620 Operation mode	-	Selection	12.1.1
	621 Amplification	-	0.01 ... 10.00	12.1.1
	622 Integral time	ms	1 ... 30000	12.1.1
✓ 	623 Starting Current	A	0.0 ... $0 \cdot I_{FIN}$	12.1.1.1
✓ 	624 Frequency Limit	Hz	0.00 ... 100.00	12.1.1.2
	625 Brake release time	ms	-5000 ... 5000	12.1.1.3
Warning application				
	626 Create Appl. Warning Mask	-	Selection	15.3.9
Stopping Behavior				
	630 Operation mode	-	Selection	12.2
Direct current brake				
✓ 	631 Braking current	A	0.00 ... $\sqrt{2} \cdot I_{FIN}$	12.3
	632 Braking time	s	0.0 ... 200.0	12.3
✓ 	633 Demagnetizing time	s	0.1 ... 30.0	12.3
	634 Amplification	-	0.00 ... 10.00	12.3
	635 Integral time	ms	0 ... 1000	12.3
Stopping Behavior				
	637 Switch-off threshold	%	0.0 ... 100.0	12.2.1
	638 Holding time	s	0.0 ... 200.0	12.2.2
Search Run				
	645 Operation mode	-	Selection	12.5
	646 Brak. time after search run	s	0.0 ... 200.0	12.5
	647 Current / rated motor current	%	1.00 ... 100.00	12.5
	648 Amplification	-	0.00 ... 10.00	12.5
	649 Integral time	ms	0 ... 1000	12.5
Auto Start				
	651 Operation mode	-	Selection	12.4
PWM-/repetition frequency input				
	652 PWM-Offset	%	-100.00 ... 100.00	14.11
	653 PWM-Amplification	%	5.0 ... 1000.0	14.11
Slip compensation				
✓ 	660 Operation mode	-	Selection	17.4.1
	661 Amplification	%	0.0 ... 300.0	17.4.1
	662 Max. Slip Ramp	Hz/s	0.01 ... 650.00	17.4.1
	663 Minimum Frequency	Hz	0.01 ... 999.99	17.4.1
Voltage controller				
	670 Operation mode	-	Selection	17.2
	671 Mains failure threshold	V	-200.0 ... -50.0	17.2
	672 Reference mains support value	V	-200.0 ... -10.0	17.2
	673 Mains support deceleration	Hz/s	0.01 ... 9999.99	17.2
	674 Acceleration on mains resumption	Hz/s	0.00 ... 9999.99	17.2
	675 Shutdown threshold	Hz	0.00 ... 999.99	17.2
	676 Reference shutdown value	V	225 ... 387.5 (201) 425 ... 775 (401)	17.2
	677 Amplification	-	0.00 ... 30.00	17.2
	678 Integral time	ms	0 ... 10000	17.2
	680 Reference DC link limitation	V	225 ... 387,5 (201) 425 ... 775 (401)	17.2
	681 Max. frequency rise	Hz	0.00 ... 999.99	17.2
	683 Gen. ref. current limit	A	0.0 ... $0 \cdot I_{FIN}$	17.2

Current Controller				
No.	Description	Unit	Setting range	Chapter
✓ 	700 Amplification	-	0.00 ... 8.00	17.5.1
✓ 	701 Integral time	ms	0.00 ... 10.00	17.5.1
Further motor parameters				
✓ 	713 Magnetizing current 50% flux	%	1 ... 50	10.2.3
✓ 	714 Magnetizing current 80% flux	%	1 ... 80	10.2.3
✓ 	715 Magnetizing current 110% flux	%	110 ... 197	10.2.3
✓ 	716 Rated magnetizing current	A	$0.01 \cdot I_{FIN} \dots 0 \cdot I_{FIN}$	10.2.3
Field Controller				
✓ 	717 Reference Flux	%	0.01 ... 300.00	17.5.6
Further motor parameters				
✓ 	718 Rated slip correction factor	%	0.01 ... 300.00	10.2.4
Frequency Limits				
	719 Slip Frequency	%	0 ... 10000	14.2
Speed controller				
	720 Operation mode	-	Selection	17.5.4
✓ 	721 Amplification 1	-	0.00 ... 200.00	17.5.4
	722 Integral time 1	ms	0 ... 60000	17.5.4
✓ 	723 Amplification 2	-	0.00 ... 200.00	17.5.4
	724 Integral time 2	ms	0 ... 60000	17.5.4
Acceleration Pre-Control				
	725 Operation mode	-	Selection	17.5.5
	726 Minimum acceleration	Hz/s	0.1 ... 6500.0	17.5.5
	727 Mech. time constant	ms	1 ... 60000	17.5.5
Speed controller				
	728 Current Limit	A	$0.0 \dots 0 \cdot I_{FIN}$	17.5.4.1
	729 Current limit generator operation	A	$-0.1 \dots 0 \cdot I_{FIN}$	17.5.4.1
	730 Torque limit	%	0.00 ... 650.00	17.5.4.1
	731 Torque limit generator operation	%	0.00 ... 650.00	17.5.4.1
	732 P comp. torque upper limit	%	0.00 ... 650.00	17.5.4.1
	733 P comp. torque lower limit	%	0.00 ... 650.00	17.5.4.1
Speed controller				
	734 Isq limit source motor operation	-	Selection	17.5.4.2
	735 Isq limit source gen. operation	-	Selection	17.5.4.2
	736 Torque limit source motor operation	-	Selection	17.5.4.2
	737 Torque limit source gen. operation	-	Selection	17.5.4.2
✓ 	738 Speed control switch-over limit	Hz	0.00 ... 999.99	17.5.4
	739 Power Limit	kW	$0.00 \dots 2 \cdot 0 \cdot P_{FIN}$	17.5.4.1
	740 Power limit generator operation	kW	$0.00 \dots 2 \cdot 0 \cdot P_{FIN}$	17.5.4.1
Field Controller				
	741 Amplification	-	0.0 ... 100.0	17.5.6
✓ 	742 Integral time	ms	0.0 ... 1000.0	17.5.6
✓ 	743 Ref. Isd upper limit	A	$0 \dots 0 \cdot I_{FIN}$	17.5.6.1
✓ 	744 Ref. Isd lower limit	A	$-I_{FIN} \dots I_{FIN}$	17.5.6.1
Speed controller				
	748 Backlash damping	%	0 ... 300	17.5.4
Modulation Controller				
	750 Reference modulator	%	3.00 ... 105.00	17.5.7
	752 Integral time	ms	0.0 ... 1000.00	17.5.7

Modulation Controller					
No.	Description	Unit	Setting range	Chapter	
	753 Operation mode	-	Selection	17.5.7	
Modulation Controller					
	754 Filter time constant	ms	0...128	17.5.4	
Modulation Controller					
	755 Reference Imr lower limit	A	$0.01 \cdot I_{FIN} \dots 0 \cdot I_{FIN}$	17.5.7.1	
	756 Control deviation limitation	%	0.00 ... 100.00	17.5.7.1	
Current Controller					
		757 Current below P. 700 is in effect	A	$0.00 \cdot \dots 0 \cdot I_{FIN}$	17.5.2
		758 Current above P. 759 is in effect	A	$0.00 \cdot \dots 0 \cdot I_{FIN}$	17.5.2
		759 Amplification high Current	-	0.00 ... 8.00	17.5.2
Speed Sensor Monitoring					
	760 Operation mode	-	Selection	18.7.3	
	761 Timeout: Signal fault	ms	0 ... 65000	18.7.3	
	762 Timeout: Track fault	ms	0 ... 65000	18.7.3	
	763 Timeout: Direction of rotation fault	ms	0 ... 65000	18.7.3	
Speed controller					
	766 Source of actual speed value	-	Selection	17.5.4	
Torque Controller					
	767 Frequency upper limit	Hz	-999.99 ... 999.99	17.5.2	
	768 Frequency lower limit	Hz	-999.99 ... 999.99	17.5.2	
	769 Frequency upper limit source	-	Selection	17.5.2	
	770 Frequency lower limit source	-	Selection	17.5.2	
Current Controller					
		775 Current above P. 700 is in effect	A	$0.00 \cdot \dots 0 \cdot I_{FIN}$	17.5.2
		776 Current below P. 777 is in effect	A	$0.00 \cdot \dots 0 \cdot I_{FIN}$	17.5.2
		777 Amplification low Current	-	0.00 ... 8.00	17.5.2
Field Controller					
	778 Reduction Factor Flux	%	20.00 ... 100.00	17.5.6	
Starting Behavior					
		779 Min. Flux-Formation Time	ms	1 ... 10000	12.1.2
		780 Max. flux formation time	ms	1 ... 10000	12.1.2
		781 Current during flux formation	A	$0.1 \cdot I_{FIN} \dots 0 \cdot I_{FIN}$	12.1.2
Timer					
	790 Operation mode Timer 1	-	Selection	15.5.1	
	791 Time 1 Timer 1	s/m/h	0 ... 650.00	15.5.1.1	
	792 Time 2 Timer 1	s/m/h	0 ... 650.00	15.5.1.1	
	793 Operation mode Timer 2	-	Selection	15.5.1	
	794 Time 1 Timer 2	s/m/h	0 ... 650.00	15.5.1	
	795 Time 2 Timer 2	s/m/h	0 ... 650.00	15.5.1	
Self-configuration					
	796 SET-UP Select	-	Selection	8.5	
Further motor parameters					
	1190 Stator Resistance	Ohm	0.001 ... 100.000	10.2.1	
	1192 Peak current	A	$0.01\% I_{FIN} \dots 100\,000\% 0 I_{FIN}$	10.2.7	
Filter encoder 1					
	1193 EC1: Filter time constant	us	0...32000	10.4.4	
Further motor parameters					
	1199 Change Sense of Rotation	-	Selection	10.2.8	

Mux/DeMux				
No.	Description	Unit	Setting range	Chapter
1250	Mux Input Index (write)	-	EEPROM: 0 ... 16 RAM: 17 ... 33	15.5.4
1251	Mux Input Index (read)	-	EEPROM: 0 ... 16 RAM: 17 ... 33	15.5.4
1252	Mux input	-	Selection	15.5.4
1253	DeMux input	-	Selection	15.5.4
User warnings				
1363	User warning 1	-	Selection	15.4.11
1364	User warning 2	-	Selection	15.4.11
Self-configuration				
1370	In-F-PDP-word 1	-	Selection	18.9
1371	In-F-PDP-word 2	-	Selection	18.9
1372	In-F-intern-long 1	-	Selection	18.9
1373	In-F-intern-long 2	-	Selection	18.9
1374	In-F-Convert-Reference	Hz	0.01...999.99	18.9



At the control unit KP500 parameter numbers > 999 are displayed hexadecimal at the leading digit (999, A00 ... B5 ... C66).

Index

A

Acceleration	163
Acceleration pre-control	236
Actual value memory	261
Actual values	
of the frequency inverter	257
of the machine	260
of the system	262
Application warning mask	190
Axle positioning.....	147

B

Block frequencies	166
Brake	
Control via digital output	186
DC braking	140
Brake chopper.....	243
Brake release	186
Brake resistance.....	243
Brake resistor	
Connection	59
Dimensioning.....	244
Bus controller.....	241

C

Cable length	57
CE conformity	30
Commissioning.....	101
Communication module	53
Comparator	204
Comparison of actual values.....	204
Conductor cross-section.....	54
Configurations	
Connection diagrams.....	73
Overview.....	74, 102, 119
Control functions.....	210
Intelligent current limits.....	210
Power failure regulation.....	213
Technology controller	216
Voltage controller.....	211
Control signals	191
Control terminals.....	70, 290
Technical data	31
Control unit	53, 87
Menu	88
Motor control.....	98
Copy parameter values	91
Error messages.....	94
Copyright.....	13
Current controller	227
Extended.....	229
Current limit value controller	226
Current limitation	186

D

Data set	104
Data set change-over	198
Deceleration	163
Decommissioning	22
Demultiplexer	206
Designated use	15
Diagnosis.....	271
Digital inputs	

Logic signals.....	191
Technical data	31, 52
Digital outputs	
Logic signals.....	180
Technical data	31, 52

Direction of rotation

Change	127
Check	113
Start clockwise, Start anticlockwise.....	196

E

Electrical connections	20
EMC	50
Encoder.....	114
Connection	58
Division marks	130
Evaluation	128, 132
Gear factor	131
Monitoring.....	253
Error acknowledgment	
automatic.....	153
via logic signal	197
Error environment	269
Error list	264
Error messages	264
of auto-setup.....	110
Expansion module	53
External error.....	200
External fan	186
External power supply	72

F

Fan	241
external	186
Field controller	237
Filter time constant.....	175
Filter time constant speed sensor 1.....	131
Fixed frequencies	161
Fixed frequency change-over.....	199
Fixed percentage change-over.....	199
Fixed percentages	162
Flow control.....	220
Flux forming finished	186
Frequency ramps.....	163
Function table	205

G

General information about the documentation	10
Group drive	58

H

Hysteresis	
of analog input signal	175
Technology controller	218

I


Installation	20
Electrical	48, 60
Mechanical	42
Instruction manuals.....	10
Intelligent current limits	210
Inverter data	118

J

JOG frequency	162
---------------------	-----

L		
Level control	221, 222	
Limit value sources	231	
M		
Machine data	104, 105, 123	
Mains connection	60	
Modulation controller	239	
Monitoring		
Active current	250	
Analog input signal	176	
Application warning mask	190	
Controller intervention	151	
DC component	151	
Heat sink temperature	150	
Load	250	
Motor temperature	152, 245	
Output frequency	152	
Overload	150	
Phase failure	153	
Warning mask	187	
Motor chopper	251	
Motor connection	60	
Motor Connection	56	
Motor potentiometer	167, 199	
Motor protection	245	
Motor Protection		
Motor Protection by I2t- Monitoring	248	
Motor temperature	252	
Multi-function input	172	
Multi-function output	177	
Multiplexer	206	
P		
Parameter identification	107	
Parameter list	275	
Percentage value ramps	166	
Plausibility check	106	
Positioning		
Axle positioning	147	
starting from reference point	144	
Power failure regulation	213	
Pressure control	133, 220, 263	
Pulse width modulation	240	
PWM input	170	
R		
Reference frequency channel	154	
Reference percentage channel	158	
Reference positioning	144	
Reference value		
Fixed frequency	161	
Fixed reference value	161	
JOG frequency	162	
Motor potentiometer	167	
reached	185	
Reference values	154	
Fixed percentages	162	
Relay output	72	
Technical data	31	
Repetition frequency input	170	
Reset	97	
S		
SA Warning messages auto set-up	108	
Safe torque off	23	
Safety		
General	14	
Safety function		
Status of the inputs	259	
Service	22	
Setting frequency	184	
Set-up	116	
SF Error messages auto-setup	110	
Slip compensation	226	
Speed controller	232	
Switch-over speed-/torque control	197	
Speed sensor	114	
Division marks	130	
Evaluation	128, 132	
Gear factor	131	
Monitoring	253	
Speed sensor connection	58	
SS Status messages auto-setup	108	
Start anticlockwise	196	
Start clockwise	196	
Starting behavior	134	
Stopping behavior	138	
Storage	20	
T		
Technical Data	30	
Technology Controller	216	
Temperature adjustment	252	
Temperature measurement	252	
Thermal contact	73, 197	
Three-wire control	196	
Timer	197, 201	
Tolerance band	174	
Torque controller	229	
Torque Reference	230	
Transport	20	
Traverse function	254	
U		
UL Approval	30	
User warning	200	
V		
V/f-characteristic	208	
Voltage controller	211	
Voltage input	72	
Volume flow control	133, 263	
Volumetric flow control	220	
W		
Warning code		
of Application warning mask	191	
of warning mask	188, 189	
Warning mask	187	
Warning messages	273	
of auto set-up	108	
Warning status	273	
Application	273	
Warranty and liability	12	
X		
X210A	71	
X210B	71	

Functions of the control terminals (table)



Functions of the control terminals in the standard configurations

Speed/Torque control change-over		Technology controller		Speed controlled	
230	430 530 630	111	211 411 611	110 210 410 510 610	
STOA/Error acknowledgement ¹⁾		STOA/Error acknowledgement ¹⁾		STOA/Error acknowledgement ¹⁾	
Start Clockwise operation		Fixed percentage value change-over 1		Start Clockwise operation	
Speed/Torque control change-over		No function	211 411 611	Start Anticlockwise operation	
		Speed sensor track B	430 530		
Speed sensor track B	230	Data set change-over 1 ²⁾	111 411	Speed sensor track B	210
Speed sensor track A	230	Data set change-over 2	611	Speed sensor track A	210
Motor thermal contact		Motor thermal contact		Motor thermal contact	
STOB/Error acknowledgement ¹⁾		STOB/Error acknowledgement ¹⁾		STOB/Error acknowledgement ¹⁾	
Run signal		Run signal		Run signal	
Actual frequency		Actual frequency		Actual frequency	
Reference speed or Reference percentage value (torque)		Actual percentage value		Reference speed	

Error signal, inverted		Error signal, inverted		Error signal, inverted	
Relay n.c.c.	1	Relay n.c.c.	1	Relay n.c.c.	1
S3OUT	2	S3OUT	2	S3OUT	2
Relay n.o.c.	3	Relay n.o.c.	3	Relay n.o.c.	3

S11IND ... S7IND: Digital inputs, S10OUT: Digital outputs, MFO1: Multi-function output (factory setting as analog output), MF11: Multi-function input (factory setting as analog voltage input), S3OUT: Relay output, ↔ bidirectional, → input, ← output, n.c.c.: normally closed contact, n.o.c.: normally open contact,

¹⁾ Error acknowledgement via STOA or STOB,

²⁾ Linked to Timer 1 (Data Set Change-Over I 70 = "158 - Timer 1", Timer I 83 = "73 - S4IND", factory setting Time I Timer I 791 = 0.00 s/m/h)

Bonfiglioli worldwide network.

Bonfiglioli Australia

2, Cox Place Glendenning NSW 2761
Locked Bag 1000 Plump-ton NSW 2761
Tel. (+ 61) 2 8811 8000 - Fax (+ 61) 2 9675 6605
www.bonfiglioli.com.au - sales@bonfiglioli.com.au

Bonfiglioli Brazil

Travessa Cláudio Armando 171 - Bloco 3
CEP 09861-730 - Bairro Assunção
São Bernardo do Campo - São Paulo
Tel. (+55) 11 4344 1900 - Fax (+55) 11 4344 1906
www.bonfigliolidobrasil.com.br
bonfigliolidobrasil@bonfiglioli.com

Bonfiglioli Canada

2-7941 Jane Street - Concord, Ontario L4K 4L6
Tel. (+1) 905 7384466 - Fax (+1) 905 7389833
www.bonfigliolicanada.com
sales@bonfigliolicanada.com

Bonfiglioli China

19D, No. 360 Pu Dong Nan Road
New Shanghai International Tower
200120 Shanghai
Tel. (+86) 21 5054 3357 - Fax (+86) 21 5970 2957
www.bonfiglioli.cn - bdssales@bonfiglioli.com.cn

Bonfiglioli Deutschland

Sperberweg 12 - 41468 Neuss
Tel. (+49) 02131 2988-0
Fax (+49) 02131 2988-100
www.bonfiglioli.de - info@bonfiglioli.de

Bonfiglioli España

TECNOTRANS BONFIGLIOLI S.A.
Pol. Ind. Zona Franca sector C, calle F, nº6
08040 Barcelona
Tel. (+34) 93 4478400 - Fax (+34) 93 3360402
www.tecnotrans.com - tecnotrans@tecnotrans.com

Bonfiglioli France

14 Rue Eugène Pottier BP 19
Zone Industrielle de Moimont II
95670 Marly la Ville
Tel. (+33) 1 34474510 - Fax (+33) 1 34688800
www.bonfiglioli.fr - btf@bonfiglioli.fr

Bonfiglioli India

PLOT AC7-AC11 Sidco Industrial Estate
Thirumudivakkam - Chennai 600 044
Tel. +91(0) 44 24781035 - 24781036 - 24781037
Fax +91(0) 44 24780091 - 24781904
www.bonfiglioliindia.com - bonfig@vsnl.com

Bonfiglioli Italia

Via Sandro Pertini lotto 7b
20080 Carpiano (Milano)
Tel. (+39) 02 985081 - Fax (+39) 02 985085817
www.bonfiglioli.it
customerservice.italia@bonfiglioli.it

Bonfiglioli New Zealand

88 Hastie Avenue, Mangere Bridge, Auckland
2022, New Zealand - PO Box 11795, Ellerslie
Tel. (+64) 09 634 6441 - Fax (+64) 09 634 6445
npollington@bonfiglioli.com.au

Bonfiglioli Österreich

Molkereistr 4 - A-2700 Wiener Neustadt
Tel. (+43) 02622 22400 - Fax (+43) 02622 22386
www.bonfiglioli.at
info@bonfiglioli.at

Bonfiglioli South East Asia

No 21 Woodlands industrial park E1
#02-03 Singapore 757720
Tel. (+65) 6893 6346/7 - Fax (+65) 6893 6342
www.bonfiglioli.com.au
sales@bonfiglioli.com.sg

Bonfiglioli South Africa

55 Galaxy Avenue,
Linbro Business Park - Sandton
Tel. (+27) 11 608 2030 OR - Fax (+27) 11 608 2631
www.bonfiglioli.co.za
bonfigsales@bonfiglioli.co.za

Bonfiglioli Türkiye

Atatürk Organize Sanayi Bölgesi,
10015 Sk. No: 17, Çigli - Izmir
Tel. +90 (0) 232 328 22 77 (pbx)
Fax +90 (0) 232 328 04 14
www.bonfiglioli.com.tr
info@bonfiglioli.com.tr

Bonfiglioli United Kingdom

Industrial Solutions
Unit 7, Colemeadow Road
North Moons Moat - Redditch,
Worcestershire B98 9PB
Tel. (+44) 1527 65022 - Fax (+44) 1527 61995
www.bonfiglioli.com
uksales@bonfiglioli.com
Mobile Solutions
3 - 7 Grosvenor Grange, Woolston
Warrington - Cheshire WA1 4SF
Tel. (+44) 1925 852667 - Fax (+44) 1925 852668
www.bonfiglioli.co.uk
mobilesales@bonfiglioli.co.uk

Bonfiglioli USA

3541 Hargrave Drive Hebron, Kentucky 41048
Tel. (+1) 859 334 3333 - Fax (+1) 859 334 8888
www.bonfiglioliusa.com

Bonfiglioli Vietnam

Lot C-9D-CN My Phuoc Industrial Park 3
Ben Cat - Binh Duong Province
Tel. (+84) 650 3577411 - Fax (+84) 650 3577422
www.bonfiglioli.vn
salesvn@bonfiglioli.com



Bonfiglioli has been designing and developing innovative and reliable power transmission and control solutions for industry, mobile machinery and renewable energy applications since 1956.